

Reloading Die Spare Parts - Headpiece M26x1,5/M8x1

[Reloading](#) > [Reloading Dies](#) > [Replacement Parts & Upgrades](#)

Headpiece, made from steel, blued and precision-manufactured – top retaining nut for reloading dies with spindle pass-through. Ensures secure guidance and fixation of the spindle. Suitable for original dies from Triebel
Waffenwerkzeuge.



Attributes

- Name: [Headpiece M26x1,5/M8x1](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017586
- Mfr. No.: 3000131V
- Thread: M26x1,5 / M8x1
- Delivery weight: 0.05kg
- Shipping height: 30mm
- Shipping width: 30mm
- Shipping length: 30mm
- EAN/UPC: 3000131V

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Reloading Die Spare Parts Headpiece M26x1.5/M8x1](#)
- [About Us](#)

Safety Instruction Guide for Reloading Die Spare Parts Headpiece M26x1.5/M8x1

Introduction

Thank you for choosing the Reloading Die Spare Parts Headpiece M26x1.5/M8x1. This guide aims to provide you with essential safety information, installation instructions, and usage guidelines to ensure a safe and effective experience with this product. Please read this guide carefully before use.

General Safety Guidelines

- Always ensure that the product is used in accordance with the manufacturer's specifications.
- Inspect the headpiece for any visible damage or defects before use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose to avoid potential hazards.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about recalls and safety notices on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the headpiece.
- Ensure that the work area is clean and free from obstructions to prevent accidents.
- Avoid using excessive force during installation or adjustment to prevent damage to the headpiece or reloading die.
- Do not modify the headpiece or use it in a way not intended by the manufacturer.
- Be cautious of sharp edges and points when handling the headpiece.

Instructions for Installation and Usage

1. Installation

- Ensure that the reloading die is securely mounted in the press.
- Align the headpiece with the spindle passthrough.
- Thread the top retaining nut onto the spindle, ensuring a snug fit without overtightening.
- Check that the headpiece is securely in place and that the spindle can move freely.

2. Usage

- Follow the manufacturer's instructions for reloading operations.
- Monitor the headpiece for any signs of wear or damage during use.
- If you encounter any issues, stop using the product immediately and inspect it for problems.

3. Maintenance

- Regularly clean the headpiece to remove debris and maintain its functionality.
- Store the headpiece in a dry and safe location when not in use to prevent corrosion or damage.

Disposal Instructions

- Dispose of the headpiece in accordance with local regulations regarding metal waste.
- Do not dispose of the headpiece in regular household waste.
- Consider recycling options for metal components to minimize environmental impact.

Contact Information for Further Support

For any inquiries or concerns regarding safety or usage of the Reloading Die Spare Parts Headpiece M26x1.5/M8x1, please refer to the manufacturer's contact information provided with the product packaging or visit the manufacturer's website.

Thank you for your attention to these safety instructions. Your adherence to these guidelines will help ensure a safe and effective experience with your Reloading Die Spare Parts Headpiece M26x1.5/M8x1.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk