

OPTIMIZED GAME CHANGER, MULTICAM

Dread Those Uncomfortable Shooting Positions No Longer

The OG by Armageddon Gear takes us back to the roots of Reasor Precision's simple solver that changed the game of positional shooting. Origins of Reasor's grasping front support bag for firearm stability began with a specific shape, heavy-poly fill blend and pliable shell to yield the most effective and versatile solution developed for those uncomfortable positions that marksmen used to dread. Also available in a Waxed Canvas version. 1000D Cordura fabric or Waxed Canvas Includes two handles on opposite ends for ambidextrous use Total weight of over 6 pounds and filled with Reasor Precision Solutions approved recycled plastic fill Dimensions: approximately 10" Long, 7" Tall and 6" Wide Zipper access to adjust fill to user desired ratio A note on shooting bags: Most positional shooting bags are not filled firmly on purpose. The reason being a loose filled bag will fill in gaps, drape across obstacles, and create a more stable shooting platform than a firm filled bag.



Attributes

- Name: OPTIMIZED GAME CHANGER, MULTICAM
- Manufacturer: ARMAGEDDON GEAR
- Product no.: 100033325
- Mfr. No.: AG0683-MC
- Color: Multi-Cam
- Material: Cordura
- Delivery weight: 2.948kg

Item details

Made in USA

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für das OPTIMIZED GAME CHANGER ARMAGEDDON GEAR
- English: Safety Instruction Guide for OPTIMIZED GAME CHANGER

Sicherheitshinweise für das OPTIMIZED GAME CHANGER ARMAGEDDON GEAR

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des OPTIMIZED GAME CHANGER ARMAGEDDON GEAR. Dieses Produkt wurde entwickelt, um Ihnen bei Positionsschießen mehr Stabilität zu bieten. Um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen, lesen Sie bitte die folgenden Sicherheitshinweise sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt vor der Verwendung auf sichtbare Schäden überprüft wird.
- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Achten Sie darauf, dass das Produkt nicht in der Nähe von offenen Flammen oder extremen Temperaturen gelagert wird.
- Überprüfen Sie regelmäßig auf mögliche Abnutzungserscheinungen oder Schäden.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie den Schießsack nur auf stabilen, ebenen Flächen.
- Achten Sie darauf, dass der Sack nicht überladen wird, um ein Umkippen oder Verrutschen zu vermeiden.
- Verwenden Sie den Reißverschluss nur zum Anpassen der Füllung. Übermäßiger Druck kann den Reißverschluss beschädigen.
- Vermeiden Sie es, den Sack in feuchten oder nassen Umgebungen zu verwenden, um Schimmelbildung zu verhindern.
- Bei Anzeichen von Beschädigungen oder Verschleiß, stellen Sie die Verwendung sofort ein und ersetzen Sie das Produkt.

Anweisungen zur Installation und Nutzung

1. Vorbereitung

- Überprüfen Sie den Schießsack auf sichtbare Schäden, bevor Sie ihn verwenden.
- Wählen Sie einen stabilen Platz für die Verwendung des Sacks.

2. Füllung anpassen

- Öffnen Sie den Reißverschluss und fügen Sie bei Bedarf Füllmaterial hinzu oder entnehmen Sie es, um das gewünschte Verhältnis zu erreichen.
- Schließen Sie den Reißverschluss sorgfältig, nachdem Sie die Füllung angepasst haben.

3. Verwendung

- Platzieren Sie den Sack unter Ihrer Waffe, um eine stabile Schießplattform zu schaffen.
- Achten Sie darauf, dass der Sack bei der Verwendung nicht verrutscht.

4. Nach der Nutzung

- Reinigen Sie den Sack bei Bedarf mit einem feuchten Tuch.
- Lagern Sie den Sack an einem trockenen, kühlen Ort.

Entsorgungsanweisungen

- Entsorgen Sie den Schießsack gemäß den örtlichen Vorschriften für Kunststoffabfälle.
- Stellen Sie sicher, dass alle Füllmaterialien umweltgerecht entsorgt werden.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zur Sicherheit Ihres Produkts wenden Sie sich bitte an den Hersteller. Es ist wichtig, bei Sicherheitsanfragen einen Ansprechpartner zu haben.

Bitte beachten Sie, dass die Sicherheit und Zufriedenheit der Benutzer an erster Stelle stehen. Halten Sie sich an diese Richtlinien, um eine sichere Nutzung des OPTIMIZED GAME CHANGER ARMAGEDDON GEAR zu gewährleisten.

Safety Instruction Guide for OPTIMIZED GAME CHANGER

Introduction

Thank you for choosing the OPTIMIZED GAME CHANGER by Armageddon Gear. This product is designed to enhance your shooting experience by providing stability and support. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always inspect the product before use to ensure it is in good condition.
- Use the product only for its intended purpose; do not use it for any other activities.
- Keep the product out of reach of children and vulnerable individuals.
- If you notice any damage or irregularities, discontinue use immediately and contact the manufacturer.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the bag is filled to your desired firmness for optimal stability.
- Avoid using the product on unstable or uneven surfaces that may cause accidents.
- Do not exceed the recommended weight limit of the bag.
- Be cautious when adjusting the fill; ensure the zipper is securely closed after adjustment.
- Always maintain proper firearm safety practices while using the product.

Instructions for Installation and Usage

1. **Unboxing:** Carefully remove the product from its packaging and check for any visible damage.
2. **Filling Adjustment:**
 - Locate the zipper on the bag.
 - Open the zipper carefully to access the fill material.
 - Adjust the fill to your preferred firmness by adding or removing material.
 - Close the zipper securely to ensure no material escapes during use.
3. **Using the Bag:**
 - Position the bag in your shooting area.
 - Place your firearm on the bag, ensuring it is stable and secure.
 - Use the handles on opposite ends for ambidextrous support as needed.
4. **PostUse Care:**
 - Store the bag in a dry place away from direct sunlight.
 - Regularly check for wear and tear.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the product is damaged beyond use, consider recycling the materials where possible.
- Do not incinerate the bag as it may release harmful substances.

Contact Information for Further Support

For any inquiries or concerns regarding the OPTIMIZED GAME CHANGER, please refer to the manufacturer's website or customer support resources.

By following these safety instructions, you can ensure a safe and enjoyable experience with your OPTIMIZED GAME CHANGER. Thank you for your attention to these important guidelines.