

# 1873 CATTLEMAN EL PATRON COMPETITION REVOLVER - 1873 CATTLEMAN EL PATRON COMPETITION 357 MAG 5.5" BBL BLUED

Uberti's 1873 El Patr?n Competition features a low-angle hammer. It provides for easy access and quick shooting, whatever your preferred discipline. Plus, it shares the same authentic features of the 1873 Cattleman El Patr?n.



## Attributes

- Name: 1873 CATTLEMAN EL PATRON COMPETITION 357 MAG 5.5" BBL BLUED
- Manufacturer: UBERTI
- Product no.: 430101614
- Mfr. No.:
- Action Type: Single Action
- Barrel Length: 5.5"
- Capacity: 6-Round
- Cartridge: 357 Magnum
- Finish: Polished
- Front Sight: Blade
- Length: NA
- Magazine Included: NA
- Magazine Type: Fixed
- Make: Uberti
- Model: 1873 Cattleman
- Muzzle: Non-Threaded
- Rear Sight: None
- Stock Material: Walnut
- Weight: NA
- Delivery weight: 1.497kg
- Shipping height: 51mm
- Shipping width: 152mm
- Shipping length: 305mm
- UPC: 037084999241

## Item details

US export classification: 0A501.a

# Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für den 1873 CATTLEMAN EL PATRON COMPETITION REVOLVER
- English: Safety Instruction Guide for the 1873 Cattleman El Patron Competition Revolver

# Sicherheitshinweise für den 1873 CATTLEMAN EL PATRON COMPETITION REVOLVER

## Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des Uberti 1873 Cattleman El Patrón Competition Revolvers. Dieser Revolver bietet Ihnen nicht nur eine herausragende Leistung, sondern auch ein authentisches Design. Um sicherzustellen, dass Sie Ihr Produkt sicher und verantwortungsvoll verwenden, haben wir diese Sicherheitshinweise zusammengestellt. Bitte lesen Sie diese sorgfältig durch.

## Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie den Revolver nur in einem sicheren und kontrollierten Umfeld verwenden.
- Halten Sie den Revolver immer in einem sicheren Zustand, auch wenn er nicht verwendet wird.
- Bewahren Sie den Revolver außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Überprüfen Sie regelmäßig, ob der Revolver ordnungsgemäß funktioniert und keine sichtbaren Schäden aufweist.
- Melden Sie unsichere Produkte oder Unfälle umgehend den zuständigen Behörden.

## Spezifische Sicherheitsvorkehrungen für die Nutzung

- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille, während der Nutzung.
- Achten Sie darauf, dass der Lauf des Revolvers frei von Hindernissen ist, bevor Sie schießen.
- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Stellen Sie sicher, dass sich keine Personen oder Tiere im Schussfeld befinden, bevor Sie abdrücken.
- Üben Sie verantwortungsbewusstes Schießen und befolgen Sie alle örtlichen Gesetze und Vorschriften.

## Anweisungen zur Installation und Nutzung

### 1. Überprüfung des Revolvers:

- Stellen Sie sicher, dass der Revolver entladen ist, bevor Sie ihn inspizieren oder reinigen.
- Überprüfen Sie den Zustand des Laufes und der Mechanik.

### 2. Laden des Revolvers:

- Öffnen Sie den Zylinder und laden Sie die Munition in die Kammern.
- Schließen Sie den Zylinder sicher, bevor Sie den Revolver verwenden.

### 3. Zielen und Schießen:

- Halten Sie den Revolver mit beiden Händen fest und zielen Sie auf Ihr Ziel.
- Drücken Sie den Abzug sanft und gleichmäßig.

### 4. Reinigung und Wartung:

- Reinigen Sie den Revolver regelmäßig, um eine optimale Leistung zu gewährleisten.
- Verwenden Sie geeignete Reinigungsmittel und werkzeuge gemäß den Herstelleranweisungen.

## Entsorgungsanweisungen

- Entsorgen Sie Munition und Zubehör gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Geben Sie den Revolver niemals ungesichert oder ohne die entsprechenden Sicherheitsvorkehrungen ab.
- Wenden Sie sich an einen Fachmann, wenn Sie den Revolver dauerhaft entsorgen möchten.

## Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrem Produkt stehen Ihnen verschiedene Ressourcen zur Verfügung.  
Bitte konsultieren Sie die Website des Herstellers oder wenden Sie sich an Ihren Händler.

## **Schlussfolgerung**

Die Sicherheit bei der Nutzung des Uberti 1873 Cattleman El Patrón Competition Revolvers ist von großer Bedeutung. Indem Sie diese Sicherheitshinweise befolgen, tragen Sie dazu bei, sich selbst und andere zu schützen. Vielen Dank, dass Sie sich für unser Produkt entschieden haben.

# Safety Instruction Guide for the 1873 Cattleman El Patron Competition Revolver

## Introduction

Thank you for choosing the 1873 Cattleman El Patron Competition Revolver. This guide provides essential safety instructions and guidelines to ensure the safe use of your revolver. It is important to follow these instructions to minimize risks and ensure a safe shooting experience.

## General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store firearms securely and out of reach of children.
- Use appropriate eye and ear protection when shooting.
- Regularly inspect your revolver for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

## Specific Safety Precautions for Use

- Ensure the revolver is unloaded before handling or cleaning.
- Do not rely solely on the revolver's safety features; always follow safe handling practices.
- Use only the recommended ammunition type (357 Magnum) for your revolver.
- Avoid using damaged or defective ammunition.
- Do not modify the revolver or its components.
- Familiarize yourself with the revolver's operation before use.
- Be cautious when shooting in adverse weather conditions.

## Instructions for Installation and Usage

### • Installation:

- There is no assembly required for the 1873 Cattleman El Patron Competition Revolver. It comes fully assembled and ready for use.

### • Usage:

- Before shooting, ensure the revolver is pointed in a safe direction.
- Load the revolver by following these steps:
  1. Open the loading gate on the right side of the revolver.
  2. Insert cartridges into each chamber of the cylinder.
  3. Close the loading gate securely.
- To fire:
  1. Cock the hammer back to the firing position.
  2. Aim at your target while maintaining a safe grip.
  3. Gently squeeze the trigger to fire.
- After shooting, always check that the revolver is unloaded before storing or cleaning.

## Disposal Instructions

- Dispose of the revolver in accordance with local laws and regulations.
- If the revolver is no longer in use, consider surrendering it to a licensed firearms dealer or law enforcement agency.
- Do not dispose of ammunition in regular trash. Follow local guidelines for hazardous waste disposal.

## Contact Information for Further Support

For any questions or concerns regarding the safety or operation of your revolver, please refer to the manufacturer's contact information provided in the product documentation. It is important to have access to support for any safety inquiries.

By following these guidelines and instructions, you can ensure a safe and enjoyable experience with your 1873 Cattleman El Patron Competition Revolver. Always prioritize safety and responsibility when handling firearms.