

SKYLIGHT LED SHELLPLATE LIGHT SYSTM FOR LEE® LOADMASTER PRESS - SKYLIGHT LED SHELLPLATE LIGHT SYSTM FOR LEE LOADMASTER PRESS

The Skylight kit for the LEE Loadmaster features a machined bushing with an embedded high output LED pod that drops into the center hole of the toolhead. Additionally, the system also has a 4" 6 LED strip that attaches to the inside of the press frame. Super bright, high output, out of the way, no heat and does the job perfectly. Average lifespan is 75,000 hours. Few things are more comforting than pure, bright white light, to be able to see everything in motion on your shellplate and verify your powder charge without having to strain your eyes or fight the shadows. These systems are one of the best upgrades you can do to increase your enjoyment and comfort while reloading. The system comes complete with a 110 plug in adapter with 48" long cord, on/off switch, wire routing anchors and zip ties.



Attributes

- Name: SKYLIGHT LED SHELLPLATE LIGHT SYSTM FOR LEE LOADMASTER PRESS
- Manufacturer: INLINE FABRICATION
- Product no.: 430112033
- Mfr. No.: LEDSKYLM
- Delivery weight: 0.227kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das SKYLIGHT LED SHELLPLATE LIGHT SYSTEM](#)
- [English: Safety Instruction Guide for SKYLIGHT LED SHELLPLATE LIGHT SYSTEM FOR LEE LOADMASTER PRESS](#)

Sicherheitshinweise für das SKYLIGHT LED SHELLPLATE LIGHT SYSTEM

Einführung

Willkommen zum SKYLIGHT LED SHELLPLATE LIGHT SYSTEM für die LEE Loadmaster Presse. Dieses Produkt wurde entwickelt, um Ihnen beim Nachladen zu helfen, indem es eine helle und effiziente Beleuchtung bietet. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere und effektive Nutzung des Produkts zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt nur für den vorgesehenen Zweck verwendet wird.
- Überprüfen Sie das Produkt regelmäßig auf sichtbare Schäden oder Abnutzung.
- Verwenden Sie das Produkt nicht, wenn es beschädigt ist oder nicht ordnungsgemäß funktioniert.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Verwenden Sie das Produkt nicht in feuchten oder nassen Umgebungen.
- Achten Sie darauf, dass keine Flüssigkeiten in das Produkt gelangen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur den mitgelieferten 110Adapter für die Stromversorgung.
- Vermeiden Sie es, das Kabel zu überdehnen oder zu knicken.
- Stellen Sie sicher, dass der Ein/AusSchalter leicht zugänglich ist.
- Schalten Sie das Produkt immer aus, wenn es nicht in Gebrauch ist.
- Verwenden Sie das Produkt nicht, wenn Sie müde sind oder sich nicht konzentrieren können.

Anweisungen zur Installation und Nutzung

1. Installation des LEDPods:

- Entfernen Sie den Werkzeugkopf von der LEE Loadmaster Presse.
- Setzen Sie den bearbeiteten LEDPod vorsichtig in das zentrale Loch des Werkzeugkopfes ein.
- Stellen Sie sicher, dass der Pod sicher sitzt.

2. Befestigung des LEDStreifens:

- Nehmen Sie den 4" LEDStreifen und bringen Sie ihn an der Innenseite des PresseRahmens an.
- Verwenden Sie die mitgelieferten Kabelverlegungsanker, um den Streifen sicher zu befestigen.

3. Stromversorgung:

- Schließen Sie den 110Adapter an eine geeignete Steckdose an.
- Verbinden Sie das Kabel mit dem LEDPod und dem LEDStreifen.
- Verwenden Sie den Ein/AusSchalter, um das Licht ein oder auszuschalten.

4. Nutzung:

- Stellen Sie sicher, dass der Arbeitsbereich gut beleuchtet ist.
- Nutzen Sie das helle Licht, um Ihre Shellplate und Pulverladung zu überprüfen.
- Achten Sie darauf, dass Sie nicht in die Lichtquelle schauen, um Augenbelastung zu vermeiden.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Elektro und Elektronikgeräte.
- Stellen Sie sicher, dass alle Batterien und elektrischen Komponenten ordnungsgemäß recycelt werden.
- Fragen Sie bei Ihrer örtlichen Entsorgungsstelle nach, wenn Sie unsicher sind, wie Sie das Produkt entsorgen sollen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu diesem Produkt, einschließlich Sicherheitsanfragen, wenden Sie sich bitte an den Hersteller oder autorisierte Händler.

Bitte beachten Sie, dass Sie unsichere Produkte oder Unfälle den zuständigen Behörden melden sollten. Überprüfen Sie regelmäßig die Rückrufupdates auf der EU Safety Gate Plattform, um sicherzustellen, dass Ihr Produkt sicher ist.

Vielen Dank, dass Sie sich für das SKYLIGHT LED SHELLPLATE LIGHT SYSTEM entschieden haben!

Safety Instruction Guide for SKYLIGHT LED SHELLPLATE LIGHT SYSTEM FOR LEE LOADMASTER PRESS

Introduction

Thank you for choosing the SKYLIGHT LED SHELLPLATE LIGHT SYSTEM for your LEE Loadmaster Press. This guide provides essential safety instructions to ensure safe and effective use of the product. Adhering to these guidelines will help you maximize the benefits of your new lighting system while maintaining safety standards in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand all instructions before using the product.
- Ensure that the product is suitable for your specific reloading press model.
- Use the product only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for damage or wear. Do not use if damaged.
- If you experience any issues with the product, cease use immediately and consult a professional.

Specific Safety Precautions for Use

- Ensure the power supply is compatible with the product specifications.
- Avoid exposure to moisture or water; the product is not waterproof.
- Do not attempt to repair or modify the product; contact a professional for repairs.
- Ensure that the power cord is not pinched or damaged during use.
- Use the on/off switch to control the light, and avoid unplugging by pulling on the cord.
- Do not cover the LED lights during operation to prevent overheating.

Instructions for Installation and Usage

1. Installation:

- Unbox the SKYLIGHT LED SHELLPLATE LIGHT SYSTEM and ensure all components are present.
- Locate the machined bushing and insert it into the center hole of the toolhead.
- Attach the 4" LED strip to the inside of the press frame using the provided wire routing anchors and zip ties.
- Connect the power cord to a compatible 110 plugin outlet.

2. Usage:

- Use the on/off switch to turn the light on or off as needed.
- Adjust the positioning of the LED strip to ensure optimal lighting on the shellplate.
- Regularly check that the light is functioning properly and that there is no obstruction to the LED lights.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding electronic waste.
- Do not dispose of the product with regular household waste.
- Check with local authorities for appropriate recycling or disposal options.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please refer to the manufacturer's contact information provided with your product packaging.

By following these safety instructions, you can ensure a safe and enjoyable experience while using the SKYLIGHT LED SHELLPLATE LIGHT SYSTEM for your LEE Loadmaster Press. Thank you for prioritizing safety in your reloading activities.