

AR-15 ULTRAMATCH - CAL. 223 REM.

The Schmeisser AR15 Ultramatch is a precision rifle with a match barrel and an integrated spare magazine in the stock. This rifle has a .936 free-swinging match barrel, a slim M-Lok handguard and a adjustable gas block made of steel. The Two-Stage trigger guarantees a clearly defined dry trigger. The safety selector, magazine trigger, charging handle and bolt catch are designed for ambidextrous use. Standard delivery with a 10 round magazine.

NO IMAGE
AVAILABLE

- NAME: AR15 Ultramatch 20" BB
- SYSTEM: Semi-automatic rifle
- CALIBER: .223 Rem.
- WEIGHT: 4.000 g
- LENGTH: 97 cm (Fixedstock)
- BARREL: 51 cm
- TWIST: 1:9
- MAGAZINE: 10 rds

Attributes

- Name: SCHMEISER AR-15 ULTRAMATCH - CAL. 223 REM.
- Manufacturer: SCHMEISER
- Product no.: EU2004557
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 20"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Black
- Handguard: Rifle
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-8
- EAN: 4251366502134

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für die Schmeisser AR15 Ultramatch Kal. .223 Rem.
- English: Safety Instruction Guide for Schmeisser AR15 Ultramatch Cal. 223 Rem.

Sicherheitshinweise für die Schmeisser AR15 Ultramatch Kal. .223 Rem.

Einleitung

Herzlichen Glückwunsch zum Kauf der Schmeisser AR15 Ultramatch! Dieses Präzisionsgewehr ist für erfahrene Schützen konzipiert und bietet höchste Genauigkeit und Zuverlässigkeit. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere Handhabung und Nutzung des Produkts zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie alle Sicherheitsanweisungen und gesetzlichen Vorschriften in Ihrem Land befolgen.
- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck.
- Halten Sie das Gewehr immer in einem sicheren Zustand, auch wenn es nicht verwendet wird.
- Bewahren Sie das Gewehr an einem sicheren Ort auf, der für Kinder und unbefugte Personen unzugänglich ist.
- Überprüfen Sie das Gewehr regelmäßig auf Beschädigungen oder Verschleiß.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur die empfohlenen Munitionstypen (.223 Remington) in Ihrer Schmeisser AR15 Ultramatch.
- Stellen Sie sicher, dass das Gewehr vor jedem Schuss leer ist, wenn es nicht verwendet wird.
- Richten Sie den Lauf niemals auf etwas, das Sie nicht treffen möchten.
- Verwenden Sie stets Gehör und Augenschutz, wenn Sie das Gewehr benutzen.
- Halten Sie den Abzug nicht gedrückt, wenn Sie das Gewehr laden oder entladen.
- Achten Sie darauf, dass sich keine Personen im Schussfeld befinden.
- Bei Fehlzündungen oder anderen Problemen befolgen Sie die empfohlenen Verfahren zur sicheren Handhabung.

Anweisungen zur Installation und Nutzung

• Installation der Waffe:

1. Überprüfen Sie, dass das Gewehr entladen ist, bevor Sie mit der Installation beginnen.
2. Befestigen Sie den Vorderschaft gemäß den Anweisungen des Herstellers.
3. Stellen Sie sicher, dass alle Teile fest und sicher montiert sind.

• Nutzung der Waffe:

1. Laden Sie das Gewehr mit dem 10SchussMagazin.
2. Stellen Sie den Gasblock auf die gewünschte Einstellung ein.
3. Richten Sie das Gewehr sicher aus und überprüfen Sie die Umgebung.
4. Betätigen Sie den Abzug, um den Schuss abzugeben.
5. Nach dem Schießen entladen Sie das Gewehr und reinigen Sie es gemäß den Pflegeanweisungen.

Entsorgungsanweisungen

- Entsorgen Sie leere Munition und andere Abfälle gemäß den örtlichen Vorschriften.
- Stellen Sie sicher, dass alle Teile des Gewehrs umweltgerecht entsorgt werden.
- Informieren Sie sich über spezielle Entsorgungsstellen für Waffen und Munition in Ihrer Nähe.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Ihrer Schmeisser AR15 Ultramatch wenden Sie sich bitte an den zuständigen Vertriebspartner oder die offizielle Webseite des Herstellers.

Bitte beachten Sie, dass diese Sicherheitshinweise nicht alle möglichen Gefahren abdecken können. Es liegt in Ihrer Verantwortung, sicherzustellen, dass Sie das Gewehr sicher und verantwortungsvoll nutzen.

Safety Instruction Guide for Schmeisser AR15

Ultramatch Cal. 223 Rem.

Introduction

Thank you for choosing the Schmeisser AR15 Ultramatch. This precision rifle is designed for safe and effective use. Please read this safety instruction guide carefully to ensure proper handling, usage, and maintenance of your firearm. Adhering to these guidelines will help prevent accidents and ensure a safe shooting experience.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store the firearm securely and out of reach of children and unauthorized users.
- Use only the recommended caliber and ammunition for your firearm.
- Regularly inspect the firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and usage.
- Seek immediate assistance if you encounter any malfunction or unsafe condition.

Specific Safety Precautions for Use

- Ensure that you are familiar with the operation of the Schmeisser AR15 Ultramatch before using it.
- Always wear appropriate eye and ear protection when shooting.
- Use the safety selector to prevent accidental discharge when the firearm is not in use.
- Do not attempt to modify or alter the firearm in any way.
- Avoid using the firearm under the influence of alcohol or drugs.
- Only load the magazine when you are ready to shoot.
- Do not place any objects in the barrel or chamber.
- Be cautious when handling a loaded magazine, as it can be mistaken for an empty one.

Instructions for Installation and Usage

Installation

- Ensure the firearm is unloaded before beginning installation.
- Follow the manufacturer's instructions for any accessories or modifications.
- If installing a new component, ensure it is compatible with the Schmeisser AR15 Ultramatch.
- Tighten all screws and fittings securely to prevent any movement during use.

Usage

- To load the firearm:
 - Insert the magazine into the magazine well until it clicks into place.
 - Pull the charging handle to the rear and release it to chamber a round.
- To fire:
 - Aim at the target, ensuring a clear line of sight.
 - Engage the safety selector to the "fire" position.
 - Place your finger on the trigger only when ready to shoot.
 - Squeeze the trigger gently to fire.
- To unload:
 - Remove the magazine from the firearm.
 - Pull the charging handle to the rear to eject any chambered round.
 - Visually and physically inspect the chamber to ensure it is empty.

Disposal Instructions

- Dispose of the firearm and ammunition in accordance with local laws and regulations.
- Do not throw the firearm or ammunition in regular trash.
- Seek guidance from local authorities or licensed dealers for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and usage of your Schmeisser AR15 Ultramatch, please refer to the contact information provided with your product documentation.

By following these safety instructions, you contribute to a safer shooting environment for yourself and others. Remember, responsible firearm ownership is key to ensuring safety and enjoyment in your shooting activities.