

LR-3 2 MILE TARGET CAMERA - LR-3 LONGSHOT CAMERA (2 MILE + UHD) + BULLETPROOF WARRANTY

After a certain distance, even the most capable long-range rounds aren't going to produce much movement on your steel, and that can be a problem for shot spotters who are looking to call good hits for extreme long-range shooters. The LONGSHOT LR-3 2-Mile Target Camera is a must-have in these situations, providing shooters with an easy way to record their hits. Each LONGSHOT LR-3 2-Mile Target Camera is a wireless, portable, battery-powered system that can be set up anywhere, as long as it sits 10-15 feet back from your target. Since the camera is positioned down near the target, dealing with mirage when spotting shots isn't an issue anymore. Plus, the system requires no cell service or Wi-Fi for use, so you can view live HD video anywhere. Each LONGSHOT LR-3 2-Mile Target Camera can run up to 12 hours continuously and features a Blinker Shot Locator and CrispEdge 2688 x 1512 HD image resolution. The system can accommodate up to three additional cameras, with each camera viewable through the company's TargetVision app. The app also allows shooters to track and number shots in addition to saving photos, reviewing sessions and recording videos and stills.



Attributes

- Name: LR-3 LONGSHOT CAMERA (2 MILE + UHD) + BULLETPROOF WARRANTY
- Manufacturer: LONGSHOT TARGET CAMERAS
- Product no.: 100038710
- Mfr. No.: TV-CF103-W
- Color: Gray
- Delivery weight: 4.33kg
- UPC: 656114672994

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die LONGSHOT LR3 2Mile Target Camera](#)
- [English: LR3 2 Mile Target Camera Safety Instructions](#)

Sicherheitshinweise für die LONGSHOT LR3 2Mile Target Camera

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der LONGSHOT LR3 2Mile Target Camera. Diese Kamera ist speziell entwickelt, um Ihnen das Aufzeichnen Ihrer Schüsse über große Entfernungen zu erleichtern. Um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen, beachten Sie bitte die folgenden Sicherheitshinweise und Anweisungen.

Allgemeine Sicherheitsrichtlinien

- Vergewissern Sie sich, dass Sie die Kamera gemäß den Anweisungen verwenden, um Verletzungen oder Schäden zu vermeiden.
- Halten Sie die Kamera von Wasser und extremen Temperaturen fern, um ihre Funktionalität zu gewährleisten.
- Verwenden Sie die Kamera nicht, wenn sie sichtbar beschädigt ist.
- Achten Sie darauf, dass die Kamera außerhalb der Reichweite von Kindern aufbewahrt wird, um Unfälle zu verhindern.
- Überprüfen Sie regelmäßig auf Sicherheitsupdates oder Rückrufinformationen über die EU Safety Gate Plattform.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Stellen Sie sicher, dass die Kamera mindestens 1015 Fuß von Ihrem Ziel entfernt positioniert ist.
- Verwenden Sie die Kamera nicht in der Nähe von stark reflektierenden Oberflächen, um Verzerrungen im Bild zu vermeiden.
- Vermeiden Sie die Nutzung der Kamera bei schlechten Lichtverhältnissen, um die Bildqualität zu verbessern.
- Achten Sie darauf, dass die Kamera sicher und stabil aufgestellt ist, um ein Umfallen zu verhindern.

Anweisungen für Installation und Nutzung

1. Installation

- Wählen Sie einen geeigneten Standort für die Kamera, der mindestens 1015 Fuß von Ihrem Ziel entfernt ist.
- Stellen Sie sicher, dass der Standort stabil und sicher ist.
- Schalten Sie die Kamera ein und überprüfen Sie die Verbindung zur TargetVisionApp.
- Positionieren Sie die Kamera so, dass sie das Ziel klar sehen kann.

2. Nutzung

- Nutzen Sie die TargetVisionApp, um die Kamera zu steuern und die aufgenommenen Videos anzuzeigen.
- Achten Sie darauf, die Kamera während des Betriebs nicht zu bewegen.
- Verwenden Sie die Blinker Shot LocatorFunktion, um Ihre Treffer zu verfolgen.
- Speichern Sie wichtige Aufnahmen und überprüfen Sie die Sitzungen regelmäßig.

Entsorgungsanweisungen

- Entsorgen Sie die LONGSHOT LR3 2Mile Target Camera gemäß den örtlichen Vorschriften für Elektronikschrott.
- Achten Sie darauf, Batterien umweltgerecht zu entsorgen. Geben Sie sie in die dafür vorgesehenen Sammelstellen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung zur LONGSHOT LR3 2Mile Target Camera wenden Sie sich bitte an den zuständigen EUKontakt. Es ist wichtig, dass Sie bei Sicherheitsanfragen oder Problemen eine Anlaufstelle haben.

Bitte beachten Sie diese Sicherheitshinweise, um eine sichere und effektive Nutzung Ihrer LONGSHOT LR3 2Mile Target Camera zu gewährleisten. Vielen Dank für Ihren Kauf!

LR3 2 Mile Target Camera Safety Instructions

Introduction

Thank you for choosing the LR3 2 Mile Target Camera. This guide provides essential safety instructions to ensure the safe and effective use of your camera. Please read this manual carefully before installation and usage.

General Safety Guidelines

- Ensure the camera is used in accordance with the manufacturer's instructions.
- Always keep the camera out of reach of children to prevent accidents.
- Do not use the camera in wet or damp conditions to avoid electrical hazards.
- Regularly inspect the camera for any signs of damage or wear. If damaged, discontinue use and contact a qualified technician.
- Follow all local regulations regarding the use of cameras in shooting areas.

Specific Safety Precautions for Use

- Avoid positioning the camera in direct sunlight for extended periods, as it may overheat.
- Ensure that the camera is securely mounted to prevent it from falling or being knocked over.
- Be aware of your surroundings when using the camera, especially in shooting ranges or outdoor environments.
- Do not attempt to disassemble or modify the camera; doing so may void the warranty and pose safety risks.
- Use the camera only as intended, for recording hits in shooting activities.

Instructions for Installation and Usage

1. Installation:

- Choose a location that is 1015 feet behind the target for optimal performance.
- Ensure the surface is stable and free from obstructions.
- Set up the camera on a tripod or a secure mount to prevent movement.
- Connect the camera to the power source if necessary and ensure it is charged.

2. Usage:

- Turn on the camera using the power button.
- Connect to the TargetVision app on your mobile device to view live video.
- Use the app to track and number your shots, save photos, and review sessions.
- Monitor the battery life and recharge as needed to ensure continuous operation.
- After use, turn off the camera to conserve battery life.

Disposal Instructions

- Dispose of the camera and its components in accordance with local waste disposal regulations.
- Do not dispose of the camera in general household waste.
- Check for any recycling programs available in your area for electronic devices.

Contact Information for Further Support

For additional support or inquiries, please refer to the manufacturer's website or contact their customer service.

By following these safety instructions, you will ensure a safe and enjoyable experience with your LR3 2 Mile Target Camera. Thank you for your attention to safety.