

AR-15 EXTRACTOR SPRING O-RING - BRN AR-15 BOLT EXTRACTOR SPRING O-RING, BLACK

OEM AR-15/M16 replacement Extractor O-Ring.



Attributes

- Name: BRN AR-15 BOLT EXTRACTOR SPRING O-RING, BLACK
- Manufacturer: BROWNELLS
- Product no.: 100040955
- Mfr. No.: AZ-0005
- Make: AR-15
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 050806029606

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: AR15 Extractor Spring ORing Safety Instructions](#)
- [Français: Instructions de sécurité pour l'ORing d'extracteur AR15](#)

AR15 Extractor Spring ORing Safety Instructions

Introduction

Thank you for choosing the AR15 Extractor Spring ORing by Brownells. This product is designed to enhance the performance and reliability of your AR15/M16 firearm. Please read this safety instruction guide carefully to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is compatible with your specific firearm model before installation.
- Always handle firearms with care and follow standard safety practices.
- Keep the product out of reach of children and unauthorized users.
- Inspect the product regularly for signs of wear or damage. Do not use if damaged.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Only use the AR15 Extractor Spring ORing for its intended purpose.
- Avoid using any tools or equipment that may cause damage to the Oring during installation or removal.
- Do not modify the Oring or use it in a manner not specified by the manufacturer.
- Ensure that the firearm is unloaded before performing any maintenance or installation work.
- Wear appropriate safety gear, such as eye protection, when handling firearms.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is completely unloaded and safe to handle.
- Gather necessary tools, such as a punch tool or small screwdriver, for installation.

2. Installation Steps

- Remove the bolt from the firearm according to the manufacturer's instructions.
- Locate the extractor on the bolt assembly.
- Carefully remove the old Oring if present. Use a tool if necessary to avoid damaging the extractor.
- Place the new AR15 Extractor Spring ORing onto the extractor, ensuring it fits snugly.
- Reassemble the bolt and reinstall it into the firearm following the manufacturer's guidelines.

3. PostInstallation Check

- After installation, perform a function check to ensure the extractor operates correctly.
- Inspect the Oring for proper seating and alignment.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste if it is considered hazardous.
- If the product is damaged or no longer usable, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the AR15 Extractor Spring ORing, please refer to the manufacturer's website or customer support channels for assistance.

Thank you for your attention to these safety instructions. Your commitment to safety ensures a better experience with your AR15 firearm.

Instructions de sécurité pour l'ORing d'extracteur AR15

Introduction

Merci d'avoir choisi l'ORing d'extracteur de remplacement OEM pour AR15/M16. Ce produit est conçu pour améliorer la performance de votre arme. Il est essentiel de suivre ces instructions de sécurité pour garantir une utilisation sécurisée et efficace.

Directives générales de sécurité

- Assuretoi que le produit est utilisé uniquement pour l'usage prévu.
- Vérifie régulièrement l'état de l'ORing avant chaque utilisation.
- Ne jamais utiliser un produit endommagé ou usé.
- Garde le produit hors de portée des enfants.
- Informetoi sur les lois et réglementations locales concernant l'utilisation des armes à feu.

Précautions de sécurité spécifiques à l'utilisation

- Ne pas forcer l'installation de l'ORing. Si tu rencontres des difficultés, consulte un professionnel.
- Porte toujours des lunettes de sécurité lors de l'installation pour protéger tes yeux.
- Assuretoi que l'arme est déchargée avant de procéder à l'installation de l'ORing.
- Ne pas manipuler l'arme ou le produit dans un environnement où il y a des personnes non autorisées.

Instructions pour l'installation et l'utilisation

1. Préparation :

- Assuretoi que l'arme est déchargée et sécurisée.
- Rassemble les outils nécessaires : un tournevis et un chiffon propre.

2. Installation :

- Retire l'ancien ORing de l'extracteur en utilisant le tournevis.
- Nettoie la zone autour de l'extracteur pour éviter toute contamination.
- Installe le nouvel ORing en le plaçant correctement dans la rainure.
- Vérifie que l'ORing est bien en place avant de remonter l'extracteur.

3. Utilisation :

- Teste le fonctionnement de l'extracteur après l'installation.
- Observe le comportement de l'arme lors des premiers tirs pour détecter tout problème potentiel.

Instructions de mise au rebut

- Ne jette pas le produit dans les ordures ménagères. Vérifie les réglementations locales concernant l'élimination des produits en plastique.
- Si l'ORing est endommagé, assuretoi de le recycler si possible, ou de le disposer de manière sécurisée.

Informations de contact pour un soutien supplémentaire

Pour toute question ou préoccupation concernant la sécurité de ce produit, consulte les ressources disponibles en ligne ou contacte un professionnel qualifié.

Conclusion

En suivant ces instructions, tu peux garantir une utilisation sûre et efficace de l'ORing d'extracteur pour AR15/M16. Reste informé et vigilant pour assurer ta sécurité et celle des autres.