

AR-15 EXTRACTOR PIN - BRN AR-15 BOLT EXTACTOR PIN, BLACK

OEM AR-15/M16 replacement Extractor Pin.



Attributes

- Name: BRN AR-15 BOLT EXTRACTOR PIN, BLACK
- Manufacturer: BROWNELLS
- Product no.: 100040958
- Mfr. No.: AZT-M4-556ST016
- Make: AR-15
- Delivery weight: 0.005kg
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 050806029637

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for AR15 Extractor Pin](#)
- [Français: Instructions de Sécurité pour le Goupille d'Extracteur AR15](#)

Safety Instruction Guide for AR15 Extractor Pin

Introduction

Thank you for choosing the AR15 Extractor Pin by Brownells. This guide provides important safety information and instructions for the proper use and handling of the Extractor Pin. It is essential to read and understand this guide to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in this guide.
- Always handle firearms and related components with care and in accordance with established safety practices.
- Keep the product out of reach of children and unauthorized users.
- Regularly check for any signs of wear or damage to the Extractor Pin before use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before installing or replacing the Extractor Pin.
- Wear appropriate safety gear, including eye protection, when handling firearms and components.
- Use only compatible parts and tools as specified by the manufacturer to avoid malfunctions.
- Do not attempt to modify the Extractor Pin or any other firearm components.
- If you are unsure about the installation or use of the Extractor Pin, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a punch tool and hammer.

2. Installation:

- Remove the existing Extractor Pin if applicable:
 - Use the punch tool to gently tap out the old Extractor Pin.
 - Ensure that the area is clear of debris.
- Insert the new AR15 Extractor Pin:
 - Align the Extractor Pin with the hole in the bolt.
 - Use the punch tool to carefully tap the new Extractor Pin into place until it is secure.
- Doublecheck that the Extractor Pin is properly seated and secure.

3. Usage:

- After installation, conduct a function check of the firearm to ensure proper operation.
- Regularly inspect the Extractor Pin and surrounding components for signs of wear or damage during routine maintenance.

Disposal Instructions

- Dispose of any old or damaged Extractor Pins in accordance with local regulations.
- Ensure that any disposed parts do not pose a risk to the environment or public safety.

Contact Information for Further Support

For any questions or concerns regarding the AR15 Extractor Pin, please contact the manufacturer or a qualified firearms expert. Always ensure that you have the most current information regarding safety and compliance.

Thank you for your attention to these safety guidelines. Your safety and the safety of others depend on responsible handling and use of this product.

Instructions de Sécurité pour le Goupille d'Extracteur AR15

Introduction

Merci d'avoir choisi le goupille d'extracteur de remplacement OEM pour AR15/M16 de BROWNELLS. Ce guide a pour but de t'assurer que tu utilises ce produit en toute sécurité et conformément aux réglementations de sécurité des produits de l'UE.

Directives de Sécurité Générales

- Assure-toi que le produit est utilisé uniquement pour son but prévu.
- Vérifie régulièrement l'état de la goupille d'extracteur pour détecter tout signe d'usure ou de dommage.
- Range le produit hors de portée des enfants et des personnes vulnérables.
- Informe-toi sur les rappels de produits via la plateforme Safety Gate de l'UE.

Précautions de Sécurité Spécifiques à l'Utilisation

- Ne pas utiliser le goupille d'extracteur si tu remarques des fissures ou des déformations.
- Porte des lunettes de protection lors de l'installation pour éviter les blessures oculaires.
- Assure-toi que l'arme est déchargée avant de procéder à l'installation de la goupille d'extracteur.
- Ne pas tenter de modifier le produit de quelque manière que ce soit.

Instructions pour l'Installation et l'Utilisation

Installation

1. Préparation:

- Vérifie que l'arme est déchargée.
- Rassemble les outils nécessaires (tournevis, pinces, etc.).

2. Retrait de l'Ancien Extracteur:

- Retire l'ancienne goupille d'extracteur en utilisant les outils appropriés.

3. Installation de la Nouvelle Goupille:

- Insère la nouvelle goupille d'extracteur dans l'emplacement prévu.
- Assure-toi qu'elle est bien en place et sécurisée.

Utilisation

- Utilise ton arme conformément aux instructions du fabricant.
- Effectue une vérification régulière de la goupille d'extracteur pour assurer son bon fonctionnement.

Instructions de Mise au Rebut

- Ne jette pas le produit avec les déchets ménagers.
- Suis les réglementations locales concernant le recyclage des pièces d'armement.
- Si le produit est endommagé ou usé, contacte un professionnel pour le mettre au rebut de manière sécurisée.

Informations de Contact pour un Support Supplémentaire

Pour toute question ou préoccupation concernant la sécurité de ce produit, consulte un professionnel ou un représentant de la marque. Assure-toi de vérifier les mises à jour de sécurité sur la plateforme Safety Gate de l'UE.

En suivant ces instructions, tu peux garantir une utilisation sécurisée et efficace de ton goupille d'extracteur AR15. Merci de ta vigilance et de ta responsabilité en matière de sécurité des produits.