

700 LONG RANGE 26" BBL 300 WINCHESTER MAGNUM

UNBEATABLE CONSISTENCY. UNMATCHED LONG-RANGE PRECISION. Engineered to make three shots look like one. From extended-range big-game hunting to printing one-ragged-hole groups from the bench, no rifle delivers like the Model 700™ Long Range. And we're continually finding new ways to maximize our legendary action's inherent precision. The Model 700™ Long Range combines the added stability of a 26"" heavy-contour barrel with hard-hitting, long-action chamberings to stretch your lethal range. HS Precision Stock Black with Gray Webbing Aluminum bedding block for added accuracy and an extra swivel for bi-pod 26"" heavy contour barrel with matte finish, perfectly matched to its high-velocity caliber offerings Concave target-style barrel crown X-Mark Pro® externally adjustable trigger Drilled and tapped for scope mounts Magazine capacity – four in standard calibers, three in magnum



Attributes

- Name: REMINGTON 700 LONG RANGE 26" BBL 300 WINCHESTER MAGNUM
- Manufacturer: REMINGTON
- Product no.: 100050011
- Mfr. No.: R84164
- Action Type: Bolt Action
- Barrel Length: 26"
- Capacity: 3-Round
- Cartridge: 300 Winchester Magnum
- Finish: Black, Grey
- Front Sight: None
- Length: 47"
- Magazine Included: Hinged Floorplate
- Magazine Type: NA
- Make: Remington
- Model: 700
- Muzzle: Plain
- Rear Sight: None
- Stock Material: Bell & Carlson M40 Tactical
- Weight: 9 lbs
- UPC: 810070681043

Item details

Made in USA

US export classification: 0A501.a

Table of Contents

- Startpage
- Deutsch: Sicherheitsanleitung für das REMINGTON 700 LONG RANGE
- English: REMINGTON 700 LONG RANGE Safety Instruction Guide

Sicherheitsanleitung für das REMINGTON 700 LONG RANGE

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des REMINGTON 700 LONG RANGE Gewehrs. Dieses Produkt wurde entwickelt, um Ihnen außergewöhnliche Präzision und Konsistenz auf langen Distanzen zu bieten. Um sicherzustellen, dass Sie Ihr Gewehr sicher und effektiv nutzen können, beachten Sie bitte die folgenden Sicherheitsrichtlinien und Anweisungen.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Gewehr immer in einem sicheren Zustand ist, wenn Sie es nicht verwenden.
- Halten Sie das Gewehr von Kindern und unbefugten Personen fern.
- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck – das Schießen auf Zielscheiben oder Wildtiere.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille, während des Schießens.
- Überprüfen Sie vor jedem Gebrauch, ob das Gewehr in einwandfreiem Zustand ist und keine sichtbaren Schäden aufweist.
- Achten Sie beim Laden und Entladen des Gewehrs stets auf die Richtung des Laufes und vermeiden Sie, auf Personen oder Tiere zu zielen.
- Halten Sie sich an alle örtlichen Gesetze und Vorschriften bezüglich des Besitzes und Gebrauchs von Feuerwaffen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Überprüfen Sie vor dem Schießen immer, ob die Munition für das Kaliber Ihres Gewehrs geeignet ist (300 Winchester Magnum).
- Laden Sie das Gewehr nur, wenn Sie bereit sind, zu schießen.
- Entladen Sie das Gewehr sofort nach dem Schießen und bevor Sie es transportieren oder lagern.
- Verwenden Sie nur zugelassene Magazine und Zubehörteile, die für das Modell 700™ Long Range geeignet sind.
- Achten Sie darauf, dass sich keine Hindernisse oder Personen hinter der Zielscheibe befinden, bevor Sie schießen.
- Verwenden Sie das Gewehr nicht unter dem Einfluss von Alkohol oder Drogen.

Anweisungen für Installation und Nutzung

• Installation des Zielfernrohrs:

- Stellen Sie sicher, dass das Gewehr entladen ist.
- Montieren Sie das Zielfernrohr an den vorgesehenen Montagepunkten auf dem Gewehr.
- Befestigen Sie das Zielfernrohr gemäß den Anweisungen des Herstellers sicher.

• Laden des Gewehrs:

- Ziehen Sie den Verschluss zurück, um das Gewehr zu entladen.
- Fügen Sie die Munition in das Magazin ein und stellen Sie sicher, dass es korrekt sitzt.
- Schieben Sie den Verschluss nach vorne, um das Gewehr zu laden.

• Schießen:

- Nehmen Sie eine stabile Schießposition ein.
- Zielen Sie auf das Ziel und drücken Sie den Abzug sanft.
- Nach dem Schuss, überprüfen Sie das Gewehr, um sicherzustellen, dass es sicher ist.

Entsorgungsanweisungen

- Entsorgen Sie leere Munition und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Lagern Sie das Gewehr in einem sicheren, trockenen Ort, wenn es nicht in Gebrauch ist.
- Wenn das Gewehr nicht mehr funktionsfähig ist, bringen Sie es zu einem autorisierten Händler oder einer Werkstatt zur fachgerechten Entsorgung.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung bezüglich der Sicherheit oder Nutzung Ihres REMINGTON 700 LONG RANGE Gewehrs, wenden Sie sich bitte an die zuständige Stelle oder den Hersteller. Es ist wichtig, dass Sie bei Bedenken oder Problemen nicht zögern, Hilfe in Anspruch zu nehmen.

Bitte beachten Sie, dass die Sicherheit immer an erster Stelle steht. Halten Sie sich an diese Richtlinien, um ein sicheres und verantwortungsvolles Schießerlebnis zu gewährleisten.

REMINGTON 700 LONG RANGE Safety Instruction Guide

Introduction

Thank you for choosing the REMINGTON 700 LONG RANGE rifle. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your firearm. It is important to read and understand these instructions before using the product.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Ensure that your firearm is stored securely and out of reach of children and unauthorized users.
- Use only the recommended ammunition for your firearm.
- Regularly inspect your firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.
- Be aware of your surroundings and ensure that your shooting area is safe and free from obstructions.

Specific Safety Precautions for Use

- Wear appropriate eye and ear protection while using the rifle.
- Do not consume alcohol or drugs before or during shooting.
- Always check the chamber to ensure it is clear before handling the firearm.
- Avoid using the rifle in wet or damp conditions to prevent malfunction.
- Keep your fingers off the trigger until you are ready to shoot.
- Be mindful of your target and what lies beyond it.

Instructions for Installation and Usage

Installation

- Ensure the rifle is unloaded before installation.
- Follow the manufacturer's instructions for mounting any accessories, such as scopes or bipods.
- Ensure that all screws and attachments are tightened securely before use.

Usage

- To load the rifle, open the bolt and insert the magazine.
- Close the bolt and ensure that the bolt is fully locked.
- To fire, aim at your target, ensure the area is safe, and squeeze the trigger gently.
- After firing, always check the chamber and magazine to ensure they are clear before handling the rifle.

Disposal Instructions

- Dispose of any unused ammunition according to local regulations.
- When disposing of the firearm, contact a licensed firearms dealer or local law enforcement for proper disposal methods.
- Ensure that the firearm is rendered inoperable before disposal.

Contact Information for Further Support

For any questions or concerns regarding the REMINGTON 700 LONG RANGE rifle, please refer to the manufacturer's website or contact your local authorized dealer for assistance.

Conclusion

Safety is paramount when handling firearms. By following the guidelines outlined in this instruction guide, you can ensure a safe and enjoyable shooting experience with your REMINGTON 700 LONG RANGE rifle. Always stay informed about safety practices and updates regarding your product.