

700 LONG RANGE 26" BBL 7MM REMINGTON MAGNUM

UNBEATABLE CONSISTENCY. UNMATCHED LONG-RANGE PRECISION. Engineered to make three shots look like one. From extended-range big-game hunting to printing one-ragged-hole groups from the bench, no rifle delivers like the Model 700™ Long Range. And we're continually finding new ways to maximize our legendary action's inherent precision. The Model 700™ Long Range combines the added stability of a 26" heavy-contour barrel with hard-hitting, long-action chamberings to stretch your lethal range. HS Precision Stock Black with Gray Webbing Aluminum bedding block for added accuracy and an extra swivel for bi-pod 26" heavy contour barrel with matte finish, perfectly matched to its high-velocity caliber offerings Concave target-style barrel crown X-Mark Pro® externally adjustable trigger Drilled and tapped for scope mounts Magazine capacity – four in standard calibers, three in magnum



Attributes

- Name: REMINGTON 700 LONG RANGE 26" BBL 7MM REMINGTON MAGNUM
- Manufacturer: REMINGTON
- Product no.: 100050012
- Mfr. No.: R84163
- Action Type: Bolt Action
- Barrel Length: 26"
- Capacity: 3-Round
- Cartridge: 7 mm Remington Magnum
- Finish: Black,Grey
- Front Sight: None
- Length: 47"
- Magazine Included: Hinged Floorplate
- Magazine Type: NA
- Make: Remington
- Model: 700
- Muzzle: Plain
- Rear Sight: None
- Stock Material: Bell & Carlson M40 Tactical
- Weight: 9 lbs
- UPC: 810070681036

Item details

Made in USA

US export classification: 0A501.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das REMINGTON 700 LONG RANGE](#)
- [English: REMINGTON 700 LONG RANGE Safety Instruction Guide](#)

Sicherheitshinweise für das REMINGTON 700 LONG RANGE

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des REMINGTON 700 LONG RANGE. Dieses Gewehr ist für Präzision und Leistung auf langen Distanzen konzipiert. Um sicherzustellen, dass Sie und andere sicher mit diesem Produkt umgehen, lesen Sie bitte die folgenden Sicherheitshinweise sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck.
- Lagern Sie das Gewehr in einem sicheren, trockenen Ort, der für Kinder unzugänglich ist.
- Halten Sie den Abzug immer von der Hand, bis Sie bereit sind zu schießen.
- Überprüfen Sie vor jedem Gebrauch, ob das Gewehr entladen ist.
- Tragen Sie beim Schießen immer geeignete Augen und Gehörschutzmittel.
- Informieren Sie sich über die Gesetze und Vorschriften in Ihrem Land oder Bundesland bezüglich des Waffenbesitzes und gebrauchs.

Besondere Sicherheitsvorkehrungen bei der Benutzung

- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Überprüfen Sie das Gewehr regelmäßig auf Beschädigungen oder Abnutzung.
- Achten Sie darauf, dass der Lauf frei von Hindernissen ist, bevor Sie abdrücken.
- Schießen Sie niemals in die Nähe von Menschen oder Tieren.
- Halten Sie immer einen sicheren Abstand zu anderen Personen, wenn Sie das Gewehr benutzen.
- Bei Anzeichen von Fehlfunktionen oder anderen Problemen, stellen Sie die Benutzung sofort ein und lassen Sie das Gewehr von einem Fachmann überprüfen.

Anweisungen zur Installation und Nutzung

- **Installation:**
 - Montieren Sie das Zielfernrohr gemäß den Anweisungen des Herstellers.
 - Stellen Sie sicher, dass alle Teile fest und sicher montiert sind.
- **Nutzung:**
 - Überprüfen Sie vor jeder Benutzung, ob das Gewehr entladen ist.
 - Laden Sie das Gewehr nur in einem sicheren Bereich.
 - Stellen Sie sicher, dass Sie eine geeignete Schießposition einnehmen.
 - Ziehen Sie den Abzug sanft, um einen präzisen Schuss zu gewährleisten.
 - Nach dem Schießen, entladen Sie das Gewehr und reinigen Sie es gemäß den Anweisungen des Herstellers.

Entsorgungsanweisungen

- Entsorgen Sie leere oder beschädigte Munition gemäß den örtlichen Vorschriften.
- Entsorgen Sie das Gewehr nicht im normalen Müll. Wenden Sie sich an ein autorisiertes Entsorgungsunternehmen für Waffen.
- Informieren Sie sich über die speziellen Anforderungen zur Entsorgung von Waffen in Ihrem Land oder Ihrer Region.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Bedenken zu Ihrem REMINGTON 700 LONG RANGE Gewehr, wenden Sie sich bitte an den Hersteller oder einen autorisierten Fachhändler. Achten Sie darauf, alle Sicherheitsrichtlinien zu befolgen und sicherzustellen, dass Sie die besten Praktiken für den Umgang mit Feuerwaffen einhalten.

Bitte beachten Sie, dass diese Sicherheitshinweise nicht alle möglichen Sicherheitsfragen abdecken können. Es liegt in Ihrer Verantwortung, sich über sichere Praktiken im Umgang mit Gewehren zu informieren und diese zu befolgen.

REMINGTON 700 LONG RANGE Safety Instruction Guide

Introduction

Thank you for choosing the REMINGTON 700 LONG RANGE. This guide provides important safety information to ensure your safe and enjoyable use of the rifle. Please read this guide carefully before using the product.

General Safety Guidelines

- Always treat the rifle as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Use appropriate ammunition as specified for the REMINGTON 700 LONG RANGE.
- Wear eye and ear protection when shooting.
- Be aware of your surroundings and ensure you have a clear shooting area.
- Follow all local laws and regulations regarding firearm ownership and use.
- Ensure that the firearm is not modified in any way that may affect its safety or performance.

Specific Safety Precautions for Use

- **Loading and Unloading:**
 - Always ensure the rifle is pointed in a safe direction when loading or unloading.
 - Open the bolt and visually check the chamber to confirm it is empty before loading.
 - Only load one round at a time until you are ready to fire.
- **Shooting:**
 - Use a stable shooting position and proper grip.
 - Avoid shooting at hard surfaces or water where ricochets may occur.
 - Be mindful of the wind direction and ensure it does not carry bullets towards people or property.
- **Maintenance:**
 - Regularly inspect the rifle for any signs of wear or damage.
 - Clean the rifle according to the manufacturer's instructions to ensure proper function.
 - Never attempt to repair or modify the rifle unless you are a qualified gunsmith.
- **Transporting:**
 - Always transport the rifle in a case or secure manner.
 - Ensure the rifle is unloaded during transport.
 - Keep the rifle out of sight when not in use.

Instructions for Installation and Usage

- **Installation of Accessories:**

- Follow the manufacturer's instructions for installing any accessories.
- Ensure that all accessories are securely attached before use.

- **Using the Trigger:**

- Familiarize yourself with the XMark Pro® externally adjustable trigger.
- Adjust the trigger according to your preference, ensuring it functions correctly before using the rifle.

- **Scope Mounting:**

- The rifle is drilled and tapped for scope mounts. Follow the scope manufacturer's instructions for proper installation.
- Ensure that the scope is securely attached and properly aligned before use.

- **Sighting In:**

- Before using the rifle for hunting or target shooting, sight in the rifle to ensure accuracy.
- Use a safe and controlled environment for sighting in the rifle.

Disposal Instructions

- Dispose of the rifle responsibly and in accordance with local laws and regulations.
- If the rifle is no longer usable, contact a licensed firearms dealer for proper disposal options.
- Ensure that the rifle is rendered inoperable before disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding the REMINGTON 700 LONG RANGE, please contact the appropriate authorities or a licensed firearms dealer. It is essential to stay informed about safety recalls and updates related to your firearm.

Conclusion

Your safety and the safety of others is paramount when using the REMINGTON 700 LONG RANGE. By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience. Always prioritize responsible firearm ownership and usage.