

AFFINITY 3 SEMI-AUTO 12 GAUGE SHOTGUN - AFFINITY 3 12 GAUGE 28" BBL 4+1 ROUND BLACK

The Affinity 3 semi-automatic shotgun is the ideal coming together of Italian craftsmanship and American passion. Even as you first shoulder it you'll be surprised by its lean dimensions, functional design and ideal weight and balance. The trim forend helps keep your eye close to the bore axis, meaning quicker and more intuitive pointing. The custom-grade controls—bolt handle, bolt release and magazine port—are oversized for positive use, even with gloved hands. The Inertia Driven® system along with the TSA recoil pad makes the Affinity 3 easy on the shoulder in the field or on the clays range.



Attributes

- Name: AFFINITY 3 12 GAUGE 28" BBL 4+1 ROUND BLACK
- Manufacturer: FRANCHI
- Product no.: 430101585
- Mfr. No.: 41025
- Action Type: Semi-Auto
- Barrel Length: 28"
- Capacity: 4+1-Round
- Finish: Black
- Front Sight: Fiber Optic
- Gauge: 12 Gauge
- Length: 49.25"
- Magazine Included: None
- Magazine Type: Fixed
- Make: Franchi
- Model: Affinity 3
- Muzzle: Choke Tubes
- Rear Sight: None
- Stock Material: Polymer
- Weight: 6.9 lbs
- Shipping height: 76mm
- Shipping width: 330mm
- Shipping length: 991mm
- UPC: 650350410259

Item details

US export classification: 0A502

Table of Contents

- Startpage
- Deutsch: Sicherheitshinweise für die AFFINITY 3 SEMIAUTO 12 GAUGE SHOTGUN
- English: Safety Instruction Guide for AFFINITY 3 SEMIAUTO 12 GAUGE SHOTGUN

Sicherheitshinweise für die AFFINITY 3 SEMIAUTO 12 GAUGE SHOTGUN

Einführung

Herzlichen Glückwunsch zu Ihrer neuen Franchi Affinity 3 halbautomatischen Flinte. Diese Anleitung bietet wichtige Informationen zur sicheren Verwendung und Handhabung Ihres Produkts. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um ein sicheres und angenehmes Erlebnis zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- **Produkt Sicherheit:** Stellen Sie sicher, dass Sie alle Sicherheitsrichtlinien beachten, um Verletzungen oder Schäden zu vermeiden.
- **Besondere Verbraucherfokus:** Seien Sie besonders vorsichtig, wenn Kinder in der Nähe sind. Halten Sie die Flinte außerhalb ihrer Reichweite.
- **Online Einkauf:** Achten Sie darauf, dass Sie Ihre Flinte nur von autorisierten Händlern kaufen, die die Sicherheitsanforderungen erfüllen.
- **Schnelle Warnungen:** Informieren Sie sich regelmäßig über Rückrufaktionen oder Sicherheitswarnungen über die EU Safety Gate Plattform.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- **Waffenhandhabung:**
 - Behandeln Sie jede Waffe, als ob sie geladen wäre.
 - Richten Sie die Flinte niemals auf etwas, das Sie nicht treffen möchten.
- **Sichere Lagerung:**
 - Lagern Sie die Flinte in einem sicheren, verschlossenen Ort, der für Kinder unzugänglich ist.
 - Verwenden Sie ein Waffenschloss oder eine sichere Waffe zur Aufbewahrung.
- **Schutzkleidung:**
 - Tragen Sie geeignete Schutzkleidung, wie Gehörschutz und Schutzbrille, während des Schießens.
- **Schießen auf dem Stand:**
 - Schießen Sie nur auf offiziellen Schießständen und befolgen Sie die dortigen Regeln und Vorschriften.

Anweisungen für Installation und Nutzung

- **Vorbereitung:**
 - Überprüfen Sie vor jeder Verwendung, ob die Flinte sauber und in gutem Zustand ist.
 - Stellen Sie sicher, dass der Verschluss ordnungsgemäß funktioniert und die Flinte korrekt geladen ist.
- **Laden der Flinte:**
 - Öffnen Sie den Verschluss und legen Sie die Patronen in das Magazin.
 - Schließen Sie den Verschluss sicher, bevor Sie die Flinte verwenden.
- **Zielen und Schießen:**
 - Halten Sie die Flinte stabil und zielen Sie sorgfältig, bevor Sie abdrücken.
 - Achten Sie darauf, dass sich niemand im Schussfeld befindet.
- **Nach dem Schießen:**
 - Entladen Sie die Flinte, sobald Sie mit dem Schießen fertig sind.
 - Reinigen Sie die Flinte regelmäßig, um ihre Funktionsfähigkeit zu gewährleisten.

Entsorgungsanweisungen

- **Entsorgung von Munition:**
 - Entsorgen Sie leere oder nicht verwendete Patronen gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- **Entsorgung der Flinte:**
 - Wenn Sie die Flinte nicht mehr benötigen, geben Sie sie an einen autorisierten Händler oder eine Waffenbehörde ab.
- **Umweltbewusstsein:**
 - Achten Sie darauf, die Umwelt nicht zu schädigen, indem Sie Abfälle ordnungsgemäß entsorgen.

Kontaktinformationen für weitere Unterstützung

Für Sicherheitsanfragen oder weitere Informationen wenden Sie sich bitte an den zuständigen Ansprechpartner in der EU.

Bleiben Sie sicher und genießen Sie die Nutzung Ihrer Franchi Affinity 3 halbautomatischen Flinte!

Safety Instruction Guide for AFFINITY 3 SEMIAUTO 12 GAUGE SHOTGUN

Introduction

Thank you for choosing the AFFINITY 3 SEMIAUTO 12 GAUGE SHOTGUN. This guide provides essential safety instructions and guidelines for the safe use and handling of your shotgun. It is crucial to read and understand these instructions to ensure your safety and the safety of others.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Never place your finger on the trigger until you are ready to shoot.
- Ensure the shotgun is unloaded when not in use or when being cleaned.
- Store the shotgun in a secure place, out of reach of children and unauthorized users.
- Use only the correct ammunition specified for this shotgun.
- Be aware of your surroundings and ensure a safe shooting environment.
- Follow all local laws and regulations regarding firearms.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection while shooting.
- Check the shotgun before each use for any signs of damage or wear.
- Ensure the safety mechanism is engaged until you are ready to fire.
- Avoid using the shotgun in wet or damp conditions, as this may affect its performance.
- Be cautious of the shotgun's recoil, especially when using heavier loads.
- Do not attempt to modify or alter the shotgun in any way.
- If you experience a misfire or hangfire, keep the shotgun pointed in a safe direction and wait at least 30 seconds before attempting to open the action.
- Be mindful of the shotgun's capacity and do not exceed the recommended rounds.

Instructions for Installation and Usage

• Installation:

- Ensure the shotgun is completely unloaded before installation.
- Attach the stock securely to the receiver, ensuring it is aligned correctly.
- Install the choke tubes as per the manufacturer's instructions, ensuring they are tightened securely.

• Usage:

- To load the shotgun, open the action and insert rounds into the magazine.
- Close the action to chamber a round.
- To fire, disengage the safety and pull the trigger.
- After firing, allow the action to cycle and prepare for the next shot.
- To unload, open the action and remove any remaining rounds from the magazine and chamber.

Disposal Instructions

- Dispose of the shotgun responsibly and in accordance with local laws and regulations.
- For any unused or expired ammunition, follow local hazardous waste disposal guidelines.
- Do not discard the shotgun in regular trash.

Contact Information for Further Support

For any safety inquiries or concerns regarding the AFFINITY 3 SEMIAUTO 12 GAUGE SHOTGUN, please refer to the manufacturer's website or contact your local dealer for assistance.

By following these safety guidelines and instructions, you will ensure a safe and enjoyable experience with your AFFINITY 3 SEMIAUTO 12 GAUGE SHOTGUN. Thank you for prioritizing safety.