

TOP BREAK NO. 3 45 COLT REVOLVER - 1875 NO. 3 TOP BREAK 45 COLT 7" BBL NICKEL-PLATED

True to the originals, Uberti Top Break Revolvers come in 3 models, including the Russian Model with Cyrillic barrel stampings. Major George Schofield designed the Top Break as a cavalry pistol. Its efficient, break-open design could be operated with one hand. That made it easy to eject the spent cartridges and reload while on horseback. It was the Russian government that truly embraced the new side arm. The Czar ordered 41,000 Top Breaks. Those had a modified grip design, lanyard ring, and a distinctive trigger spur.



Attributes

- Name: 1875 NO. 3 TOP BREAK 45 COLT 7" BBL NICKEL-PLATED
- Manufacturer: UBERTI
- Product no.: 430101620
- Mfr. No.: 348572
- Action Type: Single Action
- Barrel Length: 7"
- Capacity: 6-Round
- Cartridge: 45 (Long) Colt
- Finish: Polished
- Front Sight: Blade
- Length: NA
- Magazine Included: NA
- Magazine Type: Fixed
- Make: Uberti
- Model: 1875
- Muzzle: Non-Threaded
- Rear Sight: None
- Stock Material: Walnut
- Weight: NA
- Shipping height: 51mm
- Shipping width: 152mm
- Shipping length: 305mm
- UPC: 037084485720

Item details

US export classification: 0A501.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den TOP BREAK NO. 3 45 COLT REVOLVER UBERTI 1875](#)
- [English: Safety Instruction Guide for TOP BREAK NO. 3 45 COLT REVOLVER 1875](#)

Sicherheitshinweise für den TOP BREAK NO. 3 45 COLT REVOLVER UBERTI 1875

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des TOP BREAK NO. 3 45 COLT REVOLVER UBERTI 1875. Dieser Revolver ist ein historisches Stück, das sorgfältig entworfen wurde, um sowohl Sicherheit als auch Leistung zu gewährleisten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie den Revolver sicher und verantwortungsbewusst verwenden.

Allgemeine Sicherheitsrichtlinien

- Verwende den Revolver niemals, wenn du unter dem Einfluss von Alkohol oder Drogen stehst.
- Halte den Revolver immer in einem sicheren Zustand, bis du bereit bist zu schießen.
- Achte darauf, dass der Lauf des Revolvers nicht in Richtung von Personen oder Tieren zeigt.
- Verwende nur die vom Hersteller empfohlenen Munitionstypen.
- Bewahre den Revolver an einem sicheren Ort auf, außerhalb der Reichweite von Kindern.
- Überprüfe den Revolver regelmäßig auf Anzeichen von Verschleiß oder Beschädigung.

Besondere Sicherheitsvorkehrungen für die Verwendung

- Trage beim Schießen immer Schutzbrille und Ohrenschutz.
- Stelle sicher, dass der Schießbereich frei von Personen und Hindernissen ist.
- Lade den Revolver nur in einem sicheren, dafür vorgesehenen Bereich.
- Wenn du den Revolver nicht mehr verwenden möchtest, entlade ihn sofort und bewahre ihn sicher auf.
- Bei Problemen mit dem Revolver, wie z.B. einer Fehlzündung, lasse ihn für mindestens 30 Sekunden in der sicheren Position, bevor du versuchst, das Problem zu beheben.

Anweisungen für Installation und Nutzung

- **Installation:**
 - Der Revolver benötigt keine spezielle Installation. Stelle sicher, dass er in einem sicheren Zustand ist, bevor du ihn in die Hand nimmst.
- **Nutzung:**
 - Lade den Revolver gemäß den Anweisungen in der Bedienungsanleitung.
 - Stelle sicher, dass der Abzug nicht versehentlich betätigt wird, während du den Revolver handhabst.
 - Halte den Revolver mit beiden Händen, um eine bessere Kontrolle zu gewährleisten.
 - Ziele immer sicher und schieße nur, wenn du sicher bist, dass es keine Gefahr für andere gibt.

Entsorgungsanweisungen

- Entsorge leere Patronenhülsen gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Der Revolver selbst sollte nicht in den normalen Müll entsorgt werden. Kontaktiere deinen örtlichen Waffenhändler oder die zuständigen Behörden für Informationen zur sicheren Entsorgung.
- Stelle sicher, dass der Revolver entladen ist, bevor du ihn zur Entsorgung bringst.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Anliegen zur Sicherheit deines TOP BREAK NO. 3 45 COLT REVOLVER UBERTI 1875 wende dich bitte an den Hersteller oder einen qualifizierten Fachmann.

Bitte beachte, dass diese Sicherheitshinweise in Übereinstimmung mit den EU-Richtlinien für Produktsicherheit erstellt wurden. Halte dich an diese Richtlinien, um deine Sicherheit und die Sicherheit anderer zu gewährleisten.

Safety Instruction Guide for TOP BREAK NO. 3 45 COLT REVOLVER 1875

Introduction

Thank you for choosing the TOP BREAK NO. 3 45 COLT REVOLVER 1875. This guide provides essential safety information and instructions to ensure the safe use of your revolver. Please read this guide thoroughly before using the product.

General Safety Guidelines

- Always treat the revolver as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Ensure that the safety mechanism is engaged when not in use.
- Store the revolver in a secure location away from children and unauthorized users.
- Regularly inspect the revolver for any signs of wear or damage.
- Use only the recommended ammunition type (45 Long Colt) for this revolver.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Before handling the revolver, ensure you are in a safe environment away from people and property.
- When loading or unloading, do so in a controlled area, ensuring no one is nearby.
- Do not attempt to modify the revolver in any way. Unauthorized modifications can lead to malfunction or injury.
- Always wear appropriate eye and ear protection when firing the revolver.
- Be aware of your surroundings and ensure that there is a safe backstop when firing.
- If you experience a misfire, wait at least 30 seconds before attempting to open the revolver.
- Do not use the revolver if you are under the influence of drugs or alcohol.

Instructions for Installation and Usage

- **Loading the Revolver:**
 1. Ensure the revolver is pointed in a safe direction.
 2. Open the breakaction mechanism by pulling the lever.
 3. Insert cartridges into the chambers, ensuring they are seated properly.
 4. Close the action securely.
- **Firing the Revolver:**
 1. Ensure the revolver is loaded.
 2. Engage the safety mechanism.
 3. Point the muzzle at the intended target.
 4. Disengage the safety and pull the trigger to fire.
- **Unloading the Revolver:**
 1. Point the revolver in a safe direction.
 2. Open the breakaction mechanism.
 3. Eject any spent cartridges and remove live cartridges from the chambers.
 4. Close the action securely.
- **Cleaning and Maintenance:**
 1. Ensure the revolver is unloaded before cleaning.
 2. Use a cleaning rod and appropriate solvent to clean the barrel and chambers.
 3. Wipe down the exterior with a soft cloth to remove fingerprints and moisture.
 4. Store the revolver in a dry place.

Disposal Instructions

- When disposing of the revolver, follow local laws and regulations regarding firearm disposal.
- Do not throw the revolver in the trash.
- Contact a local firearms dealer or law enforcement agency for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the TOP BREAK NO. 3 45 COLT REVOLVER 1875, please refer to the manufacturer or authorized dealer for assistance. Ensure that you have the product information ready for reference.

By following these guidelines and instructions, you can ensure the safe and responsible use of your TOP BREAK NO. 3 45 COLT REVOLVER 1875. Always prioritize safety and adhere to all local laws regarding firearm usage. Thank you for your attention to these important safety measures.