

A400 XCEL SPORTING BLACK KO 12 GAUGE SEMI-AUTO SHOTGUN - A400 XCEL SPORTING BLACK KO 12 GAUGE 28" BBL 3RD WALNUT

The A400 Xcel is a competition shotgun that is faster-cycling, softer-shooting and better balanced than anything else on the market. Built on the revolutionary A400 action, it delivers follow-up shots faster than any other brand, while its advanced recoil-reducing systems make it absolutely pleasant to shoot, even on demanding all-day competitions. Its sleek lines and superior ergonomics are designed with one goal in mind: letting the A400 naturally lead your eye to the target. This is why it has quickly become a favorite among serious competitive shooters the world over. Building on the success of Beretta's Black Edition competition shotguns like the DT11, 692 and 690, the A400 Xcel Sporting Black Edition features a 10mm wide rib made of lightweight and strong carbon fiber (the same material and process used to make components for Formula One racecars) that reduces the weight of the barrel by 4oz for improved swingability and target acquisition. It also boasts oversized controls (bolt handle and release) to aid in faster, easier loading between shots.



Attributes

- Name: A400 XCEL SPORTING BLACK KO 12 GAUGE 28" BBL 3RD WALNUT
- Manufacturer: BERETTA USA
- Product no.: 430106376
- Mfr. No.:
- Action Type: Semi-Auto
- Barrel Length: 28"
- Capacity: 3-Round
- Finish: Walnut
- Front Sight: Bead
- Gauge: 12 Gauge
- Length: NA
- Magazine Included: 1 x 3-Round
- Magazine Type: Tubular
- Make: Beretta
- Model: A400 Xcel Sporting
- Muzzle: Choke Tubes
- Rear Sight: None
- Stock Material: Walnut
- Weight: 7.7 lbs
- Delivery weight: 4.536kg
- Shipping height: 89mm
- Shipping width: 254mm
- Shipping length: 965mm

Item details

US export classification: 0A502

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die A400 XCEL SPORTING BLACK KO 12 GAUGE SEMIAUTO SHOTGUN](#)
- [English: A400 XCEL SPORTING BLACK KO 12 GAUGE SEMIAUTO SHOTGUN Safety Instruction Guide](#)

Sicherheitshinweise für die A400 XCEL SPORTING BLACK KO 12 GAUGE SEMIAUTO SHOTGUN

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der A400 Xcel Sporting Black KO 12 Gauge SemiAuto Shotgun von Beretta. Diese Anleitung bietet wichtige Sicherheitsinformationen, um sicherzustellen, dass Sie Ihr Produkt sicher und effektiv nutzen können. Bitte lesen Sie diese Anleitung sorgfältig durch, bevor Sie das Produkt verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Schrotflinte nur in einem sicheren und geeigneten Umfeld verwenden.
- Verwenden Sie die Schrotflinte niemals unter dem Einfluss von Alkohol oder Drogen.
- Halten Sie die Schrotflinte immer in einem sicheren Zustand, indem Sie den Lauf entleert und die Sicherung aktiviert halten, wenn sie nicht in Gebrauch ist.
- Bewahren Sie die Schrotflinte außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Verwenden Sie nur die empfohlenen Munitionstypen, um Verletzungen oder Schäden zu vermeiden.
- Überprüfen Sie regelmäßig auf Verschleiß oder Beschädigungen. Bei Anzeichen von Beschädigungen verwenden Sie die Schrotflinte nicht und lassen Sie sie von einem Fachmann überprüfen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Schutzbrille und Ohrenschutz, wenn Sie die Schrotflinte verwenden.
- Achten Sie darauf, dass die Mündung immer in eine sichere Richtung zeigt.
- Stellen Sie sicher, dass sich keine Personen oder Tiere im Schussbereich befinden, bevor Sie abdrücken.
- Laden Sie die Schrotflinte nur, wenn Sie bereit sind zu schießen.
- Verwenden Sie die Schrotflinte nur für den vorgesehenen Zweck, z. B. für sportliches Schießen oder Jagd.
- Halten Sie den Finger von der Abzugsgabel, bis Sie bereit sind zu schießen.

Anweisungen zur Installation und Nutzung

- **Installation:**
 - Überprüfen Sie, ob alle Teile der Schrotflinte vorhanden sind und keine Beschädigungen aufweisen.
 - Befolgen Sie die Anweisungen im Benutzerhandbuch zur Montage und Einstellung der Schrotflinte.
- **Nutzung:**
 - Laden Sie die Schrotflinte gemäß den Anweisungen im Benutzerhandbuch.
 - Stellen Sie sicher, dass die Sicherung aktiviert ist, wenn die Schrotflinte nicht in Gebrauch ist.
 - Führen Sie regelmäßige Wartungsarbeiten durch, um die Leistung der Schrotflinte zu gewährleisten.

Entsorgungsanweisungen

- Entsorgen Sie die Schrotflinte gemäß den örtlichen Gesetzen und Vorschriften.
- Bringen Sie die Schrotflinte zu einem autorisierten Händler oder einer Fachwerkstatt, wenn Sie sie nicht mehr benötigen.
- Entsorgen Sie Munition und andere gefährliche Materialien sicher und gemäß den örtlichen Vorschriften.

Kontaktinformationen für weitere Unterstützung

Sollten Sie Fragen oder Bedenken bezüglich der Sicherheit oder Nutzung Ihrer A400 Xcel Sporting Black KO 12 Gauge SemiAuto Shotgun haben, wenden Sie sich bitte an den zuständigen Fachhändler oder den Kundenservice von Beretta. Sie stehen Ihnen gerne zur Verfügung, um Ihnen zu helfen.

A400 XCEL SPORTING BLACK KO 12 GAUGE SEMIAUTO SHOTGUN Safety Instruction Guide

Introduction

Thank you for choosing the A400 Xcel Sporting Black KO 12 Gauge SemiAuto Shotgun. This guide provides essential safety instructions to ensure your safe use of the shotgun in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure safe handling and use of the shotgun at all times.
- Always treat the shotgun as if it is loaded.
- Keep the shotgun pointed in a safe direction.
- Store the shotgun securely and out of reach of children and unauthorized users.
- Use the shotgun only for its intended purpose.
- Regularly inspect the shotgun for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm use and ownership.
- Be aware of your surroundings and ensure a safe shooting environment.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection while shooting.
- Do not use the shotgun if you are under the influence of drugs or alcohol.
- Ensure that the shotgun is unloaded when not in use.
- Avoid using the shotgun in wet or damp conditions to prevent malfunction.
- Use only manufacturerapproved ammunition for the shotgun.
- Do not attempt to modify or alter the shotgun in any way.
- Be mindful of the shotgun's recoil and practice proper shooting stance to manage it effectively.
- Always check the barrel for obstructions before loading.

Instructions for Installation and Usage

- **Installation:**
 - Ensure that you are in a safe and secure environment for installation.
 - Carefully unpack the shotgun and all included components.
 - Inspect the shotgun for any visible damage. If any damage is found, do not use the shotgun and contact the manufacturer.
 - Follow the manufacturer's instructions for attaching any accessories, such as sights or slings.
- **Usage:**
 - To load the shotgun:
 - Ensure the safety is engaged.
 - Open the action and insert the ammunition into the magazine.
 - Close the action and disengage the safety before firing.
 - To fire the shotgun:
 - Aim at your target while maintaining a safe shooting stance.
 - Pull the trigger gently to fire.
 - To unload the shotgun:
 - Engage the safety.
 - Open the action to remove any remaining ammunition from the chamber and magazine.
 - Visually and physically check that the shotgun is unloaded.

Disposal Instructions

- Dispose of the shotgun in accordance with local laws and regulations.
- Do not dispose of the shotgun in regular household waste.
- If the shotgun is damaged or no longer functional, contact a qualified firearms dealer for proper disposal methods.
- Ensure that all ammunition is disposed of safely and in compliance with local regulations.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the manufacturer's contact details provided with the product packaging.