

UXR ELITE RIFLE SYSTEM 300 AAC BLACKOUT SEMI-AUTO RIFLE - UXR ELITE RIFLE SYSTEM 300 BLACKOUT 14.5"BBL (1)30RD MAG BLK

UXR THE NEW PROPRIETARY UXR, OR "USER XCHANGE RIFLE", IS THE PINNACLE OF FIREARM INNOVATION. THIS REVOLUTIONARY SYSTEM OFFERS UNMATCHED MODULARITY AND PERFORMANCE. FEATURES:

XCHANGE Buttstock Module: Picatinny/1913/STANAG Rail mount interface, foldable with 6 position adjustable length of pull for 2.5" travel, ambidextrous LOP button and QD sling cups, 1" webbing sling slot mount, comfort-shoot rubber buttpad, and completed with a 2 position, height-adjustable cheek rest.

Reversible Folding Stock Mount: Choose your preferred side for folding the XCHANGE Buttstock Module.

XCHANGE Fire Control Housing Module: ergonomically designed UXR pistol grip also compatible with other AR15 style grips, ambidextrous QD sling cups, and oversized trigger guard.

XCHANGE Fire Control Module: Housing compatible with most AR15 triggers.

XCHANGE Magazine Well Module: Easily exchange modules for 5.56 NATO or 7.62 NATO magazines, complete with ambidextrous magazine release button and bolt stop/release

7075 Aluminum Receiver: Serialized upper receiver; universally compatible with multiple caliber configurations.

XCHANGE Titanium Trunnion: Return-to-zero-barrel clamp for precision modularity.

STANAG Top Rail: 18" usable length for optics and accessory mounts.

XCHANGE Handguard: Toolless and replaceable MLOK handguard for length customization.

Ambidextrous Folding Charging Handle: Snag-free and configurable for left or right handed users.

XCHANGE Barrel Exchange System: Swap calibers and barrel lengths rapidly with standard tooling, while maintaining repeatability and accuracy.

Ambidextrous Rocker Valve/Modified Long-Stroke Gas System: Select 3 gas settings effortlessly.

XCHANGE Evacuation Chamber: Supports suppressed and high rate of fire by removing noxious gasses from the operator's face and keeping the operating system cleaner.

Taper Muzzle Shoulder Lock: Perfect alignment and accessory lock for muzzle devices.

Universal Recoil Spring: Adaptable to various calibers and configurations.

Universal Bolt Carrier Group: Quick exchange bolt head assemblies for easy caliber conversions

14.5 inch models feature a pinned and welded muzzle device to bring the barrel overall length over 16 inches.



Attributes

- Name: UXR ELITE RIFLE SYSTEM 300 BLACKOUT 14.5"BBL (1)30RD MAG BLK
- Manufacturer: PRIMARY WEAPONS
- Product no.: 430108088
- Mfr. No.: U2E14RB11-1F
- Action Type: Semi-Auto
- Barrel Length: 14.5"
- Capacity: 30+1-Round
- Cartridge: 300 AAC Blackout
- Finish: Black
- Front Sight: None
- Length: NA
- Magazine Included: 1 x 30-Round
- Magazine Type: Removable
- Make: Primary Weapons System
- Model: UXR Elite
- Muzzle: Compensator
- Rear Sight: None
- Stock Material: Synthetic
- Weight: NA
- Delivery weight: 4.536kg
- Shipping height: 102mm
- Shipping width: 305mm
- Shipping length: 940mm
- UPC: 811154031785

Item details

Made in USA

US export classification: 0A506.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das UXR Elite Rifle System 300 AAC Blackout](#)
- [English: UXR Elite Rifle System Safety Instruction Guide](#)
- [Italiano: Guida alle Istruzioni di Sicurezza per il Sistema di Fucile UXR Elite 300 AAC Blackout](#)

Sicherheitshinweise für das UXR Elite Rifle System 300 AAC Blackout

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des UXR Elite Rifle Systems 300 AAC Blackout. Dieses Produkt wurde mit dem Ziel entwickelt, höchste Leistung und Modularität zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt in einem sicheren und kontrollierten Umfeld verwendet wird.
- Verwenden Sie das UXR Elite Rifle System nur für den vorgesehenen Zweck.
- Halten Sie das Produkt von Kindern und unbefugten Personen fern.
- Überprüfen Sie regelmäßig auf mögliche Schäden oder Abnutzungen, die die Sicherheit beeinträchtigen könnten.
- Informieren Sie sich über die geltenden Gesetze und Vorschriften in Ihrem Land bezüglich des Besitzes und der Verwendung von Feuerwaffen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- **Tragen Sie immer Schutzbrillen und Gehörschutz**, wenn Sie das UXR Elite Rifle System verwenden.
- **Vergewissern Sie sich, dass die Waffe immer als geladen betrachtet wird**, bis Sie sicher sind, dass sie entladen ist.
- **Richten Sie die Mündung niemals auf Personen oder unbeabsichtigte Ziele.**
- **Halte den Finger immer außerhalb des Abzugsbügels**, bis Sie bereit sind zu schießen.
- **Vermeiden Sie Alkohol oder Drogen**, bevor Sie das UXR Elite Rifle System verwenden.
- **Lagern Sie die Waffe sicher** und verwenden Sie einen Waffenschrank oder eine ähnliche Einrichtung, um unbefugten Zugriff zu verhindern.

Anweisungen für Installation und Nutzung

Installation

- Stellen Sie sicher, dass das UXR Elite Rifle System auf einer stabilen und ebenen Fläche montiert ist.
- Befolgen Sie die Anweisungen im Benutzerhandbuch für die Montage des XCHANGE Schulterstützenmoduls und anderer Zubehörteile.
- Überprüfen Sie alle Befestigungen, um sicherzustellen, dass sie fest angezogen sind, bevor Sie das System verwenden.

Nutzung

- Laden Sie das UXR Elite Rifle System gemäß den Anweisungen im Benutzerhandbuch.
- Wählen Sie die gewünschte GasEinstellung, um die Leistung des Systems zu optimieren.
- Achten Sie darauf, dass die Evakuierungskammer ordnungsgemäß funktioniert, um schädliche Gase abzuleiten.
- Nach dem Schießen reinigen Sie das System gründlich, um eine optimale Leistung zu gewährleisten.

Entsorgungsanweisungen

- Entsorgen Sie leere Magazine und andere nicht mehr benötigte Teile gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Überprüfen Sie die gesetzlichen Bestimmungen in Ihrer Region zur Entsorgung von Feuerwaffen und Zubehör.
- Verwenden Sie geeignete Entsorgungsmethoden, um Umweltschäden zu vermeiden.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung zu Ihrem UXR Elite Rifle System wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Es ist wichtig, dass Sie bei Sicherheitsfragen oder Problemen schnell Hilfe erhalten.

Schlussfolgerung

Die Sicherheit hat bei der Verwendung des UXR Elite Rifle Systems oberste Priorität. Durch die Einhaltung dieser Sicherheitsrichtlinien und Vorkehrungen können Sie sicherstellen, dass Sie und andere in Ihrer Umgebung geschützt sind. Bleiben Sie informiert über Sicherheitsupdates und Rückrufe, um die Sicherheit Ihres Produkts zu gewährleisten.

UXR Elite Rifle System Safety Instruction Guide

Introduction

Thank you for choosing the UXR Elite Rifle System 300 AAC Blackout SemiAuto Rifle. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your firearm. Please read and understand this manual before using the product.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store firearms securely and out of reach of children and unauthorized users.
- Use appropriate hearing and eye protection when shooting.
- Regularly inspect the firearm for any signs of wear or damage.
- Do not use ammunition not specified for this firearm.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure that the rifle is unloaded before handling or cleaning.
- Use the XCHANGE Fire Control Module and other components as specified in the manual to avoid malfunctions.
- Be cautious when using the adjustable buttstock and cheek rest to prevent pinching or injury.
- When swapping barrels or calibers, ensure that all components are properly secured and compatible.
- When using the Ambidextrous Folding Charging Handle, ensure that it is fully engaged before firing.
- If the rifle fails to fire or malfunctions, follow the manufacturer's instructions for clearing the malfunction safely.
- Avoid using the rifle in adverse weather conditions unless it is specifically designed for such use.

Instructions for Installation and Usage

Installation

1. Assemble the Rifle:

- Ensure the rifle is unloaded.
- Attach the XCHANGE Buttstock Module to the receiver by aligning the mounting points and securing it with the provided hardware.
- Install the XCHANGE Handguard by sliding it onto the barrel nut and securing it as per the instructions.
- Attach any optics or accessories to the STANAG Top Rail as needed.

2. Load the Magazine:

- Insert the magazine into the magazine well until it clicks into place.
- Ensure the magazine release button operates correctly.

3. Adjust the Buttstock:

- Adjust the length of pull by pressing the ambidextrous LOP button and sliding the buttstock to the desired position.

Usage

1. Firing the Rifle:

- Ensure the rifle is pointed downrange.
- Load the firearm by pulling back the charging handle and releasing a round into the chamber.
- Keep your finger off the trigger until ready to fire.
- Aim at your target and squeeze the trigger smoothly.

2. PostFiring:

- After firing, keep the rifle pointed in a safe direction.
- Eject the magazine and clear the chamber before handling.
- Inspect the firearm for any signs of malfunction.

Disposal Instructions

When disposing of the UXR Elite Rifle System, follow these guidelines:

- Ensure the firearm is unloaded before disposal.
- Check local laws and regulations regarding the disposal of firearms.
- If possible, return the firearm to a licensed dealer or manufacturer for safe disposal.
- Do not discard firearms in regular trash or recycling.

Contact Information for Further Support

For any safety inquiries, product support, or assistance, please contact the manufacturer or your local authorized dealer. Ensure you have your product details and any relevant information ready for a more efficient response.

By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your UXR Elite Rifle System. Always prioritize safety and responsible firearm handling.

Guida alle Istruzioni di Sicurezza per il Sistema di Fucile UXR Elite 300 AAC Blackout

Introduzione

Benvenuti nella guida alle istruzioni di sicurezza per il Sistema di Fucile UXR Elite 300 AAC Blackout. Questa guida è progettata per garantire un uso sicuro e responsabile del prodotto, in conformità con le normative europee sulla sicurezza dei prodotti (EU GPSR). Si prega di leggere attentamente tutte le sezioni per comprendere le precauzioni necessarie e le istruzioni per un uso corretto.

Linee Guida Generali di Sicurezza

- Assicurarsi di utilizzare il prodotto solo per lo scopo previsto.
- Leggere e comprendere tutte le istruzioni e le avvertenze del produttore prima dell'uso.
- Tenere il prodotto fuori dalla portata di bambini e gruppi vulnerabili.
- Controllare regolarmente il prodotto per eventuali segni di usura o danni.
- Segnalare immediatamente qualsiasi prodotto difettoso o pericoloso alle autorità competenti.

Precauzioni di Sicurezza Specifiche per l'Uso

- Utilizzare sempre occhiali protettivi e protezioni per le orecchie durante l'uso del fucile.
- Non puntare mai il fucile verso persone o animali.
- Assicurarsi che l'arma sia scarica quando non in uso o durante la manutenzione.
- Non utilizzare munizioni danneggiate o non conformi.
- Seguire sempre le normative locali e nazionali riguardanti l'uso delle armi.

Istruzioni per l'Installazione e l'Uso

Installazione

- Seguire le istruzioni del produttore per l'assemblaggio e la configurazione del fucile.
- Assicurarsi che tutti i componenti siano installati correttamente e in modo sicuro.
- Controllare che il modulo Calcolo XCHANGE sia fissato saldamente prima dell'uso.

Uso

- Prima di ogni utilizzo, controllare che l'arma sia in condizioni sicure e funzionanti.
- Regolare il Modulo Calcolo XCHANGE in base alle proprie esigenze di comfort.
- Utilizzare il pulsante di rilascio del caricatore ambidestro per una sostituzione sicura del caricatore.
- Seguire le istruzioni per la selezione delle impostazioni del gas sul sistema a gas a lunga corsa modificato.
- Durante l'uso, mantenere una postura stabile e controllata.

Istruzioni per lo Smaltimento

- Smaltire il prodotto in conformità con le normative locali sui rifiuti e sul riciclaggio.
- Non gettare il prodotto nell'indifferenziato o nei rifiuti domestici.
- Contattare un centro di raccolta autorizzato per lo smaltimento di armi e accessori.

Informazioni di Contatto per Ulteriori Supporto

Per domande o preoccupazioni relative alla sicurezza del prodotto, si prega di contattare il proprio rivenditore o un esperto di sicurezza delle armi. Assicurarsi di avere a disposizione il numero di modello e altre informazioni pertinenti per ricevere assistenza adeguata.

Si prega di notare che questa guida è stata redatta per garantire la sicurezza degli utenti e il rispetto delle normative vigenti. Utilizzare sempre il buon senso e la responsabilità quando si maneggiano armi.