

GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22LR LEVER ACTION RIFLE - GOLDEN BOY DLX ENGRAVED 4TH ED 22 S/L/LR 20" BBL 16RD WALNUT

GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22 S/L/LR LEVER ACTION RIFLE No firearm collection is complete without a Henry Golden Boy, and for the most discerning collectors, a Henry Golden Boy Deluxe Engraved Edition. Now in its fourth rendition, this limited-edition rifle elevates the legendary Golden Boy to what can only be described as a functional work of art. For centuries, firearms have been the canvas for Old World artisans to showcase their craft. The likes of Gustave Young, Louis Nimschke, the Ulrich brothers, and others have propelled this practice to new heights, with their work now adorning some of the world's most prestigious art and history museums. Today, Henry Repeating Arms proudly honors their craft and carries on this rich tradition with modern-day masters of hammer and chisel, connecting you to this rich heritage. The Golden Boy Deluxe Engraved 4th Edition rifle is a masterpiece in its own right. It features a Brasslite receiver cover and barrel band, both engraved with ornate scrollwork inspired by the 19th-century greats. Meticulous stippling throughout the intertwining scrolls adds depth and contrast, while a scalloped border frames the design on each panel. The brass barrel band is engraved on both sides with another flourishing scroll to match the receiver cover, creating a design that is sure to captivate any firearm enthusiast. While not the result of an artist's hand, we selected Fancy-grade American Walnut for these rifles, which are works of art in their own right. Every piece of wood is different, but only pieces that exhibit some marble-like figuration and rich coloration make the cut for this edition. To further distinguish this edition from the rest, each rifle in the series bears a unique serial number between 1 and 1,000. The rest of the rifle follows suit with the award-winning Golden Boy, including the 20" blued steel octagon barrel, fully adjustable sights, brass buttplate, and the smoothest action you will ever feel right out of the box. This is the finest example of a Golden Boy rifle that money can buy. Should you choose to spend your hard-earned money on this particular Golden Boy, we hope you will display it with pride as a cornerstone of your collection. SPECIFICATIONS: Barrel Length: 20" Barrel Type: Octagon Blued Steel Rate of Twist: 1:16 Overall Length: 38.5" Weight: 6.75 lbs. Receiver Finish: Brasslite Rear Sight: Fully Adj. Semi-Buckhorn w/ Diamond Insert Front Sight: Brass Bead Scopeability: Drilled and Tapped Scope Mount Type: GB-CSM Stock Material: Fancy American Walnut Buttplate/Pad: Brass Length of Pull: 14" Safety: 1/4 Cock Best Uses: Target/Hunting/Collector Embellishments/Extras: Receiver and Barrel Band Engraving. Limited to 1000.



Attributes

- Name: GOLDEN BOY DLX ENGRAVED 4TH ED 22 S/L/LR 20" BBL 16RD WALNUT
- Manufacturer: HENRY REPEATING ARMS
- Product no.: 430111614
- Mfr. No.: H004D4
- Action Type: Lever Action
- Barrel Length: 20"
- Capacity: 16-Round
- Cartridge: 22 Long,22 Short,22 Long Rifle
- Finish: American Walnut
- Front Sight: Bead
- Length: 38.5"
- Magazine Included: 1 x 16-Round
- Magazine Type: Tubular
- Make: Henry
- Model: Golden Boy
- Muzzle: Non-Threaded
- Rear Sight: Adjustable
- Stock Material: Walnut
- Weight: 6.75 lbs
- UPC: 619835044082

Item details

Made in USA

US export classification: 0A501.a

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22LR LEVER ACTION RIFLE](#)
- [English: Safety Instruction Guide for GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22LR LEVER ACTION RIFLE](#)
- [Italiano: GUIDA ALL'USO SICURO DEL FUCILE GOLDEN BOY DELUXE INCISO QUARTA EDIZIONE](#)

Sicherheitshinweise für den GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22LR LEVER ACTION RIFLE

Einleitung

Willkommen zu den Sicherheitshinweisen für das GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22LR LEVER ACTION RIFLE von Henry Repeating Arms. Dieses Gewehr ist ein Meisterwerk und erfordert verantwortungsvollen Umgang. Bitte beachte die folgenden Sicherheitsrichtlinien, um sicherzustellen, dass du und andere in deiner Umgebung sicher bleiben.

Allgemeine Sicherheitsrichtlinien

- Halte das Gewehr immer in einem sicheren Zustand, bis du bereit bist, es zu verwenden.
- Überprüfe immer, ob die Waffe entladen ist, bevor du sie handhabst oder reinigst.
- Verwende immer die richtige Munition für dein Gewehr. In diesem Fall ist das Kaliber .22 Long Rifle, .22 Short und .22 Long.
- Bewahre das Gewehr an einem sicheren Ort auf, der für Kinder unzugänglich ist.
- Trage beim Schießen immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Informiere dich über die lokalen Gesetze und Vorschriften bezüglich des Besitzes und Gebrauchs von Feuerwaffen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Vermeide es, das Gewehr auf dich selbst oder andere zu richten, auch wenn du glaubst, dass es entladen ist.
- Halte den Finger immer außerhalb des Abzugsbereichs, bis du bereit bist zu schießen.
- Achte darauf, dass du beim Schießen einen sicheren Bereich hast, in dem du die Kugel abfeuern kannst, ohne dass Gefahr für andere besteht.
- Lass das Gewehr niemals unbeaufsichtigt, wenn es geladen ist.
- Verwende das Gewehr nicht unter dem Einfluss von Alkohol oder Drogen.

Anweisungen für Installation und Nutzung

- Stelle sicher, dass du alle Teile des Gewehrs vor der ersten Nutzung überprüfst.
- Befolge die folgenden Schritte, um das Gewehr sicher zu verwenden:
 1. Überprüfe den Zustand des Gewehrs und stelle sicher, dass es sauber und funktionsfähig ist.
 2. Lade das Gewehr gemäß den Anweisungen des Herstellers:
 - Öffne den Verschluss und lade die Munition in das Magazin.
 - Schließe den Verschluss, um das Gewehr für den Schuss vorzubereiten.
 3. Zielen und schießen:
 - Nimm eine stabile Haltung ein und ziele auf das Ziel.
 - Atme tief durch und drücke den Abzug sanft.
 4. Nach dem Schießen:
 - Entlade das Gewehr sofort nach dem Schießen, bevor du es ablegst oder reinigst.
 - Reinige das Gewehr regelmäßig, um die Funktionalität aufrechtzuerhalten.

Entsorgungsanweisungen

- Entsorge leere Patronen und Munition auf umweltfreundliche Weise.
- Konsultiere lokale Vorschriften zur Entsorgung von Feuerwaffen und Munition.
- Überlege, ob du das Gewehr an einen lizenzierten Händler oder eine autorisierte Person verkaufen oder abgeben möchtest, wenn du es nicht mehr benötigst.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung zu Sicherheitsfragen, wende dich bitte an den Hersteller oder einen autorisierten Händler.

Bitte beachte, dass die Einhaltung dieser Sicherheitsrichtlinien nicht nur deine Sicherheit, sondern auch die Sicherheit anderer gewährleistet. Sei verantwortungsbewusst und genieße dein GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22LR LEVER ACTION RIFLE sicher und verantwortungsbewusst.

Safety Instruction Guide for GOLDEN BOY DELUXE ENGRAVED 4TH EDITION 22LR LEVER ACTION RIFLE

Introduction

Thank you for choosing the Golden Boy Deluxe Engraved 4th Edition 22LR Lever Action Rifle. This firearm is a finely crafted piece designed for collectors and enthusiasts alike. To ensure safe handling and operation, please read this safety instruction guide carefully. It complies with the EU General Product Safety Regulation (GPSR) to help protect you and others.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Ensure the safety mechanism is engaged until you are ready to shoot.
- Store the firearm in a secure location, away from children and unauthorized users.
- Regularly inspect the firearm for signs of wear or damage.
- Use only the recommended ammunition for this rifle: .22 Long Rifle, .22 Short, and .22 Long.
- Always wear appropriate eye and ear protection when shooting.
- Be aware of your surroundings and ensure a clear shooting area.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Use the firearm only for its intended purpose (target shooting, hunting, or collecting).
- Never modify the firearm or its components without professional assistance.
- Do not use the firearm under the influence of alcohol or drugs.
- Ensure that the barrel is clear of obstructions before firing.
- Be cautious of the potential for ricochet when shooting at hard surfaces.
- Keep your fingers off the trigger until you are ready to shoot.
- Always check the chamber before handling the firearm to ensure it is unloaded.
- If a misfire occurs, wait 30 seconds before attempting to open the action.

Instructions for Installation and Usage

1. Unpacking the Rifle:

- Carefully remove the rifle from its packaging.
- Inspect the rifle for any visible damage or defects.

2. Loading the Rifle:

- Ensure the rifle is pointed in a safe direction.
- Open the action and visually inspect the chamber to confirm it is clear.
- Insert the magazine into the magazine well until it clicks into place.
- Load the appropriate ammunition into the magazine.

3. Firing the Rifle:

- Ensure the safety is in the "fire" position.
- Aim at your target while keeping the rifle steady.
- Squeeze the trigger gently to fire.
- After firing, keep the rifle pointed downrange until you are finished shooting.

4. Unloading the Rifle:

- Engage the safety mechanism.
- Open the action and remove the magazine.
- Visually inspect the chamber to ensure it is clear of ammunition.

5. Cleaning and Maintenance:

- Regularly clean the rifle according to the manufacturer's recommendations.
- Use appropriate cleaning solvents and tools designed for firearms.
- Inspect all components for signs of wear and replace any damaged parts.

Disposal Instructions

- Dispose of the firearm only through authorized dealers or according to local regulations.
- Do not discard the firearm in regular waste.
- Follow all local laws regarding the disposal of firearms and ammunition.

Contact Information for Further Support

For any questions regarding safety, usage, or maintenance of your Golden Boy Deluxe Engraved 4th Edition 22LR Lever Action Rifle, please refer to your local dealer or authorized service center. Ensure that you have the product information and serial number available for assistance.

By following these safety guidelines and instructions, you can enjoy your Golden Boy rifle responsibly and safely. Thank you for your attention to these important safety measures.

GUIDA ALL'USO SICURO DEL FUCILE GOLDEN BOY DELUXE INCISO QUARTA EDIZIONE

Introduzione

Benvenuti nella guida all'uso sicuro del Fucile Golden Boy Deluxe Inciso Quarta Edizione 22LR Lever Action Rifle di Henry Repeating Arms. Questa guida fornisce informazioni importanti per garantire un utilizzo sicuro e responsabile del prodotto. È fondamentale seguire tutte le istruzioni e le precauzioni di sicurezza per proteggere te stesso e gli altri.

Linee Guida Generali di Sicurezza

- Assicurati di leggere e comprendere completamente il manuale dell'utente prima di utilizzare il fucile.
- Tieni il fucile sempre in una posizione sicura e puntato in una direzione sicura.
- Non puntare mai il fucile verso persone o animali.
- Mantieni il dito al di fuori del grilletto fino a quando non sei pronto a sparare.
- Controlla sempre che il fucile sia scarico quando non in uso.
- Utilizza solo munizioni appropriate per il tuo fucile, specificamente 22 Long Rifle, 22 Short, e 22 Long.
- Conserva il fucile in un luogo sicuro e inaccessibile ai bambini.

Precauzioni di Sicurezza Specifiche per l'Uso

- Indossa sempre occhiali protettivi e protezioni per le orecchie quando utilizzi il fucile.
- Non utilizza il fucile sotto l'effetto di alcol o droghe.
- Non tentare mai di modificare il fucile in alcun modo.
- Verifica sempre il funzionamento del fucile prima dell'uso. Controlla che non ci siano ostruzioni nel canna.
- Non utilizzare il fucile se presenta segni di danni o usura.
- In caso di malfunzionamenti, interrompi immediatamente l'uso e contatta un esperto.

Istruzioni per l'Installazione e l'Uso

1. Preparazione per l'uso:

- Verifica che il fucile sia scarico.
- Controlla che tutte le parti siano in buone condizioni.
- Assicurati di avere munizioni appropriate.

2. Caricamento del fucile:

- Inserisci le munizioni nel caricatore seguendo le istruzioni specifiche per il tuo modello.
- Assicurati che il caricatore sia completamente inserito nel fucile.

3. Pronto per il tiro:

- Porta il fucile in posizione di tiro, mantenendo il dito al di fuori del grilletto.
- Regola il mirino secondo le tue preferenze.

4. Sparare:

- Punta il fucile verso il bersaglio.
- Quando sei pronto, premi delicatamente il grilletto.

5. Dopo il tiro:

- Controlla sempre che il fucile sia scarico dopo aver finito di sparare.
- Pulisci il fucile regolarmente per mantenerlo in buone condizioni.

Istruzioni per lo Smaltimento

- Non gettare il fucile o le munizioni nei rifiuti domestici.
- Contatta un rivenditore autorizzato o un centro di raccolta per lo smaltimento sicuro di armi e munizioni.
- Segui sempre le leggi locali riguardanti lo smaltimento di armi da fuoco.

Informazioni di Contatto per Ulteriori Supporto

Per domande o ulteriori informazioni sulla sicurezza del prodotto, contatta il tuo rivenditore autorizzato o visita il sito web di Henry Repeating Arms.

Conclusione

La sicurezza è la priorità assoluta quando si utilizza un fucile. Segui sempre queste linee guida e istruzioni per garantire un'esperienza di tiro sicura e piacevole. Ricorda, la responsabilità è fondamentale nel possesso e nell'uso di armi da fuoco.