

SKYLIGHT LED SHELLPLATE LIGHT SYSTEM FOR LEE® LOADMASTER PRESS - INLINE FABRICATION SKYLIGHT LED SHELLPLATE LIGHT SYSTEM FOR LEE LOADMASTER PRESS

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The Skylight kit for the LEE Loadmaster features a machined bushing with an embedded high output LED pod that drops into the center hole of the toolhead. Additionally, the system also has a 4" 6 LED strip that attaches to the inside of the press frame. Super bright, high output, out of the way, no heat and does the job perfectly. Average lifespan is 75,000 hours. Few things are more comforting than pure, bright white light, to be able to see everything in motion on your shellplate and verify your powder charge without having to strain your eyes or fight the shadows. These systems are one of the best upgrades you can do to increase your enjoyment and comfort while reloading. The system comes complete with a 110 plug in adapter with 48" long cord, on/off switch, wire routing anchors and zip ties.



The Skylight kit for the LEE Loadmaster features a machined bushing with an embedded high output LED pod that drops into the center hole of the toolhead. Additionally, the system also has a 4" 6 LED strip that attaches to the inside of the press frame. Super bright, high output, out of the way, no heat and does the job perfectly. Average lifespan is 75,000 hours. Few things are more comforting than pure, bright white light, to be able to see everything in motion on your shellplate and verify your powder charge without having to strain your eyes or fight the shadows. These systems are one of the best upgrades you can do to increase your enjoyment and comfort while reloading. The system comes complete with a 110 plug in adapter with 48" long cord, on/off switch, wire routing anchors and zip ties.

Attributes

- Name: [INLINE FABRICATION SKYLIGHT LED SHELLPLATE LIGHT SYSTEM FOR LEE LOADMASTER PRESS](#)
- Manufacturer: [INLINE FABRICATION](#)
- Product no.: 430112033
- Mfr. No.: LEDSKYLM
- Delivery weight: 0.227kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 152mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for SKYLIGHT LED SHELLPLATE LIGHT SYSTEM FOR LEE LOADMASTER PRESS
- About Us

Safety Instruction Guide for SKYLIGHT LED SHELLPLATE LIGHT SYSTEM FOR LEE LOADMASTER PRESS

Introduction

Thank you for choosing the Skylight LED Shellplate Light System for your LEE Loadmaster Press. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read and understand all instructions before installation and use.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear.
- Do not use the product if it is damaged or malfunctioning.
- Avoid exposure to moisture or water; this product is intended for indoor use only.
- Follow all local electrical safety regulations when using the product.
- Do not attempt to disassemble or modify the product.

Specific Safety Precautions for Use

• Electrical Safety:

- Use the provided 110 plugin adapter only.
- Do not overload electrical outlets.
- Ensure your hands are dry before handling the electrical components.

• Installation Safety:

- Ensure the press is turned off and unplugged during installation.
- Use only the provided wire routing anchors and zip ties to secure wiring.

• Operational Safety:

- Do not stare directly into the LED lights for prolonged periods.
- Ensure the area is wellventilated while using the product.

Instructions for Installation and Usage

1. Installation:

- Unpack the Skylight LED Shellplate Light System and ensure all components are included.
- Locate the center hole of your LEE Loadmaster toolhead.
- Insert the machined bushing with the embedded LED pod into the center hole.
- Attach the 4" LED strip to the inside of the press frame using the provided adhesive backing.
- Use wire routing anchors and zip ties to secure any loose wiring.
- Connect the 110 plugin adapter to a suitable power outlet.
- Ensure the on/off switch is easily accessible.

2. Usage:

- Turn on the system using the on/off switch.
- Adjust the positioning of the LED lights as necessary to ensure optimal illumination of the shellplate.
- Verify the functionality of the lights before starting your reloading process.

Disposal Instructions

- Dispose of the product and any electrical components in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Check for local electronic waste disposal programs for safe disposal.

Contact Information for Further Support

For any questions or concerns regarding the Skylight LED Shellplate Light System, please reach out to your retailer or the manufacturer for assistance. Always refer to the product packaging for specific contact details.

By following these guidelines, you can ensure a safe and enjoyable experience while using the Skylight LED Shellplate Light System for your LEE Loadmaster Press. Thank you for your attention to these important safety instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk