

HILL COUNTRY II RIFLE CASE - HILL COUNTRY II 48" RIFLE CASE BROWN/KHAKI

HILL COUNTRY II RIFLE CASE Whether you're gearing up for hunting season or looking for a premium gun case for your newest firearm, you'll want to check out the features in the Hill Country II Series Gun Case. Constructed of extremely rugged 1680D, a dense heavy gauge foam & finished with a plush debossed fleece lining, our cases provide great protection from dust, bumps & scratches. It has 1.5 in. webbing straps and a durable carry handle for easy carry when hunting outdoors. It also has plenty of storage with 2 large front gusseted zippered pockets for all those necessary accessories. FEATURES: Extremely Rugged 1680D Construction Dense Heavy Gauge Interior Foam Padding Plush Debossed Fleece Interior Lining Reinforced Bar Tack Stitching on Handles 2 Large Front Gusseted Storage Pockets Reversed Zipper Provides a Clean Look Oversized Zipper Loop Pulls Oversized 1.5" Webbing Straps with Padded Handle Wrap Tall Profile Fits Scoped Rifles SPECIFICATIONS: Color: Green/Walnut Length: 48" inches (46in inch inner length)



Attributes

- Name: HILL COUNTRY II 48" RIFLE CASE BROWN/KHAKI
- Manufacturer: EVOLUTION OUTDOOR, LLC
- Product no.: 430112384
- Mfr. No.: 44370-EV
- Color: Brown/Khaki
- Material: Polyester
- Size: 48
- Style: Rifle
- Delivery weight: 1.089kg
- Shipping height: 13mm
- Shipping width: 254mm
- Shipping length: 1,219mm
- UPC: 814640025695

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den HILL COUNTRY II RIFLE CASE](#)
- [English: HILL COUNTRY II RIFLE CASE SAFETY INSTRUCTIONS](#)

Sicherheitshinweise für den HILL COUNTRY II RIFLE CASE

Einführung

Vielen Dank, dass du dich für den HILL COUNTRY II RIFLE CASE entschieden hast. Dieser Gewehrkoffer wurde entwickelt, um dein Gewehr sicher zu transportieren und zu lagern. Es ist wichtig, die Sicherheitshinweise zu beachten, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitshinweise

- Stelle sicher, dass der Gewehrkoffer nur für den Transport von Gewehren und nicht für andere Zwecke verwendet wird.
- Überprüfe regelmäßig den Zustand des Koffers auf Risse, Abnutzung oder andere Schäden.
- Halte den Koffer außerhalb der Reichweite von Kindern und Haustieren.
- Verwende den Koffer nur für den vorgesehenen Zweck und beachte die Herstellerhinweise.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Achte darauf, dass das Gewehr vor dem Einlegen in den Koffer entladen ist.
- Vermeide es, den Koffer in feuchten oder extrem heißen Umgebungen zu lagern, um Materialschäden zu vermeiden.
- Verwende die Gurtbänder und den Tragegriff, um den Koffer sicher zu transportieren.
- Schließe den Koffer immer, wenn er nicht in Gebrauch ist, um das Gewehr zu schützen.

Anweisungen für Installation und Nutzung

- Öffne den Koffer und lege das Gewehr vorsichtig hinein, wobei du darauf achtest, dass es gut gepolstert ist.
- Schließe den Koffer, indem du den Reißverschluss vollständig schließt, um ein Herausfallen des Gewehrs zu verhindern.
- Nutze die großen Taschen für die Aufbewahrung von Zubehörteilen, aber überlade den Koffer nicht, um die Handhabung zu erleichtern.
- Bei Bedarf kannst du den Koffer mit den Gurtbändern über der Schulter tragen oder mit dem Tragegriff in der Hand transportieren.

Entsorgungsanweisungen

- Entsorge den Gewehrkoffer gemäß den örtlichen Vorschriften für die Abfallentsorgung.
- Wenn der Koffer nicht mehr verwendet werden kann, stelle sicher, dass er sicher und umweltgerecht entsorgt wird.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zu diesem Produkt, wende dich bitte an den Hersteller oder den Verkäufer. Sie stehen dir für alle sicherheitsrelevanten Anfragen zur Verfügung.

Bitte beachte, dass diese Sicherheitshinweise im Einklang mit den EUVorgaben für Produktsicherheit stehen. Bei Fragen oder Bedenken bezüglich der Sicherheit des Produkts, zögere nicht, die entsprechenden Stellen zu kontaktieren.

HILL COUNTRY II RIFLE CASE SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Hill Country II Rifle Case. This product is designed to provide safe and effective protection for your firearm. Please read this safety instruction guide carefully to ensure proper use and maintenance of the rifle case, in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the rifle case is used only for its intended purpose: to store and transport firearms safely.
- Always check the case for any damage or wear before use. Do not use if damaged.
- Keep the rifle case out of reach of children and vulnerable individuals to prevent accidents.
- Regularly inspect the storage pockets for any items that may pose a risk when handling the case.
- Follow all local laws and regulations regarding firearm storage and transportation.

Specific Safety Precautions for Use

- When loading or unloading your firearm into the case, ensure that the firearm is unloaded and the safety is engaged.
- Store firearms in a secure location when not in use, even when inside the case.
- Avoid exposing the case to extreme temperatures or moisture, as this may compromise its integrity and protection capabilities.
- Do not overload the storage pockets, as this may affect the balance and handling of the case.
- Use the webbing straps and carry handle properly to prevent dropping or mishandling the case.

Instructions for Installation and Usage

1. Preparation:

- Ensure the rifle is unloaded and safe before placing it into the case.
- Open the zipper completely to allow for easy access.

2. Loading Your Firearm:

- Place the firearm gently into the case, ensuring it fits securely within the padded interior.
- If using a scoped rifle, ensure that it fits comfortably without putting pressure on the scope.

3. Securing Your Firearm:

- Close the zipper carefully, ensuring that the zipper is fully engaged to prevent accidental opening.
- Use the oversized zipper loop pulls for ease of handling.

4. Using Storage Pockets:

- Utilize the two large front gusseted zippered pockets for storing necessary accessories such as ammunition, cleaning kits, and other gear.
- Ensure that items stored in the pockets do not interfere with the firearm or compromise safety.

5. Carrying the Case:

- Use the padded handle wrap for comfort during transport.
- If using the webbing straps, adjust them as needed for a secure grip.

Disposal Instructions

When it comes time to dispose of your rifle case, please consider the following:

- If the case is damaged beyond repair, check local regulations for proper disposal methods.
- Recycle materials when possible. The case may contain recyclable components such as polyester fabric.
- Do not burn the case, as it may release harmful chemicals.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Hill Country II Rifle Case, please refer to the product packaging or the manufacturer's website for contact details. It is important to ensure that you are receiving information from official sources.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Hill Country II Rifle Case. Thank you for your attention to these important guidelines.