

HILL COUNTRY II RIFLE CASE - HILL COUNTRY II 54" RIFLE CASE GREEN/WALNUT

HILL COUNTRY II RIFLE CASE Whether you're gearing up for hunting season or looking for a premium gun case for your newest firearm, you'll want to check out the features in the Hill Country II Series Gun Case. Constructed of extremely rugged 1680D, a dense heavy gauge foam & finished with a plush debossed fleece lining, our cases provide great protection from dust, bumps & scratches. It has 1.5 in. webbing straps and a durable carry handle for easy carry when hunting outdoors. It also has plenty of storage with 2 large front gusseted zippered pockets for all those necessary accessories. FEATURES: Extremely Rugged 1680D Construction Dense Heavy Gauge Interior Foam Padding Plush Debossed Fleece Interior Lining Reinforced Bar Tack Stitching on Handles 2 Large Front Gusseted Storage Pockets Reversed Zipper Provides a Clean Look Oversized Zipper Loop Pulls Oversized 1.5" Webbing Straps with Padded Handle Wrap Tall Profile Fits Scoped Rifles SPECIFICATIONS: Color: Green/Walnut Length: 48" inches (46in inch inner length)



Attributes

- Name: HILL COUNTRY II 54" RIFLE CASE GREEN/WALNUT
- Manufacturer: EVOLUTION OUTDOOR, LLC
- Product no.: 430112385
- Mfr. No.: 44384-EV
- Color: Green/Walnut
- Material: Polyester
- Size: 54
- Style: Rifle
- Delivery weight: 0.998kg
- Shipping height: 13mm
- Shipping width: 292mm
- Shipping length: 1,372mm
- UPC: 814640027163

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den HILL COUNTRY II RIFLE CASE](#)
- [English: HILL COUNTRY II RIFLE CASE Safety Instruction Guide](#)

Sicherheitshinweise für den HILL COUNTRY II RIFLE CASE

Einführung

Vielen Dank, dass du dich für den HILL COUNTRY II RIFLE CASE von EVOLUTION OUTDOOR, LLC entschieden hast. Dieser Gewehrkoffer bietet hervorragenden Schutz und ist ideal für die Jagd oder die sichere Aufbewahrung deines Gewehrs. Um sicherzustellen, dass du den Koffer sicher und effektiv nutzt, bitten wir dich, die folgenden Sicherheitshinweise zu beachten.

Allgemeine Sicherheitsrichtlinien

- Stelle sicher, dass der Gewehrkoffer für die Größe und das Gewicht deines Gewehrs geeignet ist.
- Vermeide es, den Koffer über längere Zeit direkter Sonneneinstrahlung oder extremen Temperaturen auszusetzen.
- Halte den Koffer außerhalb der Reichweite von Kindern und Haustieren.
- Überprüfe regelmäßig den Zustand des Koffers auf Risse, Löcher oder andere Beschädigungen.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwende den Koffer nur für die Aufbewahrung von Gewehren und zugehörigem Zubehör.
- Stelle sicher, dass das Gewehr sicher im Koffer verstaut ist, um Bewegungen während des Transports zu vermeiden.
- Achte darauf, dass alle Reißverschlüsse und Taschen ordnungsgemäß geschlossen sind, bevor du den Koffer transportierst.
- Bei der Verwendung im Freien achte darauf, dass der Koffer vor Nässe und Schmutz geschützt ist.

Anweisungen für Installation und Nutzung

- **Öffnen des Koffers:** Ziehe vorsichtig am Reißverschluss, um den Koffer zu öffnen. Achte darauf, dass der Reißverschluss nicht klemmt.
- **Einlegen des Gewehrs:** Platziere das Gewehr vorsichtig im Innenraum des Koffers. Stelle sicher, dass es richtig sitzt und nicht wackelt.
- **Sichern des Gewehrs:** Schließe den Koffer und ziehe den Reißverschluss vollständig zu. Überprüfe, ob alle Taschen und Fächer sicher verschlossen sind.
- **Transport:** Nutze die gepolsterten Tragegriffe oder die Gurtbänder für den Transport. Stelle sicher, dass der Koffer gut in der Hand liegt.

Entsorgungsanweisungen

- Entsorge den Koffer gemäß den örtlichen Vorschriften für Kunststoff und Textilabfälle.
- Recycling ist empfohlen, wo möglich. Informiere dich über die entsprechenden Recyclingstellen in deiner Nähe.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Sicherheitsrichtlinien und zur Nutzung des HILL COUNTRY II RIFLE CASE, wende dich bitte an den Kundenservice von EVOLUTION OUTDOOR, LLC.

Bitte beachte diese Sicherheitshinweise, um eine sichere Nutzung deines HILL COUNTRY II RIFLE CASE zu gewährleisten. Dein Schutz und deine Sicherheit stehen an erster Stelle!

HILL COUNTRY II RIFLE CASE Safety Instruction Guide

Introduction

Thank you for choosing the HILL COUNTRY II Rifle Case. This guide provides essential safety instructions to ensure the safe use and storage of your rifle case. Please read and follow these guidelines carefully to protect yourself and your firearm.

General Safety Guidelines

- Ensure that the rifle case is used only for its intended purpose—storing and carrying firearms.
- Always keep the case away from children and vulnerable individuals to prevent accidents.
- Regularly inspect the case for any signs of wear or damage. If the case is damaged, discontinue use immediately.
- Store the rifle case in a dry, cool place to prevent damage from moisture or extreme temperatures.
- Be aware of your surroundings when using the rifle case outdoors, especially in hunting scenarios.

Specific Safety Precautions for Use

- Always ensure that your firearm is unloaded before placing it in the case.
- Use the webbing straps and carry handle properly to avoid dropping the case and potentially damaging the firearm.
- Do not overload the storage pockets to maintain the integrity and balance of the case.
- Avoid placing sharp objects in the case that could puncture or damage the interior lining.
- Keep the case closed and secured when not in use to prevent accidental access.

Instructions for Installation and Usage

1. Unpacking the Case

- Carefully remove the rifle case from its packaging.
- Inspect the case for any damage or defects before use.

2. Loading the Rifle

- Ensure the firearm is completely unloaded.
- Open the case and place the firearm inside, ensuring it fits securely.
- Close the case and ensure that all zippers are fully zipped to secure the firearm.

3. Using the Storage Pockets

- Utilize the two large front gusseted zippered pockets for storing accessories.
- Ensure that items stored in the pockets do not exceed the weight limit for safe carrying.

4. Carrying the Case

- Use the padded handle wrap for comfort when carrying the case.
- Utilize the oversized webbing straps for additional support during transport.

5. Cleaning and Maintenance

- Regularly clean the exterior of the case with a damp cloth.
- Avoid using harsh chemicals or solvents that could damage the materials.

Disposal Instructions

- When the rifle case reaches the end of its life cycle, dispose of it responsibly.
- Check local regulations for proper disposal methods of textile and plastic materials.
- Do not burn the case, as it may release harmful substances.

Contact Information for Further Support

For safety inquiries or support related to your HILL COUNTRY II Rifle Case, please reach out to the designated contact point provided with your purchase. Ensure you have the product details ready for assistance.

Conclusion

By following these safety guidelines and instructions, you can ensure the safe use and longevity of your HILL COUNTRY II Rifle Case. Always prioritize safety when handling firearms and related accessories. Thank you for your attention to these important safety measures.