

ZERO S-SERIES SIZING DIES - AREA 419 ZERO S-SERIES 7MM PRC SIZING DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

ZERO S-SERIES SIZING DIES Following the resounding success of our M-Series Sizing Die, the mission became to take as many of those industry-leading features as possible and push them into a traditional 7/8" die, keeping the price point under \$300. Introducing the ZERO S-Series Sizing Die. KEY FEATURES Precision Ground Expander Mandrels (all dies ship with a .002 neck tension mandrel, or add more increments with our MANDREL KIT) Full-Length Neck to Extractor Sizing Spring Ejection for Spent Primers Replaceable Steel Decap Pins Reamer Cut to Exacting Dimensions for a TRUE Size (no more sticky bolt after the second firing) Hydraulic Shoulder Pressure Relief 100% Made in AMERICA NOTE: This is for a Die-Only. These dies do not come with a shellholder. They are compatible with common shellholders from Redding, Hornady, RCBS, etc. They are also compatible with our ZERO Modular Shellholder System All dies ship with an Area 419 ZERO Universal Die Ring, a spare decapping pin and necessary install/removal tools. After testing them all, and finding everything Area 419 like and didn't like, and working with thousands of customers and a variety of industry partners, they believe this is what a 7/8" sizing die should be.



Attributes

- Name: [AREA 419 ZERO S-SERIES 7MM PRC SIZING DIE](#)
- Manufacturer: [AREA 419](#)
- Product no.: 430112756
- Mfr. No.: 419-ZERODIE-S7PRC
- Cartridge: 7mm PRC
- Die Style: Sizing Dies
- Delivery weight: 0.907kg
- Shipping height: 76mm
- Shipping width: 114mm
- Shipping length: 165mm
- UPC: 810080183223

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [ZERO SSeries Sizing Die Safety Instruction Guide](#)
- [About Us](#)

ZERO SSeries Sizing Die Safety Instruction Guide

Introduction

Thank you for choosing the ZERO SSeries Sizing Die. This guide provides important safety information and instructions for the proper use and care of your die. Please read this guide carefully to ensure safe and effective usage.

General Safety Guidelines

- Always follow the manufacturer's instructions for use and maintenance.
- Ensure that the die is used in a wellventilated area to prevent inhalation of any dust or debris.
- Keep the die and all related tools out of reach of children and vulnerable individuals.
- Inspect the die regularly for any signs of damage or wear. Do not use a damaged die.
- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves during operation.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- **Cartridge Safety:** Always ensure that the cartridge you are using is compatible with the ZERO SSeries Sizing Die.
- **Neck Tension:** The die includes a .002 neck tension mandrel. Ensure that this is correctly installed before use.
- **Ejection of Spent Primers:** Be cautious when using the spring ejection feature for spent primers. Ensure that your hands are clear of the ejection area.
- **Hydraulic Shoulder Pressure Relief:** Understand how to use the hydraulic shoulder pressure relief feature correctly to avoid injury.
- **Replacement of Decap Pins:** Only use replaceable steel decap pins provided by the manufacturer to maintain safety and compatibility.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable before installation.
- Remove any existing dies from the press.
- Insert the ZERO SSeries Sizing Die into the press and tighten securely.
- Attach the Area 419 ZERO Universal Die Ring according to the manufacturer's instructions.

2. Usage:

- Set the die to the appropriate height for your specific cartridge.
- Insert the cartridge case into the shellholder.
- Operate the press smoothly, applying even pressure to resize the cartridge.
- After resizing, check the cartridge for proper fit and function.
- Eject the spent primer using the spring ejection feature, ensuring your hands are clear.

3. Maintenance:

- Clean the die regularly to remove any debris or residue.
- Store the die in a dry place when not in use.
- Check the decap pin and mandrel for wear and replace as necessary.

Disposal Instructions

- Dispose of the ZERO SSeries Sizing Die according to local regulations.
- Do not dispose of the die in regular household waste if it is damaged or broken.
- Contact local recycling centers for proper disposal methods for metal components.

Contact Information for Further Support

For any questions or concerns regarding the ZERO SSeries Sizing Die, please refer to the manufacturer's website or customer support for assistance.

By following these safety instructions, you can ensure a safe and effective reloading experience with your ZERO SSeries Sizing Die. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk