

SHOTSYNC WEARABLE SHOT TIMER - WALKERS GAME EAR

SHOTSYNC WEARABLE SHOT TIMER BLACK

WALKER'S SHOTSYNC WEARABLE SHOT TIMER For over 25 years Walker's has developed innovative solutions for hearing protection & enhancement. The Walker's line of products is widely considered the industry standard for shooting protection and safety. FEATURES: Counts Shots Based on Recoil as well as Sound? Microphone? Accelerometer? Par Setting? Bluetooth (Ble) Connectivity (5.2)? Countdown Timer? Multiple Firearm Options? Sampling Frequency Of 1.6Khz? 5.5 Hr. Battery Life (Battery On & Recording)? 60-70 Min Recharge Time? Compatible With Walker's App?? SPECIFICATIONS: Color: Black Manufacturer: Walker's Manufacturer Part #: GWP-ACCEL Model: SHOTSYNC Type: Shot Timer

NO IMAGE
AVAILABLE

Attributes

- Name: WALKERS GAME EAR SHOTSYNC WEARABLE SHOT TIMER BLACK
- Manufacturer: WALKERS GAME EAR
- Product no.: 430114054
- Mfr. No.: GWP-ACCEL
- Colour: Black
- Style: Timer
- Delivery weight: 0.44kg
- Shipping height: 150mm
- Shipping width: 150mm
- Shipping length: 100mm
- UPC: 888151084823

Table of Contents

- [Startpage](#)
- English: [SHOTSYNC WEARABLE SHOT TIMER USER MANUAL](#)

SHOTSYNC WEARABLE SHOT TIMER USER MANUAL

Introduction

Thank you for choosing the Walker's SHOTSYNC Wearable Shot Timer. This innovative product is designed to enhance your shooting experience while ensuring safety and performance. Please read this manual carefully to understand how to use the device safely and effectively.

General Safety Guidelines

To ensure the safe use of the SHOTSYNC Wearable Shot Timer, please adhere to the following guidelines:

- Always follow local laws and regulations regarding the use of shooting equipment.
- Ensure that the device is used in a safe environment, away from unauthorized individuals, especially children.
- Regularly inspect the device for any signs of damage or malfunction before use.
- Do not expose the device to extreme temperatures, moisture, or direct sunlight for prolonged periods.
- If you notice any unusual behavior or performance issues with the device, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

When using the SHOTSYNC Wearable Shot Timer, please observe the following precautions:

- **Hearing Protection:** Always wear appropriate hearing protection when using firearms, even when using the SHOTSYNC device.
- **Recoil Awareness:** Be aware that the device counts shots based on recoil as well as sound. Ensure that your firearm is in proper working condition to avoid miscounts.
- **Bluetooth Connectivity:** When using Bluetooth features, ensure that you are in a secure environment to protect your personal data.
- **Age Restrictions:** This product is not intended for use by children. Keep it out of reach of minors.
- **Battery Safety:** Do not attempt to open the battery compartment. If the device shows signs of battery leakage, do not handle it and contact a professional.

Instructions for Installation and Usage

To install and use your SHOTSYNC Wearable Shot Timer, follow these steps:

1. Charging the Device:

- Connect the device to a power source using the provided charging cable.
- Allow the device to charge for approximately 6070 minutes until fully charged.
- A full charge provides approximately 5.5 hours of battery life during use.

2. Connecting to the Walker's App:

- Download the Walker's App from your device's app store.
- Open the app and follow the onscreen instructions to pair your SHOTSYNC device via Bluetooth (BLE 5.2).
- Ensure that Bluetooth is enabled on your mobile device.

3. Setting Up the Shot Timer:

- Once connected, configure the shot timer settings according to your preferences within the app.
- Select the appropriate firearm option and set the par time as needed.

4. Using the Shot Timer:

- Wear the device securely on your wrist or clothing.
- Ensure the microphone and accelerometer are unobstructed for accurate shot counting.
- Begin your shooting session, and the device will automatically count shots based on recoil and sound.

5. Countdown Timer:

- Utilize the countdown timer feature for training and practice sessions.
- Set your desired countdown duration within the app.

Disposal Instructions

Proper disposal of the SHOTSYNC Wearable Shot Timer is essential to minimize environmental impact. Follow these guidelines:

- Dispose of the device in accordance with local electronic waste disposal regulations.
- Remove the battery if applicable and dispose of it separately according to battery recycling guidelines.
- Do not dispose of the device in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the SHOTSYNC Wearable Shot Timer, please refer to the manufacturer's website or customer service for assistance. Ensure you have your product details ready for a more efficient response.

Thank you for choosing the SHOTSYNC Wearable Shot Timer. Enjoy your shooting experience safely!