

RIFLE PRECISION MICROMETER BULLET SEATING DIES - LEE PRECISION 6MM ARC RIFLE PRECISION MICROMETER BULLET SEATING DIE

LEE PRECISION RIFLE PRECISION MICROMETER BULLET SEATING DIES

Introducing the new Precision Micrometer bullet seating die. Features dead length bullet seating with smooth, accurate adjustment. Tests prove sliding bullet guide provides cartridges with the least bullet runout. When used as a dead length bullet seating die, the body contacts the shell holder assuring precise uniform seating depth. FEATURES Laser engraved micrometer thimble and body is easy to read with divisions representing one thousandth of an inch, reads just like a precision depth micrometer. Infinitely adjustable, providing precision bullet seating depth. Bullet seating stem is machined and burnished to seat nearly any point style bullet without damage or marking. The case mouth and bullet are held in perfect alignment by a floating bullet guide. The bullet guide is provided with radial clearance to allow the case and bullet guide to align perfectly with the bullet seater screw. The floating bullet guide is reversible, simply unthread guide and re-install to allow seating and crimping simultaneously, an exclusive feature to Lee. This bullet seating die proves accuracy doesn't have to cost a lot.



Attributes

- Name: LEE PRECISION 6MM ARC RIFLE PRECISION MICROMETER BULLET SEATING DIE
- Manufacturer: LEE PRECISION
- Product no.: 430114517
- Mfr. No.: 92233
- Cartridge: 6 mm ARC
- Die Style: Bullet Seating Die
- Delivery weight: 0.276kg
- Shipping height: 117mm
- Shipping width: 36mm
- Shipping length: 148mm
- UPC: 734307922337

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for RIFLE PRECISION MICROMETER BULLET SEATING DIES](#)

Safety Instruction Guide for RIFLE PRECISION MICROMETER BULLET SEATING DIES

Introduction

Thank you for choosing the RIFLE PRECISION MICROMETER BULLET SEATING DIES by LEE PRECISION. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read these guidelines carefully before using the product to avoid any hazards and to ensure compliance with EU safety regulations.

General Safety Guidelines

- **Product Safety:** The RIFLE PRECISION MICROMETER BULLET SEATING DIES are designed for safe use. Always follow the instructions provided to minimize risks.
- **Enhanced Recalls:** Stay informed about product recalls. Register your product to receive timely information about any safety issues.
- **Online Shopping Safety:** If purchased online, ensure that the seller complies with EU safety standards.
- **Special Consumer Focus:** This product is not intended for use by children. Keep out of reach of minors.
- **EU Contact Point:** For safety inquiries related to this product, please refer to the manufacturer's contact information provided with your purchase.
- **Rapid Alerts:** Monitor the EU Safety Gate platform for updates on product safety and recalls.

Specific Safety Precautions for Use

- **Read the Manual:** Always read the instruction manual thoroughly before use.
- **Inspect the Product:** Before each use, inspect the die for any signs of damage or wear. Do not use if damaged.
- **Use Proper Equipment:** Ensure that you are using compatible reloading equipment with the bullet seating die.
- **Wear Safety Gear:** Always wear appropriate safety gear, including eye protection and gloves, when using this product.
- **Work in a Safe Environment:** Ensure that your workspace is clean, welllit, and free from distractions.
- **Handle with Care:** Use caution when handling the die and bullets to avoid injury.
- **Follow Load Data:** Always refer to reliable loading data and guidelines specific to the 6 mm ARC cartridge.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is securely mounted and stable.
- Carefully insert the bullet seating die into the reloading press according to the manufacturer's instructions.
- Adjust the die to the desired seating depth using the micrometer thimble for precision.

2. Usage:

- Prepare your cases and bullets according to standard reloading practices.
- Place a prepared case in the shell holder of your reloading press.
- Insert the bullet into the case mouth.
- Activate the press to seat the bullet. Ensure that the bullet guide aligns the bullet and case properly.
- Check the seating depth using the micrometer scale and make adjustments as necessary.

- After seating, inspect the finished cartridge for proper bullet depth and alignment.

Disposal Instructions

- **Product Disposal:** When the product reaches the end of its useful life, dispose of it in accordance with local regulations regarding metal and plastic waste.
- **Environmental Considerations:** Do not dispose of the product in regular household waste. Check for recycling options to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the RIFLE PRECISION MICROMETER BULLET SEATING DIES, please refer to the manufacturer's contact information provided with your purchase.

By following these safety instructions, you can ensure a safe and effective experience with your RIFLE PRECISION MICROMETER BULLET SEATING DIES. Always prioritize safety and stay informed about best practices in reloading.