

RIFLE PRECISION MICROMETER BULLET SEATING DIES - LEE PRECISION 8.6 BLACKOUT RIFLE PRECISION MICROMETER BULLET SEATING DIE

LEE PRECISION RIFLE PRECISION MICROMETER BULLET SEATING DIES

Introducing the new Precision Micrometer bullet seating die. Features dead length bullet seating with smooth, accurate adjustment. Tests prove sliding bullet guide provides cartridges with the least bullet runout. When used as a dead length bullet seating die, the body contacts the shell holder assuring precise uniform seating depth. FEATURES Laser engraved micrometer thimble and body is easy to read with divisions representing one thousandth of an inch, reads just like a precision depth micrometer. Infinitely adjustable, providing precision bullet seating depth. Bullet seating stem is machined and burnished to seat nearly any point style bullet without damage or marking. The case mouth and bullet are held in perfect alignment by a floating bullet guide. The bullet guide is provided with radial clearance to allow the case and bullet guide to align perfectly with the bullet seater screw. The floating bullet guide is reversible, simply unthread guide and re-install to allow seating and crimping simultaneously, an exclusive feature to Lee. This bullet seating die proves accuracy doesn't have to cost a lot.



Attributes

- Name: LEE PRECISION 8.6 BLACKOUT RIFLE PRECISION MICROMETER BULLET SEATING DIE
- Manufacturer: LEE PRECISION
- Product no.: 430114526
- Mfr. No.: 92237
- Cartridge: 8.6 Blackout
- Die Style: Bullet Seating Die
- Delivery weight: 0.282kg
- Shipping height: 117mm
- Shipping width: 36mm
- Shipping length: 148mm
- UPC: 734307922375

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for RIFLE PRECISION MICROMETER BULLET SEATING DIES](#)

Safety Instruction Guide for RIFLE PRECISION MICROMETER BULLET SEATING DIES

Introduction

Thank you for choosing the RIFLE PRECISION MICROMETER BULLET SEATING DIES by LEE PRECISION. This product is designed to provide precision and accuracy in bullet seating. However, it is essential to follow safety guidelines to ensure safe and effective use. This guide outlines important safety instructions, precautions, and recommendations for the proper handling of this product.

General Safety Guidelines

- Ensure you are familiar with all components of the bullet seating die before use.
- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading equipment.
- Keep the workspace clean and organized to prevent accidents.
- Ensure that all tools and equipment are in good working condition before use.
- Store all components, including the bullet seating die, in a secure location away from children and pets.
- Follow local laws and regulations regarding the use and storage of reloading equipment.

Specific Safety Precautions for Use

- Use only the recommended cartridge type, which in this case is 8.6 Blackout, to ensure compatibility and safety.
- Ensure that the die is securely mounted to the reloading press before use to prevent movement during operation.
- Avoid overtightening the die, as this may cause damage to the equipment or affect performance.
- Do not attempt to modify or alter the die in any way, as this may lead to unsafe conditions.
- Always check the bullet seating depth before loading cartridges to avoid dangerous overseating.
- Never use damaged or worn components; replace them immediately to maintain safety.
- Be cautious of the potential for lead exposure when handling bullets; wash hands thoroughly after use.

Instructions for Installation and Usage

1. Installation:

- Unpack the bullet seating die and ensure all components are included.
- Securely attach the die to the reloading press, following the manufacturer's instructions.
- Make sure the die is aligned correctly to ensure accurate bullet seating.

2. Usage:

- Insert the case into the shell holder and ensure it is properly positioned.
- Adjust the micrometer thimble to the desired bullet seating depth, using the engraved divisions for precision.
- Place the bullet into the case mouth and gently lower the bullet seating stem onto the bullet.
- Apply steady pressure to seat the bullet to the desired depth, ensuring the bullet guide aligns correctly.
- After seating, check the cartridge for proper seating depth before proceeding to crimping or loading.

Disposal Instructions

- Dispose of any unused or damaged components in accordance with local regulations for hazardous materials.
- Recycle packaging materials where possible to minimize environmental impact.
- Ensure that all lead components are disposed of properly to prevent environmental contamination.

Contact Information for Further Support

For any questions or concerns regarding the RIFLE PRECISION MICROMETER BULLET SEATING DIES, please refer to the manufacturer's website or customer service for assistance. It is important to stay informed about product recalls or safety updates by checking official sources regularly.

By following these safety guidelines and instructions, you can ensure a safe and effective reloading experience with the RIFLE PRECISION MICROMETER BULLET SEATING DIES. Thank you for prioritizing safety and enjoying your reloading activities responsibly.