

RF-M 7x25 Rangefinder

[Optics & Mounting](#) > [Rangefinders](#)

Kahles RF-M 7x25 Entfernungsmesser



Attributes

- Name: [Kahles RF-M 7x25 Rangefinder](#)
- Manufacturer: [KAHLES](#)
- Product no.: EU0000170
- Mfr. No.: 20034
- Delivery weight: 214g
- Shipping height: 78mm
- Shipping width: 37mm
- Shipping length: 102mm

Item details

This product is excluded from discount promotions.

Table of Contents

- Startpage
- Safety Instruction Guide for Kahles RFM 7x25 Rangefinder
- About Us

Safety Instruction Guide for Kahles RFM 7x25 Rangefinder

Introduction

Thank you for choosing the Kahles RFM 7x25 Rangefinder. This guide provides essential safety instructions to ensure the safe use of your rangefinder. Please read this guide carefully before using the product to familiarize yourself with its features and safety precautions.

General Safety Guidelines

- Ensure that the rangefinder is used only for its intended purpose.
- Keep the rangefinder out of reach of children and vulnerable individuals.
- Regularly inspect the device for any signs of damage or wear.
- Do not attempt to repair the rangefinder yourself. Seek professional assistance if needed.
- Follow all local regulations regarding the use of rangefinders in your area.

Specific Safety Precautions for Use

- Do not point the rangefinder directly at the sun or any other intense light source, as this may damage the device and impair vision.
- Avoid using the rangefinder in extreme weather conditions, such as heavy rain or snow, to prevent water damage.
- Use the rangefinder in accordance with the manufacturer's guidelines to avoid operational hazards.
- Do not expose the device to strong impacts or drops, as this may cause internal damage.

Instructions for Installation and Usage

1. Battery Installation

- Open the battery compartment located on the side of the rangefinder.
- Insert the battery according to the polarity markings (+ and -) inside the compartment.
- Close the battery compartment securely.

2. Powering On the Device

- Press the power button to turn on the rangefinder.
- Wait for the display to initialize before use.

3. Using the Rangefinder

- Aim the rangefinder at the target object.
- Press the measurement button to obtain the distance reading.
- The distance will be displayed on the screen. Ensure that you have a clear line of sight to the target for accurate measurements.

4. Powering Off the Device

- Press the power button again to turn off the rangefinder when not in use.
- Remove the battery if the device will not be used for an extended period.

Disposal Instructions

- Dispose of the rangefinder and its components in accordance with local regulations.
- Do not dispose of electronic devices in regular household waste.
- Take the device to an authorized recycling center for proper disposal.
- Remove batteries before disposal and recycle them according to local guidelines.

Contact Information for Further Support

For any inquiries regarding the safety or functionality of your Kahles RFM 7x25 Rangefinder, please refer to the manufacturer's website or customer support channels.

Please remember to stay informed about potential recalls or safety notices for your product. You can check the EU's Safety Gate platform for updates on product safety. Thank you for your attention to these important safety instructions, and enjoy using your Kahles RFM 7x25 Rangefinder responsibly.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at