

AR-15 ULTRAMATCH - CAL. 223 REM. - Schmeisser AR-15 Ultramatch STS - 24" - cal. .223 Rem

The Schmeisser AR15 Ultramatch is a precision rifle with a match barrel and an integrated spare magazine in the stock. This rifle has a .936 free-swinging match barrel, a slim M-Lok handguard and a adjustable gas block made of steel. The Two-Stage trigger guarantees a clearly defined dry trigger. The safety selector, magazine trigger, charging handle and bolt catch are designed for ambidextrous use. Standard delivery with a 10 round magazine.

NO IMAGE
AVAILABLE

- NAME: AR15 Ultramatch 20" STS
- SYSTEM: Semi-automatic rifle
- CALIBER: .223 Rem.
- WEIGHT: 4.200 g
- LENGTH: 107 cm
- BARREL: 61 cm
- TWIST: 1:8
- MAGAZINE: 10 rds

Attributes

- Name: Schmeisser AR-15 Ultramatch STS - 24" - cal. .223 Rem
- Manufacturer: SCHMEISSER
- Product no.: EU2004559
- Mfr. No.: 03-0131M
- Action Type: Semi-Auto
- Barrel Length: 24"
- Caliber: 22 Caliber (.223)
- Cartridge: 223 Remington
- Color: Black
- Handguard: Rifle
- Make: AR-15
- Model: AR-15
- Style: M-LOK
- Twist: 1-8
- EAN: 4251366502158

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Schmeisser AR15 Ultramatch Kal. .223 Rem](#)
- [English: Safety Instructions for Schmeisser AR15 Ultramatch Cal. .223 Rem](#)

Sicherheitshinweise für die Schmeisser AR15 Ultramatch Kal. .223 Rem

Einleitung

Herzlichen Glückwunsch zum Erwerb der Schmeisser AR15 Ultramatch! Diese Präzisionswaffe ist speziell für den anspruchsvollen Schützen konzipiert. Um die Sicherheit bei der Verwendung dieses Produkts zu gewährleisten, ist es wichtig, die folgenden Sicherheitsrichtlinien und Gebrauchsanweisungen zu beachten.

Allgemeine Sicherheitsrichtlinien

- Achte darauf, dass du die Waffe immer als geladen betrachtest, auch wenn du glaubst, dass sie entladen ist.
- Halte den Abzug immer von der Waffe fern, bis du bereit bist zu schießen.
- Richte die Waffe niemals auf etwas, das du nicht treffen möchtest.
- Verwende die Waffe nur auf zugelassenen Schießständen oder in sicheren, kontrollierten Umgebungen.
- Halte die Waffe außerhalb der Reichweite von Kindern und unbefugten Personen.
- Überprüfe regelmäßig die Waffe auf Verschleiß und Beschädigungen.

Spezifische Sicherheitsvorkehrungen für die Benutzung

- Verwende ausschließlich Munition im Kaliber .223 Remington.
- Achte darauf, dass der Lauf frei von Verunreinigungen ist, bevor du die Waffe lädst.
- Verwende beim Schießen geeignete Schutzbrillen und Gehörschutz.
- Stelle sicher, dass du die Waffe sicher und stabil hältst, um Rückstoß zu kontrollieren.
- Lese und verstehe die Bedienungsanleitung, bevor du die Waffe benutzt.
- Bei Fehlfunktionen oder Blockaden, versuche nicht, die Waffe selbst zu reparieren. Suche professionelle Hilfe.

Anweisungen für Installation und Nutzung

- Stelle sicher, dass die Waffe entladen ist, bevor du mit der Installation von Zubehör oder der Wartung beginnst.
- Um das Magazin zu laden, drücke den Magazinauslöser und entferne das Magazin. Lade die Munition ein und setze das Magazin wieder ein, bis es einrastet.
- Um die Waffe zu entladen, ziehe den Durchladehebel zurück, um eine Patronenlagerung zu prüfen, und drücke den Magazinauslöser, um das Magazin zu entfernen.
- Stelle den verstellbaren Stahlgasblock gemäß der Bedienungsanleitung ein, um die Leistung der Waffe zu optimieren.
- Die Waffe sollte immer in einem sicheren Zustand gelagert werden, wenn sie nicht in Gebrauch ist. Verwende einen Waffenschränk oder ein ähnliches Sicherheitssystem.

Entsorgungsanweisungen

- Entsorge leere Patronenhülsen und Munition gemäß den örtlichen Vorschriften.
- Die Waffe selbst sollte nicht als gewöhnlicher Abfall entsorgt werden. Wende dich an einen autorisierten Fachhändler oder eine Fachwerkstatt für die sichere Entsorgung.
- Halte dich an alle gesetzlichen Bestimmungen zur Entsorgung von Waffen und Munition in deinem Land.

Kontaktinformationen für weitere Unterstützung

- Für Sicherheitsanfragen oder weitere Informationen zu diesem Produkt, wende dich bitte an den Hersteller oder den Händler, bei dem du die Waffe erworben hast.

Bitte beachte, dass diese Sicherheitsrichtlinien dazu dienen, dich und andere zu schützen. Halte dich stets an die geltenden Gesetze und Vorschriften in deinem Land.

Safety Instructions for Schmeisser AR15 Ultramatch Cal. .223 Rem

Introduction

Thank you for choosing the Schmeisser AR15 Ultramatch. This precision rifle is designed for optimal performance and safety. Please read this safety instruction guide thoroughly to ensure safe handling and use in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Store the firearm securely and out of reach of children and unauthorized users.
- Use only the recommended caliber and ammunition specified for this firearm.
- Ensure that the firearm is clean and wellmaintained before use.
- Always wear appropriate eye and ear protection when operating the firearm.
- Be aware of your surroundings and ensure you have a clear line of sight and a safe backstop before firing.
- Do not consume alcohol or drugs before or while handling the firearm.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- **Age Restrictions:** This firearm is intended for use by individuals aged 18 and older. Ensure that younger individuals are supervised by a qualified adult.
- **Handling:** Always keep your finger off the trigger until you are ready to shoot.
- **Loading and Unloading:** Follow proper procedures for loading and unloading the firearm. Always check the chamber visually and physically to confirm it is empty.
- **Malfunctions:** In case of a malfunction, keep the firearm pointed in a safe direction and wait at least 30 seconds before attempting to clear the jam.
- **Transportation:** When transporting the firearm, ensure it is unloaded and securely stored in a suitable case.
- **Cleaning:** Follow the manufacturer's guidelines for cleaning and maintenance. Use appropriate tools and solvents.

Instructions for Installation and Usage

1. Installation of Accessories:

- Ensure the firearm is unloaded before installing any accessories.
- Follow the specific manufacturer's instructions for any accessories you wish to install.

2. Usage:

- Before firing, familiarize yourself with the controls of the firearm, including the safety selector, magazine trigger, charging handle, and bolt catch.
- Adjust the gas block as needed to optimize performance for different ammunition types.
- When ready to fire, assume a stable shooting position and align your sights on the target.
- Squeeze the trigger gently to fire, maintaining a firm grip on the firearm.

Disposal Instructions

- Dispose of the firearm in accordance with local laws and regulations regarding firearms disposal.
- Do not dispose of ammunition in regular trash. Contact local authorities or a licensed disposal service for proper disposal methods.
- Ensure that all components, including magazines and accessories, are disposed of safely and responsibly.

Contact Information for Further Support

For any questions or concerns regarding the Schmeisser AR15 Ultramatch, please refer to the product documentation or contact your local dealer for assistance.

Thank you for prioritizing safety and compliance while using the Schmeisser AR15 Ultramatch. Your responsible handling of this firearm contributes to a safer shooting environment for everyone.