

# ClayCopter UFO Charger

[Shooting Accessories](#) > [Targets & Accessories](#) > [Throwers](#)

The Caldwell ClayCopter Target Dispenser keeps targets within easy reach when using handheld ClayCopter launchers. Its simple, user-friendly end caps fit securely over the shipping tubes of any 90mm or 110mm ClayCopter targets. To reload, simply pull a target from the dispensing end cap with your fingers—quick and effortless. An adjustable shoulder strap is included, allowing you to keep both hands free to operate the launcher while ensuring targets are always close at hand for fast, efficient reloads.

NO IMAGE  
AVAILABLE

## Attributes

- Name: [ClayCopter UFO Charger](#)
- Manufacturer: [CALDWELL](#)
- Product no.: EU2016834
- Mfr. No.: 1245169
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 198700005293

# Table of Contents

- [Startpage](#)
- [ClayCopter UFO Charger Safety Instruction Guide](#)
- [About Us](#)

# ClayCopter UFO Charger Safety Instruction Guide

## Introduction

Thank you for choosing the Caldwell ClayCopter Target Dispenser. This product is designed to enhance your shooting experience by keeping targets within easy reach while using handheld ClayCopter launchers. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

## General Safety Guidelines

- Always read the manual and safety instructions before using the product.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any damage before use. Do not use if damaged.
- Use the product only for its intended purpose as described in this guide.
- Ensure that the area around you is clear of obstructions and bystanders before using the launcher.
- Report any unsafe conditions or incidents to the appropriate authorities.

## Specific Safety Precautions for Use

- Ensure that the ClayCopter targets are compatible with your launcher (90mm or 110mm).
- Always wear appropriate eye and ear protection when using the launcher.
- Do not attempt to modify or alter the product in any way.
- Avoid using the product in wet or damp conditions to prevent slipping or malfunction.
- Always secure the shoulder strap properly to prevent accidental drops.
- Do not overload the dispenser with more targets than recommended.

## Instructions for Installation and Usage

### 1. Installation of Targets:

- Remove the end cap from the shipping tube.
- Insert the ClayCopter targets into the tube, ensuring they are aligned properly.
- Securely replace the end cap over the shipping tube.

### 2. Using the Dispenser:

- Adjust the shoulder strap for a comfortable fit.
- Hold the dispenser in one hand and the launcher in the other.
- To reload, pull a target from the dispensing end cap using your fingers.
- Ensure that your fingers are clear of the launcher's path when loading.

### 3. PostUse Care:

- After use, store the dispenser in a dry place away from direct sunlight.
- Regularly check the product for wear and tear, and replace if necessary.

## Disposal Instructions

- Dispose of the product in accordance with local regulations for plastic and electronic waste.
- Do not dispose of the product in household waste.
- If the product is damaged beyond repair, contact your local waste management service for proper disposal methods.

## **Contact Information for Further Support**

For any questions regarding safety or product usage, please refer to the manufacturer's website or customer service for assistance.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the Caldwell ClayCopter Target Dispenser!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)