

ClayCopter Surface-to-Air Pro Kit

[Shooting Accessories](#) > [Targets & Accessories](#) > [Throwers](#)

The Caldwell ClayCopter Surface-to-Air™ Launcher is the most advanced ClayCopter launcher available. Portable and ultra-lightweight at under 10 lbs, it retains the proven features of the original ClayCopter while adding convenient hands-free operation. Powered by the included Caldwell 12-volt Li-Ion battery pack, it delivers up to 300 launches on a single charge.

Packed with advanced functionality, the Surface-to-Air features independently adjustable oscillation and wobble modes, allowing shooters to customize the challenge to their preference. To unlock its full potential, users can connect via Bluetooth and control the launcher with the free Caldwell Clays App from up to 100 yards away. App-enabled features include pairing up to 10 additional Surface-to-Air or Claymore Connect throwers, hands-free voice control, target pair presentations, customizable flurries, and more. Fill the sky with ClayCopter targets using the Surface-to-Air™ Launcher.

NO IMAGE
AVAILABLE

Attributes

- Name: [ClayCopter Surface-to-Air Pro Kit](#)
- Manufacturer: [CALDWELL](#)
- Product no.: EU2016836
- Mfr. No.: 1262976
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 198700005767

Table of Contents

- [Startpage](#)
- [ClayCopter Surface to Air Pro Kit Safety Instructions](#)
- [About Us](#)

ClayCopter SurfacetoAir Pro Kit Safety Instructions

Introduction

Thank you for choosing the Caldwell ClayCopter SurfacetoAir™ Launcher. This safety instruction guide is designed to ensure the safe and effective use of your product. Please read and follow all instructions carefully to prevent accidents and injuries.

General Safety Guidelines

- Always use the ClayCopter launcher in a safe and controlled environment.
- Ensure that all users are aware of and follow safety instructions.
- Keep the launcher out of reach of children and unauthorized users.
- Regularly inspect the launcher for any signs of damage or wear before use.
- Use only the recommended Caldwell 12volt Lilon battery pack for operation.
- Avoid using the launcher in adverse weather conditions, such as high winds or rain.
- Follow local laws and regulations regarding the use of clay target launchers.

Specific Safety Precautions for Use

- Always wear appropriate eye protection when operating the launcher.
- Ensure that the launch area is clear of people, pets, and obstacles before launching.
- Do not place any part of your body in the launch area during operation.
- Be aware of your surroundings and ensure that there is a safe backstop for the launched targets.
- Do not attempt to modify or repair the launcher yourself. Contact a qualified technician for assistance.
- If the launcher malfunctions, stop using it immediately and disconnect the power source.

Instructions for Installation and Usage

1. Setup and Assembly

- Unbox the ClayCopter launcher and all included components.
- Follow the assembly instructions provided in the product manual to set up the launcher.
- Ensure that all parts are securely connected before proceeding.

2. Connecting the Battery

- Locate the Caldwell 12volt Lilon battery pack included with your launcher.
- Connect the battery pack to the launcher according to the instructions in the manual.
- Ensure that the battery is fully charged before first use.

3. Bluetooth Connectivity

- Download the free Caldwell Clays App on your smartphone.
- Enable Bluetooth on your device and follow the app instructions to pair with the launcher.
- Once connected, you can control the launcher from up to 100 yards away.

4. Launching Targets

- Load clay targets into the launcher as per the instructions in the manual.
- Use the app or the manual controls to adjust oscillation and wobble modes to your preference.
- Ensure the launch area is clear before initiating the launch.

5. PostUse Care

- After use, disconnect the battery pack to prevent accidental activation.
- Clean the launcher and store it in a dry place to prolong its lifespan.

Disposal Instructions

- Dispose of the ClayCopter launcher and its components in accordance with local regulations.
- Do not dispose of the Lilon battery in regular household waste. Follow local guidelines for battery disposal or recycling.

Contact Information for Further Support

For any inquiries or concerns regarding the ClayCopter SurfacetoAir™ Launcher, please refer to the contact information provided with your product. Ensure that you have the model number and purchase details ready for assistance.

By following these safety instructions, you can enjoy a safe and fun experience with your ClayCopter SurfacetoAir™ Launcher. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk