

# ClayCopter Ground Stake Target Holder

[Shooting Accessories](#) > [Targets & Accessories](#) > [Throwers](#)

The ClayCopter Ground Stake Target Holder is designed to anchor into the ground, keeping ClayCopter targets within easy reach and providing a convenient place to rest your launcher when not in use. Its two-piece design makes it simple to disassemble for storage or transport and allows a full tube of 50 ClayCopter targets to be placed directly onto the holder while leaving the base in the ground.

Elevated off the ground, it reduces back strain from constantly bending over to reload and helps ensure quick, efficient target access. Add the Caldwell ClayCopter Ground Stake to your range setup for a more comfortable and enjoyable shooting experience.

NO IMAGE  
AVAILABLE

## Attributes

- Name: [ClayCopter Ground Stake Target Holder](#)
- Manufacturer: [CALDWELL](#)
- Product no.: EU2016841
- Mfr. No.: 1243906
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 198700004708

# Table of Contents

- [Startpage](#)
- [ClayCopter Ground Stake Target Holder Safety Instructions](#)
- [About Us](#)

# ClayCopter Ground Stake Target Holder Safety Instructions

## Introduction

Thank you for choosing the ClayCopter Ground Stake Target Holder. This guide provides essential safety instructions and usage guidelines to ensure a safe and enjoyable experience. Please read this manual carefully before using the product.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in the product text.
- Always inspect the product before use for any signs of damage or wear.
- Keep the product out of reach of children and vulnerable individuals when not in use.
- Report any unsafe products or accidents to the relevant authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Do not use the ClayCopter Ground Stake Target Holder in adverse weather conditions, such as high winds or heavy rain.
- Ensure that the ground where you are anchoring the stake is stable and free of debris.
- Avoid placing the holder in areas where it could pose a tripping hazard.
- Always supervise children or inexperienced users when using the product.
- When reloading targets, ensure that the area is clear of people and obstructions.

## Instructions for Installation and Usage

### 1. Installation:

- Choose a suitable location on stable ground for the target holder.
- Firmly insert the ground stake into the ground until it is secure.
- Ensure that the holder is stable and upright before use.

### 2. Using the Holder:

- Place a full tube of 50 ClayCopter targets directly onto the holder.
- When not in use, rest your launcher on the holder for convenience.
- Always check that the targets are securely placed before shooting.

### 3. Disassembly for Storage:

- To disassemble, gently pull the two pieces apart.
- Store the product in a dry place away from direct sunlight and moisture.

## Disposal Instructions

- Dispose of the ClayCopter Ground Stake Target Holder in accordance with local waste disposal regulations.
- Do not dispose of the product in regular household waste if it contains nonbiodegradable materials.
- Check with local authorities for recycling options.

## **Contact Information for Further Support**

For any inquiries regarding safety or product information, please refer to the relevant EUbased contact point or customer service resources provided at the time of purchase.

Thank you for choosing the ClayCopter Ground Stake Target Holder. Your safety and satisfaction are our top priorities. Enjoy your shooting experience!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)