

## Reloading Die Spare Parts - Threaded ring 7/8

Threaded ring 7/8", steel, blued and laser-marked – solid lock ring for precise adjustment of reloading dies in the press, incl. clamp screw. Compatible with dies from Triebel Waffenwerkzeuge.



### Attributes

- Name: Threaded ring 7/8
- Manufacturer: TRIEBEL
- Product no.: EU2017176
- Mfr. No.: 3000030V
- Thread: 7/8
- Delivery weight: 0.03kg
- Shipping height: 40mm
- Shipping width: 10mm
- Shipping length: 40mm
- EAN/UPC: 3000030V

# Table of Contents

- [Startpage](#)
- [English: Reloading Die Spare Parts Threaded Ring 7/8 Safety Instruction Guide](#)

# Reloading Die Spare Parts Threaded Ring 7/8

## Safety Instruction Guide

### Introduction

Thank you for choosing the Reloading Die Spare Parts Threaded Ring 7/8. This product is designed to ensure precise adjustment of reloading dies in your press. To ensure safe and effective usage, please read this safety instruction guide carefully.

### General Safety Guidelines

To promote the safe use of the Reloading Die Spare Parts Threaded Ring 7/8, please adhere to the following guidelines:

- Ensure that the product is used only for its intended purpose.
- Always read and follow the manufacturer's instructions and safety guidelines.
- Inspect the product regularly for signs of wear or damage.
- Keep this product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or incidents to the relevant authorities.
- Stay informed about product recalls through the EU Safety Gate platform.

### Specific Safety Precautions for Use

When using the Reloading Die Spare Parts Threaded Ring 7/8, please observe the following safety precautions:

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading equipment.
- Ensure that the reloading press is securely mounted before installation or adjustment of the threaded ring.
- Do not exceed the manufacturer's recommended torque specifications when tightening the clamp screw.
- Avoid using the threaded ring if it shows signs of damage, such as cracks or deformation.
- Keep hands and body clear of moving parts during operation to prevent injury.

### Instructions for Installation and Usage

Follow these steps for the safe installation and usage of the Reloading Die Spare Parts Threaded Ring 7/8:

#### 1. Preparation:

- Gather all necessary tools and materials, including the threaded ring, clamp screw, and reloading press.
- Ensure that the reloading press is unplugged or turned off.

#### 2. Installation:

- Align the threaded ring with the reloading die.
- Carefully screw the threaded ring into the die until it is snug but not overly tight.
- Insert and tighten the clamp screw to secure the threaded ring in place.

#### 3. Usage:

- After installation, check the alignment of the reloading die and make any necessary adjustments.
- Perform a test run to ensure that the reloading die operates smoothly with the threaded ring in place.

- Always monitor the reloading process for any irregularities or signs of malfunction.

#### **4. PostUsage:**

- After use, clean the threaded ring and surrounding area to remove any debris or residue.
- Store the threaded ring in a dry, safe place away from children and unauthorized users.

## **Disposal Instructions**

When the Reloading Die Spare Parts Threaded Ring 7/8 reaches the end of its life cycle, please dispose of it responsibly:

- Check local regulations for proper disposal methods of metal products.
- Consider recycling the threaded ring if possible.
- Do not dispose of the product in regular household waste.

## **Contact Information for Further Support**

For any inquiries or further support regarding the Reloading Die Spare Parts Threaded Ring 7/8, please refer to the manufacturer's contact details provided with the product packaging.

Thank you for your attention to these safety instructions. Your safety is our priority.