

Reloading Die Spare Parts - Nut Stopper Spindle ⌀14/M6

Lock nut, steel, blued and precision-made – for securing the stop of the neck sizing bushing in bench rest neck sizing dies. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Nut Stopper Spindle ⌀14/M6
- Manufacturer: TRIEBEL
- Product no.: EU2017179
- Mfr. No.: 3000033.01V
- Thread: M6
- Delivery weight: 0.01kg
- Shipping height: 10mm
- Shipping width: 10mm
- Shipping length: 10mm
- EAN/UPC: 3000033.01V

Table of Contents

- [Startpage](#)
- [English: Reloading Die Spare Parts Nut Stopper Spindle Safety Instruction Guide](#)

Reloading Die Spare Parts Nut Stopper Spindle Safety Instruction Guide

Introduction

Thank you for choosing the Reloading Die Spare Parts Nut Stopper Spindle. This guide provides essential safety instructions and usage information to ensure your safety and the effective operation of the product. Please read this guide thoroughly before using the product.

General Safety Guidelines

- Ensure that all safety measures are followed when using the Reloading Die Spare Parts Nut Stopper Spindle.
- Always handle the product with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- If you notice any defects, do not use the product and contact the manufacturer for advice.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when using reloading equipment.
- Ensure that the working area is clean and free from any hazards that could cause accidents.
- Do not exceed the recommended torque specifications when securing the nut stopper.
- Avoid using the product in wet or damp conditions to prevent slipping and accidents.
- Do not modify the product in any way, as this may compromise its safety and effectiveness.

Instructions for Installation and Usage

1. Installation

- Ensure that the bench rest neck sizing die is securely mounted in a stable position.
- Insert the neck sizing bushing into the die and ensure it is properly seated.
- Place the nut stopper onto the spindle and align it with the threads.
- Handtighten the nut stopper until it is snug. Use a wrench to secure it further, ensuring not to overtighten.

2. Usage

- When using the neck sizing die, ensure that the reloading press is stable and secure.
- Follow the manufacturer's instructions for the reloading process carefully.
- Monitor the operation closely and stop immediately if you notice any unusual noises or resistance.
- After use, remove the nut stopper and clean the components to prevent corrosion and ensure longevity.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding metal waste.
- Do not dispose of the product in household waste.
- If the product is damaged beyond repair, ensure it is recycled or disposed of at a designated facility.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Reloading Die Spare Parts Nut Stopper Spindle, please refer to the manufacturer's contact details provided with the product.

Conclusion

By following the safety instructions outlined in this guide, you can ensure a safe and effective experience with the Reloading Die Spare Parts Nut Stopper Spindle. Always prioritize safety and adhere to best practices while using this product. Thank you for your attention to these important guidelines.