

Reloading Die Spare Parts - Nut Stopper Spindle ⌀12/M6

Lock nut, steel, blued and precision-made – for securing the stop of the neck sizing bushing in bench rest neck sizing dies. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Nut Stopper Spindle ⌀12/M6
- Manufacturer: TRIEBEL
- Product no.: EU2017180
- Mfr. No.: 3000033V
- Thread: M6
- Delivery weight: 0.01kg
- Shipping height: 10mm
- Shipping width: 10mm
- Shipping length: 10mm
- EAN/UPC: 3000033V

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Reloading Die Spare Parts Nut Stopper Spindle](#)

Safety Instruction Guide for Reloading Die Spare Parts Nut Stopper Spindle

Introduction

Thank you for choosing the Reloading Die Spare Parts Nut Stopper Spindle. This product is designed to enhance your reloading experience while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as outlined in this guide.
- Always wear appropriate safety gear, such as safety glasses and gloves, when handling reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage. Do not use if damaged.
- Store the product in a dry and safe environment to prevent corrosion and deterioration.
- Dispose of any damaged parts according to local regulations.

Specific Safety Precautions for Use

- **Thread Compatibility:** Ensure that the thread size is M6 to avoid compatibility issues with your reloading dies.
- **Lock Nut Security:** Always ensure that the lock nut is securely fastened before use to prevent accidental loosening during operation.
- **Avoid OverTightening:** Do not overtighten the lock nut, as this may cause damage to the neck sizing bushing.
- **Use in WellVentilated Areas:** If using any lubricants or cleaning agents, ensure proper ventilation to avoid inhalation of fumes.
- **Follow Manufacturer Instructions:** Always refer to the original die manufacturer's instructions for specific guidance on usage.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and ensure you are in a clean, organized workspace.
- Verify that the Reloading Die Spare Parts Nut Stopper Spindle is compatible with your existing equipment.

2. Installation:

- Remove the neck sizing bushing from the reloading die.
- Insert the Reloading Die Spare Parts Nut Stopper Spindle into the designated area of the neck sizing bushing.
- Secure the lock nut by threading it onto the spindle and tightening it until it is snug. Ensure it is not overtightened.

3. Usage:

- Once installed, proceed with your reloading process as per the manufacturer's guidelines.
- Monitor the lock nut during use to ensure it remains secure.

4. PostUse:

- After reloading, remove the nut stopper spindle from the neck sizing bushing.
- Clean the product to remove any residue or debris.
- Store the product in a safe and dry location.

Disposal Instructions

- Dispose of the product and any associated parts in accordance with local regulations.
- Do not dispose of the product in regular household waste if it contains hazardous materials.
- Check with local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the Reloading Die Spare Parts Nut Stopper Spindle, please reach out to the manufacturer directly or consult the retailer from whom the product was purchased. Always ensure you have the product details ready for a more efficient response.

By following these safety instructions, you can ensure a safe and effective reloading experience with the Reloading Die Spare Parts Nut Stopper Spindle. Thank you for prioritizing safety in your reloading activities.