

Sizing Die Spindle - Spindle M6/M4-5,6 L=110mm

Spindle for sizing dies, precision-made from steel and blued – high-quality replacement part for reliable reloading performance. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Spindle M6/M4-5,6 L=110mm
- Manufacturer: TRIEBEL
- Product no.: EU2017182
- Mfr. No.: 3000040AV-110
- Length: 110
- Thread: M6 / M4-5,6
- Delivery weight: 0.02kg
- Shipping height: 110mm
- Shipping width: 6mm
- Shipping length: 6mm
- EAN: 3000040AV-110

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Sizing Die Spindle M6/M45,6 L=110mm](#)

Safety Instruction Guide for Sizing Die Spindle M6/M45,6 L=110mm

Introduction

Thank you for choosing the Sizing Die Spindle M6/M45,6 L=110mm. This precisionmade spindle is designed for use with sizing dies and is manufactured from highquality steel. It is important to follow the safety instructions outlined in this guide to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure the product is used in accordance with the manufacturer's specifications.
- Always wear appropriate safety gear, such as safety glasses and gloves, when handling or using the spindle.
- Keep the spindle and all related equipment out of reach of children and vulnerable individuals.
- Inspect the product regularly for signs of wear or damage. Do not use if damaged.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls and safety updates through the EU Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure that the spindle is securely attached before use to prevent accidents.
- Do not exceed the recommended torque settings for the spindle to avoid damage or injury.
- Use the spindle only for its intended purpose as specified by the manufacturer.
- Avoid using the spindle in wet or damp conditions to prevent electrical hazards.
- Do not modify or alter the spindle in any way, as this may compromise safety and functionality.

Instructions for Installation and Usage

1. Installation

- Ensure that the work area is clean and free from obstructions.
- Verify that all necessary tools are available for installation.
- Align the spindle with the sizing die and ensure it fits securely.
- Tighten the spindle using the appropriate tool, ensuring it is firmly in place without overtightening.

2. Usage

- Before each use, inspect the spindle for any signs of wear or damage.
- Attach the spindle to the sizing die and ensure it is securely fastened.
- Follow the manufacturer's guidelines for operation, ensuring correct settings are used.
- After use, clean the spindle to remove any debris or residue that may affect performance.

Disposal Instructions

- Dispose of the spindle in accordance with local regulations regarding metal waste.
- Do not dispose of the spindle in regular household waste.
- Consider recycling options for metal materials to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the manufacturer's contact

information provided with the product packaging. It is essential to have access to support for any safety-related questions or concerns.

Thank you for your attention to these safety instructions. Your careful adherence to these guidelines will contribute to a safer and more effective use of the Sizing Die Spindle M6/M45,6 L=110mm.