

Sizing Die Spindle - Spindle M6/M4 L=110mm

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Spindle for sizing dies, precision-made from steel and blued - high-quality replacement part for reliable reloading performance. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Spindle M6/M4 L=110mm](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017184
- Mfr. No.: 3000041AV-110
- Length: 110
- Thread: M6 / M4
- Delivery weight: 0.02kg
- Shipping height: 110mm
- Shipping width: 6mm
- Shipping length: 6mm
- EAN: 3000041AV-110

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Sizing Die Spindle M6/M4 L=110mm](#)
- [About Us](#)

Safety Instruction Guide for Sizing Die Spindle M6/M4 L=110mm

Introduction

Thank you for choosing the Sizing Die Spindle M6/M4 L=110mm. This product is designed to provide reliable performance for reloading applications. To ensure your safety and the effective use of this product, please read this safety instruction guide carefully before use.

General Safety Guidelines

- Always handle the spindle with care to avoid injury.
- Ensure that your workspace is clean and free from distractions.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling the spindle.
- Keep the spindle out of reach of children and vulnerable individuals.
- Regularly inspect the spindle for signs of wear or damage before use.
- Follow all local laws and regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- Ensure that the spindle is compatible with your sizing dies from Triebel Waffenwerkzeuge.
- Do not modify the spindle in any way, as this may compromise its safety and performance.
- Avoid using the spindle if it shows any signs of damage or excessive wear.
- Always use the spindle in accordance with the manufacturer's instructions and guidelines.
- In case of any malfunction or unexpected behavior, discontinue use immediately and seek assistance.

Instructions for Installation and Usage

1. Installation:

- Ensure that your workspace is clean and organized.
- Verify that the sizing die you intend to use is compatible with the spindle.
- Carefully insert the spindle into the sizing die, ensuring a snug fit.
- Tighten any locking mechanisms as per the manufacturer's guidelines to secure the spindle in place.

2. Usage:

- Follow the reloading procedure as outlined in your reloading manual.
- Maintain a steady and controlled motion when using the spindle to ensure accuracy.
- Monitor the spindle and die for any unusual sounds or movements during operation.
- If you encounter any issues, stop using the equipment immediately and conduct a thorough inspection.

Disposal Instructions

- Dispose of the spindle and any associated packaging materials in accordance with local waste disposal regulations.
- Do not dispose of the spindle in regular household waste if it is damaged or shows signs of wear. Instead, consult your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Sizing Die Spindle M6/M4 L=110mm, please refer to the manufacturer's website or customer service resources.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with your Sizing Die Spindle M6/M4 L=110mm. Always prioritize safety and compliance with local regulations during your reloading activities. Thank you for your attention to these important safety guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk