

Sizing Die Spindle - Spindle M6/M4 L=135mm

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Spindle for sizing dies, precision-made from steel and blued - high-quality replacement part for reliable reloading performance. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Spindle M6/M4 L=135mm](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017186
- Mfr. No.: 3000041AV-135
- Length: 135
- Thread: M6 / M4
- Delivery weight: 0.02kg
- Shipping height: 135mm
- Shipping width: 6mm
- Shipping length: 6mm
- EAN: 3000041AV-135

Table of Contents

- [Startpage](#)
- [Sizing Die Spindle Safety Instructions](#)
- [About Us](#)

Sizing Die Spindle Safety Instructions

Introduction

Thank you for choosing the Sizing Die Spindle Spindle M6/M4 L=135mm. This precisionmade spindle is designed for reliable reloading performance and is compatible with original dies from Triebel Waffenwerkzeuge. To ensure safe and effective use of this product, please read the following safety instructions carefully.

General Safety Guidelines

- Always read and follow the instructions provided in this manual before using the product.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any damage before use. Do not use if damaged.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the spindle.
- Ensure that the work area is clean, dry, and free from hazards.
- Use the spindle in a wellventilated area to avoid inhalation of any fumes or dust.
- Do not exceed the recommended load limits of the spindle.
- Avoid using the spindle near flammable materials.
- Do not modify or alter the spindle in any way, as this may compromise safety.

Instructions for Installation and Usage

1. Installation:

- Before installation, ensure that the work area is clean and organized.
- Carefully remove the spindle from its packaging.
- Inspect the spindle for any signs of damage before installation.
- Align the spindle with the corresponding die threads (M6/M4).
- Handtighten the spindle into the die, ensuring a secure fit. Do not overtighten.

2. Usage:

- Follow the manufacturer's instructions for the specific reloading process.
- Use the spindle only with compatible sizing dies to ensure optimal performance.
- Monitor the spindle during use for any signs of wear or damage.
- If you notice any unusual sounds or performance issues, stop using the spindle immediately and inspect it.

3. PostUsage:

- After use, clean the spindle with a soft cloth to remove any debris or residue.
- Store the spindle in a safe, dry location away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the spindle according to local regulations for metal waste.
- Do not dispose of the spindle in household waste.

- If the spindle is damaged beyond repair, ensure it is recycled or disposed of responsibly.

Contact Information for Further Support

For any safety inquiries or support regarding the Sizing Die Spindle, please contact your local distributor or the manufacturer directly. Ensure you have the product details ready for reference.

By following these safety instructions, you can ensure a safe and effective experience with your Sizing Die Spindle. Thank you for prioritizing safety and responsible usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk