

Sizing Die Spindle - Spindle M8/M6 L=155mm

Spindle for sizing dies, precision-made from steel and blued – high-quality replacement part for reliable reloading performance. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Spindle M8/M6 L=155mm
- Manufacturer: TRIEBEL
- Product no.: EU2017190
- Mfr. No.: 3000043AV-155
- Length: 155
- Thread: M8 / M6
- Delivery weight: 0.02kg
- Shipping height: 155mm
- Shipping width: 6mm
- Shipping length: 6mm
- EAN: 3000043AV-155

Table of Contents

- [Startpage](#)
- [English: Sizing Die Spindle M8/M6 L=155mm Safety Instruction Guide](#)

Sizing Die Spindle M8/M6 L=155mm Safety Instruction Guide

Introduction

Thank you for choosing the Sizing Die Spindle M8/M6 L=155mm. This guide provides essential safety instructions and information to ensure the safe and effective use of your product. Please read this guide carefully before use.

General Safety Guidelines

- Always ensure that the product is used in accordance with the manufacturer's specifications.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check the product for any signs of wear or damage before use.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Inspect the spindle for any visible defects before installation. Do not use if damaged.
- Ensure that the spindle is compatible with your sizing die. Use only with original dies from Triebel Waffenwerkzeuge.
- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling and using the spindle.
- Do not exceed the recommended torque specifications during installation to avoid damage.
- Always follow the manufacturer's guidelines for reloading to prevent accidents.

Instructions for Installation and Usage

1. Installation

- Ensure that the work area is clean and welllit.
- Gather all necessary tools and equipment before starting the installation.
- Carefully remove the spindle from its packaging.
- Align the spindle with the sizing die, ensuring that the threads match (M8/M6).
- Gently screw the spindle into the sizing die until it is securely fastened. Do not overtighten.
- Confirm that the spindle is properly installed and stable before proceeding.

2. Usage

- Follow the reloading process as outlined in the instructions for your specific sizing die.
- Monitor the spindle during use for any unusual sounds or movements. If any issues arise, stop using the product immediately.
- After use, clean the spindle to remove any debris or residues that may have accumulated.

Disposal Instructions

- Dispose of the spindle in accordance with local regulations for metal waste.
- Do not dispose of the spindle in regular household waste.
- Consider recycling the product if possible to minimize environmental impact.

Contact Information for Further Support

For any inquiries regarding safety, usage, or product support, please contact your local distributor or retailer. They will provide the necessary assistance and information.

By following these safety instructions, you can ensure a safe and effective experience with the Sizing Die Spindle M8/M6 L=155mm. Thank you for your attention to safety.