

Expander BR ⌀7,18/.2827

Expander BR (Bench Rest) made from hardened steel, precision-ground – designed for short cartridge cases. Replaces the brass knurled sleeve and also secures the decapping pin. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Expander BR ⌀7,18/.2827
- Manufacturer: TRIEBEL
- Product no.: EU2017363
- Mfr. No.: 3000051V-07.18
- Diameter mm: 7,18
- Delivery weight: 0.005kg
- Shipping height: 10mm
- Shipping width: 15mm
- Shipping length: 15mm
- EAN/UPC: 3000051V-07.18

Table of Contents

- [Startpage](#)
- [English: Expander BR Safety Instruction Guide](#)

Expander BR Safety Instruction Guide

Introduction

Thank you for choosing the Expander BR (Bench Rest). This product is designed for precision use in reloading short cartridge cases. It is made from hardened steel and precisionground for optimal performance. Please read this safety instruction guide carefully to ensure safe and effective use of the Expander BR.

General Safety Guidelines

- Always use the Expander BR according to the manufacturer's instructions.
- Inspect the product before each use for any signs of damage or wear.
- Keep the product out of reach of children and vulnerable individuals.
- Ensure that your workspace is clean and free of any obstructions.
- Use appropriate personal protective equipment, such as safety glasses and gloves, while handling the Expander BR.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Do not use the Expander BR with damaged or defective reloading dies.
- Avoid using excessive force when operating the Expander BR to prevent injury or damage.
- Ensure that the decapping pin is securely fastened before use.
- Do not exceed the recommended diameter specifications (7.18 mm) when using the Expander BR.
- Always follow proper reloading safety practices, including the use of correct components and tools.

Instructions for Installation and Usage

1. Installation:

- Remove the existing brass knurled sleeve from your reloading die.
- Insert the Expander BR into the die, ensuring a snug fit.
- Secure the decapping pin in place according to the die's specifications.
- Doublecheck that everything is properly installed before proceeding.

2. Usage:

- Place your cartridge case into the reloading die.
- Operate the press according to your reloading setup, ensuring that the Expander BR is aligned with the cartridge case.
- Monitor the operation closely to avoid any misalignment or excessive force.
- After use, carefully remove the cartridge case and inspect it for proper expansion.

Disposal Instructions

- Dispose of the Expander BR responsibly at a designated recycling or waste disposal facility.
- Do not dispose of the product in regular household waste.
- Follow local regulations for the disposal of metal products.

Contact Information for Further Support

For any questions or concerns regarding the Expander BR, please refer to the manufacturer's contact point or your retailer for assistance. They can provide additional information and support as needed.

Thank you for following these safety guidelines. Your safety and satisfaction are our top priorities.