

Expander BR ⌀8,17/.3217

Expander BR (Bench Rest) made from hardened steel, precision-ground – designed for short cartridge cases. Replaces the brass knurled sleeve and also secures the decapping pin. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Expander BR ⌀8,17/.3217
- Manufacturer: TRIEBEL
- Product no.: EU2017366
- Mfr. No.: 3000051V-08.17
- Diameter mm: 8,17
- Delivery weight: 0.005kg
- Shipping height: 10mm
- Shipping width: 15mm
- Shipping length: 15mm
- EAN/UPC: 3000051V-08.17

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Expander BR](#)

Safety Instruction Guide for Expander BR

Introduction

Thank you for choosing the Expander BR. This product is designed to enhance your reloading experience by providing precision and reliability. Please read this safety instruction guide carefully to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always ensure that the Expander BR is used in accordance with the manufacturer's instructions.
- Inspect the product before each use for any signs of wear or damage.
- Store the Expander BR in a dry and secure location, away from children and pets.
- Be aware of your surroundings when using the product to prevent accidents.
- Follow all local regulations regarding the use and disposal of reloading equipment.

Specific Safety Precautions for Use

- Use the Expander BR only with short cartridge cases as designed.
- Ensure that the decapping pin is securely fastened before use.
- Do not exceed the recommended diameter specifications (8.17 mm) when using the product.
- Wear appropriate safety gear, including eye protection, when operating the reloading equipment.
- Keep hands and other body parts clear of moving parts during operation.
- If you experience any unusual noises or resistance during use, stop immediately and inspect the product.

Instructions for Installation and Usage

1. Installation:

- Remove the existing brass knurled sleeve from your reloading die.
- Insert the Expander BR into the die, ensuring it is seated properly.
- Secure the decapping pin in place using the provided mechanism.

2. Usage:

- Set up your reloading press according to the manufacturer's instructions.
- Position the cartridge case under the Expander BR.
- Operate the reloading press smoothly to expand the cartridge case.
- After use, remove the Expander BR from the die and clean it as necessary.

Disposal Instructions

- Dispose of the Expander BR in accordance with local regulations regarding metal waste.
- Do not throw the product in regular household waste.
- If the product is damaged beyond repair, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further support regarding the Expander BR, please refer to the manufacturer's contact point based in the EU.

Please ensure that you follow these guidelines to maintain safety and compliance while using the Expander BR. Your safety is our priority.