

Expander BR ⌀8,55/.3366

Expander BR (Bench Rest) made from hardened steel, precision-ground – designed for short cartridge cases. Replaces the brass knurled sleeve and also secures the decapping pin. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Expander BR ⌀8,55/.3366
- Manufacturer: TRIEBEL
- Product no.: EU2017368
- Mfr. No.: 3000051V-08.55
- Diameter mm: 8,55
- Delivery weight: 0.005kg
- Shipping height: 10mm
- Shipping width: 15mm
- Shipping length: 15mm
- EAN/UPC: 3000051V-08.55

Table of Contents

- [Startpage](#)
- [English: Expander BR Safety Instruction Guide](#)

Expander BR Safety Instruction Guide

Introduction

Thank you for choosing the Expander BR (Bench Rest). This product is designed for precision and safety when reloading short cartridge cases. Please read this safety instruction guide thoroughly to ensure safe and effective use of the Expander BR.

General Safety Guidelines

- Ensure that you are familiar with the operation of the Expander BR before use.
- Always wear appropriate safety gear, such as safety glasses and gloves, to protect against potential hazards.
- Keep the work area clean and organized to prevent accidents.
- Store the Expander BR in a dry, secure place out of reach of children and unauthorized users.
- Regularly inspect the Expander BR for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding the reloading of ammunition.

Specific Safety Precautions for Use

- Always use the Expander BR with compatible reloading dies from Triebel Waffenwerkzeuge.
- Do not exceed the recommended specifications for cartridge cases.
- Avoid wearing loose clothing or jewelry while operating the Expander BR.
- Ensure that the decapping pin is securely fastened before use.
- Be cautious of sharp edges and moving parts during operation.
- Do not attempt to modify or repair the Expander BR yourself. Contact a professional if repairs are needed.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and unplugged.
- Remove any existing components that the Expander BR will replace.
- Install the Expander BR by securing it into the reloading die setup, ensuring it fits snugly.
- Check that the decapping pin is properly aligned and secured.

2. Usage

- Prepare your cartridge cases as per standard reloading procedures.
- Insert the cartridge case into the reloading press.
- Activate the reloading press to expand the case using the Expander BR.
- Monitor the process closely to ensure that the operation is smooth and without obstruction.
- After use, clean the Expander BR to remove any debris or residue.

Disposal Instructions

- Dispose of the Expander BR responsibly at the end of its service life.
- Follow local regulations for the disposal of metal products.
- Do not dispose of the Expander BR in household waste. Instead, consider recycling options available in your area.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Expander BR, please refer to the EUbased contact point provided with your product packaging.

By following these guidelines, you can ensure a safe and effective experience with the Expander BR. Thank you for your attention to safety!