

Reloading Die Spare Parts - Decapping Pin ⌀1,75mm 2 Stk.

Decapping pins (2 pcs) made from steel, precision-manufactured – ensure reliable primer removal during reloading. To be secured with decapping pin holder. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Decapping Pin ⌀1,75mm 2 Stk.
- Manufacturer: TRIEBEL
- Product no.: EU2017583
- Mfr. No.: 3000070V-1.75
- Thread: 0
- Delivery weight: 0.001kg
- Shipping height: 15mm
- Shipping width: 2mm
- Shipping length: 2mm
- EAN: 3000070V-1.75

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Reloading Die Spare Parts Decapping Pin](#)

Safety Instruction Guide for Reloading Die Spare Parts Decapping Pin

Introduction

Thank you for choosing the Reloading Die Spare Parts Decapping Pin. This guide provides essential safety instructions to ensure the safe and effective use of the product. Please read this guide carefully before using the decapping pins.

General Safety Guidelines

- Ensure safe use of the decapping pins by following the instructions provided.
- Be aware of potential risks associated with the use of reloading equipment.
- Always use the product in accordance with the manufacturer's recommendations.
- Check for any updates or recalls on the EU Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling reloading components.
- Keep the decapping pins out of reach of children and pets.
- Inspect the decapping pins for damage before each use. Do not use damaged pins.
- Ensure that the decapping pin holder is securely attached before use.
- Do not exceed the recommended specifications for the decapping pins.
- Be cautious of sharp edges and points when handling the pins.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials for reloading.
- Ensure you have the correct decapping pin holder compatible with the pins.

2. Installation:

- Remove the old or damaged decapping pin from the holder.
- Insert the new decapping pin into the holder, ensuring it is securely fitted.
- Tighten any screws or fasteners to hold the pin in place.

3. Usage:

- Place the reloading die in the appropriate position on your reloading press.
- Follow standard reloading procedures to decap the primers using the decapping pin.
- After use, remove the decapping pin and store it in a safe place.

Disposal Instructions

- Dispose of any damaged or worn decapping pins in accordance with local regulations.
- Do not dispose of the decapping pins in regular household waste if they are considered hazardous.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any questions or concerns regarding the use of the Reloading Die Spare Parts Decapping Pin, please refer to the manufacturer's website or contact customer support for assistance.

Thank you for your attention to these safety instructions. Your safety is our priority.