

Neck Bushing ⌀12,7-5,61/.2209

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-5,61/.2209
- Manufacturer: TRIEBEL
- Product no.: EU2017591
- Mfr. No.: 3000240V-05.61
- Diameter mm: 12,7 / 5,61
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-05.61

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This guide provides essential safety instructions and information to ensure the safe and effective use of the product. Please read and follow all guidelines carefully to avoid potential hazards and ensure optimal performance.

General Safety Guidelines

- Always use the Neck Bushing in accordance with the manufacturer's instructions.
- Ensure that the product is suitable for your specific reloading die model.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for signs of wear or damage before each use.
- Report any unsafe conditions or accidents to the appropriate authorities immediately.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not use the Neck Bushing if it appears damaged or worn.
- Use protective eyewear and gloves when handling the bushing to prevent personal injury.
- Ensure the work area is clean and free from obstructions to avoid accidents.
- Be cautious of sharp edges when handling the Neck Bushing, as they may cause cuts.
- Follow all recommended procedures for neck sizing to prevent misfires or other dangerous situations.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your reloading die is clean and free of debris.
- Gather all necessary tools and materials required for the installation.

2. Installation:

- Carefully remove the Neck Bushing from its packaging.
- Insert the Neck Bushing into the designated area of your reloading die, ensuring a snug fit.
- Tighten any locking mechanisms as specified in your reloading die's manual to secure the bushing in place.

3. Usage:

- Adjust your reloading press according to the specifications for neck sizing.
- Insert the casing into the reloading die with the installed Neck Bushing.
- Apply steady pressure to resize the neck of the casing, following best practices for reloading.
- After use, remove the casing and inspect it for proper sizing and any signs of damage.

Disposal Instructions

- Dispose of the Neck Bushing responsibly in accordance with local regulations.
- Do not throw the product in regular household waste. Instead, check for recycling options or designated disposal sites for metal products.

Contact Information for Further Support

For any questions or concerns regarding the Neck Bushing, please refer to the manufacturer's website or contact their customer service for assistance. Always ensure you have the product details ready for a more efficient response.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities.