

Neck Bushing ⌀12,7-6,07/.2390

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,07/.2390
- Manufacturer: TRIEBEL
- Product no.: EU2017596
- Mfr. No.: 3000240V-06.07
- Diameter mm: 12,7 / 6,07
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.07

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This guide provides essential safety information, usage instructions, and disposal guidelines to ensure your safe and effective use of the product. Please read this guide carefully before using the Neck Bushing.

General Safety Guidelines

- Always ensure that the Neck Bushing is used in accordance with the manufacturer's instructions.
- Inspect the Neck Bushing for any signs of damage before each use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Use the Neck Bushing only for its intended purpose, which is neck sizing for reloading dies.
- Follow all local regulations regarding the use and disposal of reloading materials.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling the Neck Bushing.
- Ensure that the work area is clean, dry, and welllit to prevent accidents.
- Do not exceed the specified diameter measurements when using the Neck Bushing (Diameter V mm: 12.7 / 6.07).
- Avoid using the Neck Bushing with incompatible materials or equipment.
- Always follow safe reloading practices when using the Neck Bushing in conjunction with reloading dies.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is compatible with the Neck Bushing.
- Clean the Neck Bushing and the reloading die to remove any debris or contaminants.
- Insert the Neck Bushing into the reloading die according to the die's specific instructions.
- Tighten securely to prevent movement during operation.

2. Usage:

- Set the reloading press to the appropriate settings for neck sizing.
- Place the cartridge case into the reloading die with the installed Neck Bushing.
- Operate the reloading press smoothly and steadily to achieve optimal neck sizing.
- Regularly check the progress and ensure that the Neck Bushing is functioning correctly.

Disposal Instructions

- Dispose of the Neck Bushing according to local regulations for metal products.
- Do not dispose of in regular household waste.
- Consider recycling the Neck Bushing if possible, as it is made from highquality hardened steel.

Contact Information for Further Support

For any questions or concerns regarding the Neck Bushing, please refer to the manufacturer's contact information provided in the product packaging or documentation.

Thank you for your attention to these safety guidelines. Your safety is important, and adhering to these

instructions will help ensure a safe and effective experience with your Neck Bushing.