

Neck Bushing ⌀12,7-6,19/.2437

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,19/.2437
- Manufacturer: TRIEBEL
- Product no.: EU2017602
- Mfr. No.: 3000240V-06.19
- Diameter mm: 12,7 / 6,19
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.19

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This product is designed for precise neck sizing in reloading applications. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always handle the Neck Bushing with care to avoid injury.
- Ensure that the product is used in accordance with the manufacturer's instructions.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of wear or damage before use.
- Report any unsafe product conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the Neck Bushing.
- Do not exceed the recommended specifications for the Neck Bushing as outlined by the manufacturer.
- Avoid using the Neck Bushing if it shows signs of damage or excessive wear.
- Ensure that the work area is clean and free from any obstructions or hazards.
- Use the Neck Bushing only for its intended purpose as stated in the product description.

Instructions for Installation and Usage

1. Preparation

- Ensure that your reloading press is clean and properly set up.
- Gather all necessary tools and materials before starting the process.

2. Installation

- Carefully remove the Neck Bushing from its packaging.
- Insert the Neck Bushing into the designated die of your reloading press.
- Ensure that the bushing is securely fitted and properly aligned.

3. Usage

- Adjust the reloading press according to the specifications for neck sizing.
- Insert the cartridge case into the press and engage the Neck Bushing.
- Follow the manufacturer's guidelines for applying pressure and sizing the neck of the cartridge case.
- After sizing, carefully remove the cartridge case from the press.

4. PostUse Care

- Clean the Neck Bushing after each use to maintain its precision and longevity.
- Store the Neck Bushing in a safe, dry place away from moisture and extreme temperatures.

Disposal Instructions

- Dispose of any damaged or worn Neck Bushings in accordance with local regulations.
- Recycle packaging materials where possible to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the Neck Bushing, please refer to the product packaging for the manufacturer's contact details. It is important to reach out for assistance if you encounter any issues or have safety inquiries.

By following these guidelines, you can ensure a safe and effective experience with your Neck Bushing. Thank you for prioritizing safety in your reloading activities.