

Neck Bushing ⌀12,7-6,21/.2445

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,21/.2445
- Manufacturer: TRIEBEL
- Product no.: EU2017604
- Mfr. No.: 3000240V-06.21
- Diameter mm: 12,7 / 6,21
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.21

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This highquality product is designed for precise neck sizing in reloading applications. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure safe use of the Neck Bushing by following these guidelines:
 - Always handle the product with care to avoid injury.
 - Keep the Neck Bushing out of reach of children and vulnerable individuals.
 - Use the product only for its intended purpose as described in this guide.
 - Regularly inspect the Neck Bushing for signs of wear or damage before use.
 - Follow all local regulations regarding the use of reloading equipment.

Specific Safety Precautions for Use

- To minimize risks while using the Neck Bushing:
 - Wear appropriate safety gear, such as safety glasses and gloves, during operation.
 - Avoid wearing loose clothing or jewelry that could get caught in machinery.
 - Ensure your workspace is welllit and free of clutter.
 - Do not exceed the recommended specifications for the Neck Bushing.
 - If you experience any issues during use, stop immediately and consult the troubleshooting guide or seek professional assistance.

Instructions for Installation and Usage

- Follow these steps for the proper installation and usage of the Neck Bushing:

1. Preparation:

- Gather all necessary tools and materials for the reloading process.
- Ensure that your reloading press is clean and in good working condition.

2. Installation:

- Carefully remove the Neck Bushing from its packaging.
- Insert the Neck Bushing into the designated die in your reloading press.
- Secure the die according to the manufacturer's instructions to ensure stability.

3. Usage:

- Adjust the reloading press to the appropriate settings as per your reloading specifications.
- Place the cartridge case into the reloading press and apply the necessary force to size the neck.
- Inspect the sized neck for conformity and accuracy before proceeding with further reloading steps.

4. PostUse Care:

- Clean the Neck Bushing after each use to maintain its precision and longevity.
- Store the Neck Bushing in a safe, dry location away from moisture and extreme temperatures.

Disposal Instructions

- Dispose of the Neck Bushing responsibly:
 - If the product is damaged or no longer usable, follow local regulations for disposal of metal products.
 - Consider recycling the Neck Bushing if possible to minimize environmental impact.

Contact Information for Further Support

- For safety inquiries or further assistance regarding the Neck Bushing, please contact your local distributor or refer to the manufacturer's website for additional resources.

Thank you for prioritizing safety while using the Neck Bushing. By following these guidelines, you can ensure a safe and effective reloading experience.