

Neck Bushing ⌀12,7-6,24/.2457

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,24/.2457
- Manufacturer: TRIEBEL
- Product no.: EU2017607
- Mfr. No.: 3000240V-06.24
- Diameter mm: 12,7 / 6,24
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.24

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Neck Bushing](#)

Safety Instruction Guide for Neck Bushing

Introduction

Thank you for choosing the Neck Bushing. This product is designed for precise neck sizing in reloading applications. To ensure your safety and the effective use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure safe use of the Neck Bushing by following these guidelines:
 - Always use the product according to the manufacturer's instructions.
 - Keep the product out of reach of children and vulnerable individuals.
 - Regularly inspect the Neck Bushing for wear or damage before use.
 - Do not use the product if it shows signs of damage or malfunction.
 - Report any unsafe products or incidents to the appropriate authorities.
 - Stay informed about recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- To avoid potential hazards associated with the Neck Bushing, please observe the following precautions:
 - Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while using the product.
 - Ensure that the working area is clean and free from any obstructions.
 - Use the Neck Bushing only with compatible reloading dies from Triebel Waffenwerkzeuge.
 - Avoid excessive force when using the Neck Bushing to prevent injury or damage.
 - Follow the recommended dimensions and specifications to ensure proper function.

Instructions for Installation and Usage

- Follow these steps for the correct installation and usage of the Neck Bushing:

1. Installation:

- Ensure the reloading press is turned off and unplugged.
- Select the appropriate Neck Bushing based on the dimensions specified (Diameter V mm: 12.7 / 6.24).
- Insert the Neck Bushing into the reloading die, ensuring it fits securely.
- Tighten the die according to the manufacturer's specifications.

2. Usage:

- Prepare your brass cases for resizing.
- Insert the brass case into the reloading press.
- Operate the press smoothly, applying consistent pressure.
- Inspect the resized brass cases for accuracy and consistency.
- Clean the Neck Bushing after use to maintain its performance.

Disposal Instructions

- Dispose of the Neck Bushing responsibly:
 - Do not dispose of the product in regular household waste.
 - Follow local regulations for the disposal of metal products.

- Consider recycling options where available.

Contact Information for Further Support

- For any safety inquiries or additional support related to the Neck Bushing, please reach out to the appropriate EUbased contact for assistance.

By following these safety instructions, you can ensure a safe and effective experience with the Neck Bushing. Always prioritize safety and consult professionals if you have any doubts or questions regarding the use of this product. Thank you for your attention to these guidelines.