

Neck Bushing ⌀12,7-6,40/.2520

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,40/.2520
- Manufacturer: TRIEBEL
- Product no.: EU2017615
- Mfr. No.: 3000240V-06.40
- Diameter mm: 12,7 / 6,40
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.40

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Neck Bushing](#)

Safety Instruction Guide for Neck Bushing

Introduction

Thank you for choosing the Neck Bushing. This guide provides essential safety instructions to ensure the safe and effective use of the product. Please read this document carefully before using the Neck Bushing to understand the precautions and proper handling procedures.

General Safety Guidelines

- Ensure that the Neck Bushing is used in accordance with the manufacturer's instructions.
- Always inspect the Neck Bushing for any signs of damage or wear before use.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Follow all local regulations regarding the use of reloading equipment.
- Report any incidents or unsafe conditions to the appropriate authorities.

Specific Safety Precautions for Use

- Use only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, when using the Neck Bushing.
- Avoid using the Neck Bushing if you are tired, under the influence of drugs or alcohol, or distracted.
- Do not exceed the recommended sizing parameters as specified in the product specifications.
- Always work in a wellventilated area to avoid inhaling any dust or particles generated during use.

Instructions for Installation and Usage

1. Preparation

- Ensure that your reloading press is clean and free from any debris.
- Gather all necessary tools and equipment before starting.

2. Installation

- Carefully remove the Neck Bushing from its packaging.
- Install the Neck Bushing into the reloading die according to the manufacturer's specifications.
- Ensure that the Neck Bushing is securely fastened and properly aligned.

3. Usage

- Place the cartridge case into the shell holder of the reloading press.
- Operate the reloading press to size the neck of the cartridge case using the Neck Bushing.
- Inspect the sized cartridge case for proper dimensions and concentricity.

4. PostUse Care

- Clean the Neck Bushing after use to remove any residue or debris.
- Store the Neck Bushing in a safe and dry location, away from direct sunlight and moisture.

Disposal Instructions

- Dispose of the Neck Bushing according to local regulations for metal products.
- Do not dispose of the Neck Bushing in regular household waste.
- If the Neck Bushing is damaged or no longer usable, consider recycling it if possible.

Contact Information for Further Support

For any questions or concerns regarding the Neck Bushing, please refer to the manufacturer's contact information provided on the product packaging or visit the official website for support resources.

Thank you for prioritizing safety while using the Neck Bushing. Your adherence to these guidelines ensures a safe and effective reloading experience.