

Neck Bushing ⌀12,7-6,45/.2539

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,45/.2539
- Manufacturer: TRIEBEL
- Product no.: EU2017616
- Mfr. No.: 3000240V-06.45
- Diameter mm: 12,7 / 6,45
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.45

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This product is designed for precise neck sizing in reloading applications. To ensure your safety and the effective use of this product, please read the following safety instructions carefully.

General Safety Guidelines

- Always follow the manufacturer's instructions for use.
- Ensure that the Neck Bushing is compatible with your reloading die.
- Inspect the Neck Bushing for any damage or wear before each use.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform regularly.

Specific Safety Precautions for Use

- Handle the Neck Bushing with care to avoid injury from sharp edges.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the product.
- Do not exceed the recommended sizing specifications to prevent damage to the bushing or your reloading equipment.
- Ensure that your work area is clean and free from distractions while using the Neck Bushing.
- Always store the Neck Bushing in a safe place when not in use to prevent accidents.

Instructions for Installation and Usage

1. Prepare Your Equipment

- Ensure that your reloading press is clean and properly set up.
- Gather all necessary tools and materials before starting.

2. Installing the Neck Bushing

- Remove the existing bushing from your reloading die, if applicable.
- Carefully insert the Neck Bushing into the reloading die, ensuring it fits snugly.
- Tighten the die to secure the bushing in place, following the manufacturer's guidelines.

3. Using the Neck Bushing

- Adjust your reloading press according to the specifications for neck sizing.
- Insert the case into the press and lower the ram to size the neck.
- Monitor the process closely to ensure proper sizing and avoid oversizing.

4. PostUse Care

- Remove the Neck Bushing from the die after use.
- Clean the bushing with a soft cloth to remove any debris or residue.
- Store the Neck Bushing in a protective case or designated area to prevent damage.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is damaged or no longer functional, consider recycling options if available.

Contact Information for Further Support

For any questions or concerns regarding the Neck Bushing, please refer to the manufacturer or your point of purchase for assistance.

By following these safety instructions, you can ensure a safe and effective experience with the Neck Bushing. Thank you for your attention to these guidelines.