

Neck Bushing ⌀12,7-6,60/.2598

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,60/.2598
- Manufacturer: TRIEBEL
- Product no.: EU2017624
- Mfr. No.: 3000240V-06.60
- Diameter mm: 12,7 / 6,60
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.60

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instructions](#)

Neck Bushing Safety Instructions

Introduction

Thank you for choosing the Neck Bushing. This product is designed for precise neck sizing and is made from highquality hardened steel. To ensure your safety and the optimal performance of the Neck Bushing, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure safe use of the Neck Bushing by following all instructions.
- Be aware of potential hazards associated with the use of this product.
- Always handle the Neck Bushing with care to prevent injury.
- Use the Neck Bushing only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for updates on product recalls and safety notices.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using the Neck Bushing.
- Inspect the Neck Bushing for any signs of damage or wear before each use. Do not use if damaged.
- Ensure that the Neck Bushing is properly secured in your reloading die before starting the sizing process.
- Avoid forcing the Neck Bushing into the die; it should fit snugly without excessive pressure.
- Do not exceed the manufacturer's recommended specifications for use.
- If you experience any unusual resistance or difficulty during use, stop immediately and inspect the equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure your workspace is clean and free from obstructions.
- Select the appropriate Neck Bushing size based on your reloading needs.
- Carefully insert the Neck Bushing into the reloading die, ensuring it is seated properly.
- Tighten the die according to the manufacturer's instructions to secure the Neck Bushing in place.

2. Usage:

- Prepare your brass cases for neck sizing by cleaning and inspecting them.
- Place the brass case in the reloading press and align it with the Neck Bushing.
- Slowly and steadily operate the press to size the neck of the brass case.
- After sizing, remove the brass case and inspect it for proper sizing.
- Store the Neck Bushing in a safe, dry place when not in use.

Disposal Instructions

- Dispose of the Neck Bushing responsibly at the end of its life cycle.
- Follow local regulations for the disposal of metal products.
- Do not dispose of the Neck Bushing in household waste.

Contact Information for Further Support

For any safety inquiries or further support regarding the Neck Bushing, please contact your local distributor or manufacturer. They will be able to assist you with any questions or concerns you may have.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.