

Neck Bushing ⌀12,7-6,65/.2618

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,65/.2618
- Manufacturer: TRIEBEL
- Product no.: EU2017627
- Mfr. No.: 3000240V-06.65
- Diameter mm: 12,7 / 6,65
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.65

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This guide provides essential safety instructions and information to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose, which is precise neck sizing in reloading applications.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Regularly inspect the Neck Bushing for any signs of wear or damage before each use.
- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using this product.
- Be aware of your surroundings and ensure that the work area is clean and free from distractions while using the Neck Bushing.
- Report any unsafe conditions or product malfunctions to the appropriate authorities.

Specific Safety Precautions for Use

- Do not exceed the specified dimensions of the Neck Bushing (Diameter V mm: 12.7 / 6.65) during use.
- Avoid using the Neck Bushing with incompatible reloading dies or equipment.
- Do not attempt to modify or repair the Neck Bushing. If damage occurs, discontinue use immediately.
- Ensure that the Neck Bushing is securely attached to the reloading die before operation.
- Use only in wellventilated areas to avoid inhalation of any dust or particles generated during use.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged before installation.
- Remove any existing bushing from the reloading die.
- Insert the Neck Bushing into the reloading die, ensuring it fits securely.
- Tighten the locking mechanism of the die to secure the Neck Bushing in place.

2. Usage:

- Prepare your brass cases according to standard reloading procedures.
- Insert the brass case into the reloading die with the installed Neck Bushing.
- Operate the reloading press according to the manufacturer's instructions, applying steady and even pressure.
- After sizing, remove the brass case from the die and inspect it for proper sizing.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations regarding metal waste.
- Do not dispose of the product in household waste. Instead, take it to a designated recycling center or facility that accepts metal products.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Neck Bushing, please contact the manufacturer or your local distributor. Ensure that you have the product details available for reference.

Thank you for taking the time to read this safety instruction guide. Your safety and satisfaction are our top priorities.