

Neck Bushing ⌀12,7-6,67/.2626

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-6,67/.2626
- Manufacturer: TRIEBEL
- Product no.: EU2017628
- Mfr. No.: 3000240V-06.67
- Diameter mm: 12,7 / 6,67
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-06.67

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Neck Bushing](#)

Safety Instruction Guide for Neck Bushing

Introduction

Thank you for choosing the Neck Bushing. This product is designed for precise neck sizing and is made from highquality hardened steel. To ensure your safety and the effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure safe use of the Neck Bushing by following all instructions.
- Be aware of potential hazards associated with the use of this product.
- Always use the Neck Bushing as intended and in accordance with the guidelines provided.
- Use personal protective equipment (PPE) such as safety glasses and gloves when handling or using the product.
- Store the Neck Bushing in a safe place, out of reach of children and vulnerable individuals.

Specific Safety Precautions for Use

- Inspect the Neck Bushing before each use for any signs of damage or wear.
- Do not use the Neck Bushing if it is damaged or if any parts are missing.
- Ensure that the Neck Bushing is compatible with your reloading dies before use.
- Avoid placing your hands or other body parts near moving parts during operation.
- Follow all manufacturer instructions for your reloading equipment when using the Neck Bushing.
- Do not exceed the manufacturer's recommended specifications for neck sizing.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and equipment required for neck sizing.
- Ensure that your reloading press is clean and in good working condition.

2. Installation:

- Insert the Neck Bushing into the appropriate die according to the manufacturer's instructions.
- Secure the die in your reloading press, ensuring it is tightened properly to avoid movement during use.

3. Usage:

- Place the cartridge case into the reloading press and engage the sizing operation.
- Apply steady and even pressure when operating the press to ensure consistent neck sizing.
- After sizing, carefully remove the cartridge case from the press.

4. PostUse Care:

- Clean the Neck Bushing after use to remove any debris or residue.
- Store the Neck Bushing in its original packaging or a safe location to prevent damage.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations regarding metal waste.
- Do not dispose of the Neck Bushing in regular household waste.

- Consider recycling options available in your area for metal products.

Contact Information for Further Support

For any safety inquiries or product support, please refer to the manufacturer's contact information provided with the product packaging. Always report unsafe products and accidents to the appropriate authorities.

Thank you for your attention to these safety instructions. Your safety is our priority, and we hope you enjoy using the Neck Bushing.