

Neck Bushing ⌀12,7-7,29/.2870

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Neck Bushing ⌀12,7-7,29/.2870
- Manufacturer: TRIEBEL
- Product no.: EU2017662
- Mfr. No.: 3000240V-07.29
- Diameter mm: 12,7 / 7,29
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-07.29

Table of Contents

- [Startpage](#)
- [English: Neck Bushing Safety Instruction Guide](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing. This guide provides essential safety instructions to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose: neck sizing in reloading applications.
- Always handle the Neck Bushing with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of damage or wear before use.
- If you notice any defects or irregularities, do not use the product and contact the manufacturer for further guidance.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the Neck Bushing.
- Ensure that your reloading setup is stable and secure before proceeding with neck sizing.
- Avoid using excessive force during the neck sizing process to prevent damage to the bushing or your reloading equipment.
- Follow the manufacturer's specifications for the correct diameter and size to ensure compatibility with your reloading dies.
- Do not modify the Neck Bushing in any way, as this may compromise its safety and effectiveness.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is turned off and unplugged.
- Select the appropriate Neck Bushing based on the diameter specifications (12.7 mm to 7.29 mm).
- Insert the Neck Bushing into the reloading die according to the manufacturer's instructions.
- Secure the bushing in place to prevent movement during operation.

2. Usage:

- Prepare your brass cases for neck sizing by cleaning and inspecting them for damage.
- Place the brass case in the reloading press and ensure it is properly aligned with the Neck Bushing.
- Apply consistent pressure to the press handle to size the neck of the brass case.
- After sizing, carefully remove the brass case and inspect it for proper sizing and any signs of damage.
- Store the Neck Bushing in a safe, dry location when not in use to prevent damage.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations for metal products.
- Do not dispose of the Neck Bushing in regular household waste.
- Consider recycling the Neck Bushing if local facilities accept metal recycling.

Contact Information for Further Support

For any inquiries regarding the Neck Bushing, including safety concerns or product defects, please refer to the contact information provided by the manufacturer or retailer.

By following these safety instructions, you can ensure a safe and effective experience with your Neck Bushing. Thank you for your attention to safety, and enjoy your reloading process!