

Neck Bushing ⌀12,7-7,37/.2902

[Reloading](#) > [Reloading Dies](#) > [Neck Size Bushings](#)

Neck sizing bushing made from high-quality hardened steel, precision-ground internally and externally in a single setup on CNC machines – ensuring perfect concentricity and maximum dimensional accuracy. Designed for precise neck sizing. Suitable for original reloading dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Neck Bushing ⌀12,7-7,37/.2902](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017669
- Mfr. No.: 3000240V-07.37
- Diameter mm: 12,7 / 7,37
- Delivery weight: 0.02kg
- Shipping height: 25mm
- Shipping width: 60mm
- Shipping length: 50mm
- EAN/UPC: 3000240V-07.37

Table of Contents

- [Startpage](#)
- [Neck Bushing Safety Instruction Guide](#)
- [About Us](#)

Neck Bushing Safety Instruction Guide

Introduction

Thank you for choosing the Neck Bushing manufactured by TRIEBEL. This guide provides important safety instructions and guidelines to ensure safe and effective use of the product. Please read this manual carefully before using the Neck Bushing.

General Safety Guidelines

- Ensure that the Neck Bushing is used only for its intended purpose of neck sizing during reloading.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses when using the Neck Bushing.
- Keep the Neck Bushing out of reach of children and vulnerable individuals.
- Regularly inspect the Neck Bushing for any signs of damage or wear before each use.
- If the Neck Bushing is damaged, do not use it. Contact the manufacturer for further assistance.

Specific Safety Precautions for Use

- Use the Neck Bushing only with compatible reloading dies from Triebel Waffenwerkzeuge.
- Do not exceed the specified diameter range of 12.7 mm to 7.37 mm when using the Neck Bushing.
- Ensure that the Neck Bushing is properly secured in the reloading press before operation.
- Avoid using excessive force when resizing to prevent damage to the bushing or the reloading equipment.
- Always follow the reloading guidelines provided by the manufacturer of your reloading equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure the reloading press is turned off and unplugged.
- Insert the Neck Bushing into the appropriate die according to the die manufacturer's instructions.
- Secure the Neck Bushing firmly in place.

2. Usage:

- Adjust the reloading press settings according to the specifications for neck sizing.
- Place the cartridge case in the reloading press and ensure it is aligned with the Neck Bushing.
- Gradually apply pressure to resize the neck of the cartridge case.
- After resizing, remove the cartridge case and inspect it for proper sizing.

Disposal Instructions

- Dispose of the Neck Bushing in accordance with local regulations and guidelines.
- If the Neck Bushing is no longer usable, consider recycling it if possible, as it is made from highquality hardened steel.

Contact Information for Further Support

For any safety inquiries, product support, or to report unsafe products, please refer to the appropriate EU contact point or safety authority in your region.

By following these safety guidelines and instructions, you can ensure a safe and effective experience while using the Neck Bushing. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk